



# JEEP Function list V18.2

Notes:	
√	Functions is fully supported and already existed in former software version.
※	Functions is fully supported and newly added in current software version.
Number	Index number of the special function , you can find the name from the special function table.
	Functions is not supported.

## Special Function Table

0001	ABS Bleed Brakes	0030	Initialize Steering Angle Sensor
0002	ABS Initialization	0031	Injector Kill System Test
0003	Actuate Engine Battery Feed	0032	Injector Quantity Adjustment
0004	Battery Pack Fan Test	0033	Isolation Fault Reset
0005	Bleed Brakes	0034	Left Front Tire Pressure Signal Transmission Test
0006	Bleed Brakes 2WD	0035	Left Rear Tire Pressure Signal Transmission Test
0007	Bleed Brakes 4WD	0036	New DPF Initialize
0008	Bleed Brakes ABS only	0038	Oil Change Reset
0009	Bleed Brakes:LX	0039	Oil change
0010	Bleed Brakes:WK	0040	Reset Active Discharge Fault
0011	DPF Pressure Sensor Reset	0041	Reset Enhanced Automatic Oil Change Indicator
0012	DPF Regeneration	0042	Reset High Voltage Impact Event
0013	DPF Replacement	0043	Reset Odometer
0014	DPF Reset Option	0044	Reset Oil Change Indicator
0015	Diesel Particulate Filter Replacement	0045	Reset Weld Check Fault
0016	Display Diesel Particulate Filter Values	0046	Right Front Tire Pressure Signal Transmission Test
0017	Electronic Throttle Control (ETC) Throttle Follower Test	0047	Right Rear Tire Pressure Signal Transmission Test
0018	Enable/Disable HV Battery Contactors	0048	Service Diesel Particulate Filter Regeneration
0019	HV Battery Balance Test	0049	Set Oil Dilution Mass Value
0020	HV Battery Isolation Test	0050	Set RPM Test - Electronic Throttle Control (ETC) equipped
0021	High Voltage Battery Charge	0051	Throttle Valve Actuator (TVA) DC Motor test
0022	High Voltage Battery Drain	0052	Throttle Valve Initialization
0023	High Voltage Battery Negative Contactor Test	0053	Throttle Valve Learn
0024	High Voltage Battery Positive Contactor Test	0054	Verify Front TPM Antenna
0025	High Voltage Battery Precharge Contactor Test	0055	Verify Rear TPM Antenna
0026	Hybrid Battery Contactor Test	0056	View Battery Pack Information
0027	Initialize ABS	0057	View Electronic TPM ID
0028	Initialize ABS Module	0058	View Hybrid Battery Reasons Contactor Not Closing When Commanded
0029	Initialize ABS Non ESP	0059	View Oil Dilution Mass Value

Vehicle	System	Ecu Info.	Read Codes	Erase Codes	Live data	Active Test	Special Function
2004\HB-Durango	ECM -- Engine Control Module	√	√	√	√	√	
2004\HB-Durango	TCM -- Transmission Control Module	√	√	√	√	√	
2004\HB-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	0007, 0006, 0008, 0008

2004\HB-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2004\HB-Durango	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2004\HB-Durango	CGW -- Central Gateway	√	√	√	√	√	
2004\HB-Durango	WCM/TPMS -- Wireless Control	√	√	√	√		
2004\HB-Durango	RADIO -- Radio	√	√	√	√		
2004\HB-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2004\HB-Durango	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2004\HB-Durango	DDM -- Driver Door Module	√	√	√	√	√	
2004\HB-Durango	PDM -- Passenger Door Module	√	√	√	√	√	
2004\HB-Durango	OCM -- Occupant Classification	√	√	√	√		
2004\HB-Durango	EOM -- Electronic Overhead	√	√	√	√	√	
2004\HB-Durango	SDAR -- Satellite Radio	√	√	√	√		
2004\HB-Durango	AMP -- Amplifier	√	√	√	√		
2004\HB-Durango	HFM -- Hands Free Module	√	√	√	√	√	
2004\HB-Durango	VES -- Vehicle Entertainment System	√	√	√	√	√	
2004\HB-Durango	HSM -- Heated Seat Module	√	√	√	√	√	
2005\HB-Durango	ECM -- Engine Control Module	√	√	√	√	√	0031, 0050
2005\HB-Durango	TCM -- Transmission Control Module	√	√	√	√	√	
2005\HB-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	0007, 0006, 0008, 0008
2005\HB-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2005\HB-Durango	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2005\HB-Durango	CGW -- Central Gateway	√	√	√	√	√	
2005\HB-Durango	WCM/TPMS -- Wireless Control	√	√	√	√		
2005\HB-Durango	RADIO -- Radio	√	√	√	√		
2005\HB-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2005\HB-Durango	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2005\HB-Durango	DDM -- Driver Door Module	√	√	√	√	√	
2005\HB-Durango	OCM -- Occupant Classification	√	√	√	√		
2005\HB-Durango	EOM -- Electronic Overhead	√	√	√	√		
2005\HB-Durango	SDAR -- Satellite Radio	√	√	√	√		
2005\HB-Durango	AMP -- Amplifier	√	√	√	√		
2005\HB-Durango	HFM -- Hands Free Module	√	√	√	√	√	
2005\HB-Durango	VES -- Vehicle Entertainment System	√	√	√	√	√	
2005\HB-Durango	HSM -- Heated Seat Module	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	ECM -- Engine Control Module	√	√	√	√	√	0050, 0031
2005\LX-300,Charger,Magnum,Grand Voyager	TCM -- Transmission Control Module	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	ABS -- Anti Lock Brakes	√	√	√	√	√	0028, 0005, 0002, 0030, 0009, 0010
2005\LX-300,Charger,Magnum,Grand Voyager	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2005\LX-300,Charger,Magnum,Grand Voyager	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	

2005\LX-300,Charger,Magnum,Grand Voyager	CGW -- Central Gateway	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	WCM/TPMS -- Wireless Control	√	√	√	√		
2005\LX-300,Charger,Magnum,Grand Voyager	PTS -- Parktronics	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	RADIO -- Radio	√	√	√	√		
2005\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2005\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	SCM -- Steering Column	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	OCM -- Occupant Classification	√	√	√	√		
2005\LX-300,Charger,Magnum,Grand Voyager	SUNR -- Sunroof	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	EOM -- Electronic Overhead	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	RSM -- Rain Sensor Module	√	√	√	√		
2005\LX-300,Charger,Magnum,Grand Voyager	SDAR -- Satellite Radio	√	√	√	√		
2005\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√		
2005\LX-300,Charger,Magnum,Grand Voyager	HFM -- Hands Free Module	√	√	√	√	√	
2005\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2005\ND-Dakota	ECM -- Engine Control Module	√	√	√	√	√	0031, 0050
2005\ND-Dakota	TCM -- Transmission Control Module	√	√	√	√	√	
2005\ND-Dakota	ABS -- Anti Lock Brakes	√	√	√	√	√	0005, 0028
2005\ND-Dakota	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2005\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2005\ND-Dakota	CGW -- Central Gateway	√	√	√	√	√	
2005\ND-Dakota	WCM/TPMS -- Wireless Control	√	√	√	√		
2005\ND-Dakota	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2005\ND-Dakota	OCM -- Occupant Classification	√	√	√	√		
2005\ND-Dakota	EOM -- Electronic Overhead	√	√	√	√		

2005\ND-Dakota	SDAR -- Satellite Radio	√	√	√	√		
2005\ND-Dakota	AMP -- Amplifier	√	√	√	√		
2005\ND-Dakota	HFM -- Hands Free Module	√	√	√	√	√	
2005\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	0031, 0050
2005\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√	√	
2005\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005, 0028, 0030
2005\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2005\WK-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2005\WK-Grand Cherokee	CGW -- Central Gateway	√	√	√	√	√	
2005\WK-Grand Cherokee	WCM/TPMS -- Wireless Control	√	√	√	√		
2005\WK-Grand Cherokee	PTS -- Parktronics	√	√	√	√	√	
2005\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√		
2005\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2005\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2005\WK-Grand Cherokee	DDM -- Driver Door Module	√	√	√	√	√	
2005\WK-Grand Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2005\WK-Grand Cherokee	SCM -- Steering Column	√	√	√	√		
2005\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2005\WK-Grand Cherokee	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2005\WK-Grand Cherokee	OCM -- Occupant Classification	√	√	√	√		
2005\WK-Grand Cherokee	SUNR -- Sunroof	√	√	√	√	√	
2005\WK-Grand Cherokee	AHBM -- Automatic High Beam	√	√	√	√	√	
2005\WK-Grand Cherokee	EOM -- Electronic Overhead	√	√	√	√		
2005\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2005\WK-Grand Cherokee	RSM -- Rain Sensor Module	√	√	√	√		
2005\WK-Grand Cherokee	SDAR -- Satellite Radio	√	√	√	√		
2005\WK-Grand Cherokee	AMP -- Amplifier	√	√	√	√		
2005\WK-Grand Cherokee	HFM -- Hands Free Module	√	√	√	√	√	
2005\WK-Grand Cherokee	VES -- Vehicle Entertainment System	√	√	√	√	√	
2005\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2006\DR-RAM	ECM -- Engine Control Module	√	√	√	√	√	
2006\DR-RAM	TCM -- Transmission Control Module	√	√	√	√	√	
2006\DR-RAM	ABS -- Anti Lock Brakes	√	√	√	√	√	
2006\DR-RAM	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2006\DR-RAM	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2006\DR-RAM	CGW -- Central Gateway	√	√	√	√	√	0003
2006\DR-RAM	RADIO -- Radio	√	√	√	√		
2006\DR-RAM	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2006\DR-RAM	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2006\DR-RAM	OCM -- Occupant Classification	√	√	√	√		
2006\DR-RAM	SUNR -- Sunroof	√	√	√	√	√	
2006\DR-RAM	EOM -- Electronic Overhead	√	√	√	√		
2006\DR-RAM	SDAR -- Satellite Radio	√	√	√	√		
2006\DR-RAM	AMP -- Amplifier	√	√	√	√		
2006\DR-RAM	HFM -- Hands Free Module	√	√	√	√	√	

2006\DR-RAM	VES -- Vehicle Entertainment System	√	√	√	√	√	
2006\HB-Durango	ECM -- Engine Control Module	√	√	√	√	√	
2006\HB-Durango	TCM -- Transmission Control Module	√	√	√	√	√	
2006\HB-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	
2006\HB-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2006\HB-Durango	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2006\HB-Durango	CGW -- Central Gateway	√	√	√	√	√	
2006\HB-Durango	WCM/TPMS -- Wireless Control	√	√	√	√		
2006\HB-Durango	SAS -- Steering Angle Sensor	√	√	√	√		
2006\HB-Durango	RADIO -- Radio	√	√	√	√		
2006\HB-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2006\HB-Durango	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2006\HB-Durango	DDM -- Driver Door Module	√	√	√	√	√	
2006\HB-Durango	PDM -- Passenger Door Module	√	√	√	√	√	
2006\HB-Durango	PLGM -- Power Liftgate Module	√	√	√	√	√	
2006\HB-Durango	OCM -- Occupant Classification	√	√	√	√		
2006\HB-Durango	EOM -- Electronic Overhead	√	√	√	√		
2006\HB-Durango	SDAR -- Satellite Radio	√	√	√	√		
2006\HB-Durango	AMP -- Amplifier	√	√	√	√		
2006\HB-Durango	HFM -- Hands Free Module	√	√	√	√	√	
2006\HB-Durango	VES -- Vehicle Entertainment System	√	√	√	√	√	
2006\HB-Durango	HSM -- Heated Seat Module	√	√	√	√	√	
2006\KJ-Liberty	ECM -- Engine Control Module	√	√	√	√	√	
2006\KJ-Liberty	TCM -- Transmission Control Module	√	√	√	√	√	
2006\KJ-Liberty	ABS -- Anti Lock Brakes	√	√	√	√	√	
2006\KJ-Liberty	SAS -- Steering Angle Sensor	√	√	√	√		
2006\LX-300,Charger,Magnum,Grand Voyager	ECM -- Engine Control Module	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	TCM -- Transmission Control Module	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005, 0028, 0030
2006\LX-300,Charger,Magnum,Grand Voyager	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2006\LX-300,Charger,Magnum,Grand Voyager	CGW -- Central Gateway	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	WCM/TPMS -- Wireless Control	√	√	√	√		
2006\LX-300,Charger,Magnum,Grand Voyager	PTS -- Parktronics	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	RADIO -- Radio	√	√	√	√		
2006\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		

2006\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	SCM -- Steering Column	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	OCM -- Occupant Classification	√	√	√	√		
2006\LX-300,Charger,Magnum,Grand Voyager	SUNR -- Sunroof	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	PTIM -- Police/Taxi Interface Module	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	AHBM -- Automatic High Beam	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	EOM -- Electronic Overhead	√	√	√	√		
2006\LX-300,Charger,Magnum,Grand Voyager	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	RSM -- Rain Sensor Module	√	√	√	√		
2006\LX-300,Charger,Magnum,Grand Voyager	SDAR -- Satellite Radio	√	√	√	√		
2006\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√		
2006\LX-300,Charger,Magnum,Grand Voyager	HFM -- Hands Free Module	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	VES -- Vehicle Entertainment System	√	√	√	√	√	
2006\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2006\ND-Dakota	ECM -- Engine Control Module	√	√	√	√	√	
2006\ND-Dakota	TCM -- Transmission Control Module	√	√	√	√	√	
2006\ND-Dakota	ABS -- Anti Lock Brakes	√	√	√	√	√	
2006\ND-Dakota	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2006\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2006\ND-Dakota	CGW -- Central Gateway	√	√	√	√	√	
2006\ND-Dakota	WCM/TPMS -- Wireless Control	√	√	√	√		
2006\ND-Dakota	RADIO -- Radio	√	√	√	√		
2006\ND-Dakota	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2006\ND-Dakota	OCM -- Occupant Classification	√	√	√	√		
2006\ND-Dakota	EOM -- Electronic Overhead	√	√	√	√		
2006\ND-Dakota	SDAR -- Satellite Radio	√	√	√	√		
2006\ND-Dakota	AMP -- Amplifier	√	√	√	√		
2006\ND-Dakota	HFM -- Hands Free Module	√	√	√	√	√	

2006\NM-Raider	ECM -- Engine Control Module	√	√	√	√	√	
2006\NM-Raider	TCM -- Transmission Control Module	√	√	√	√	√	
2006\NM-Raider	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2006\NM-Raider	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2006\NM-Raider	CGW -- Central Gateway	√	√	√	√	√	
2006\NM-Raider	WCM/TPMS -- Wireless Control	√	√	√	√		
2006\NM-Raider	RADIO -- Radio	√	√	√	√		
2006\NM-Raider	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2006\NM-Raider	OCM -- Occupant Classification	√	√	√	√		
2006\NM-Raider	EOM -- Electronic Overhead	√	√	√	√		
2006\NM-Raider	SDAR -- Satellite Radio	√	√	√	√		
2006\NM-Raider	AMP -- Amplifier	√	√	√	√		
2006\NM-Raider	HFM -- Hands Free Module	√	√	√	√	√	
2006\PT-PT Cruiser	ECM -- Engine Control Module	√	√	√	√	√	0050, 0017, 0031, 0031
2006\PT-PT Cruiser	TCM -- Transmission Control Module	√	√	√	√	√	
2006\PT-PT Cruiser	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005, 0028, 0030
2006\PT-PT Cruiser	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2006\PT-PT Cruiser	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2006\PT-PT Cruiser	CGW -- Central Gateway	√	√	√	√	√	0003
2006\PT-PT Cruiser	WCM/TPMS -- Wireless Control	√	√	√	√		
2006\PT-PT Cruiser	RADIO -- Radio	√	√	√	√		
2006\PT-PT Cruiser	DDM -- Driver Door Module	√	√	√	√	√	
2006\PT-PT Cruiser	PDM -- Passenger Door Module	√	√	√	√	√	
2006\PT-PT Cruiser	OCM -- Occupant Classification	√	√	√	√		
2006\PT-PT Cruiser	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2006\PT-PT Cruiser	SDAR -- Satellite Radio	√	√	√	√		
2006\PT-PT Cruiser	AMP -- Amplifier	√	√	√	√		
2006\PT-PT Cruiser	HFM -- Hands Free Module	√	√	√	√	√	
2006\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	
2006\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√	√	
2006\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	
2006\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2006\WK-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2006\WK-Grand Cherokee	CGW -- Central Gateway	√	√	√	√	√	
2006\WK-Grand Cherokee	WCM/TPMS -- Wireless Control	√	√	√	√		
2006\WK-Grand Cherokee	PTS -- Parktronics	√	√	√	√	√	
2006\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√		
2006\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2006\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2006\WK-Grand Cherokee	DDM -- Driver Door Module	√	√	√	√	√	
2006\WK-Grand Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2006\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2006\WK-Grand Cherokee	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2006\WK-Grand Cherokee	OCM -- Occupant Classification	√	√	√	√		
2006\WK-Grand Cherokee	TM -- Trailer		√	√			

2006\WK-Grand Cherokee	SUNR -- Sunroof	√	√	√	√	√	
2006\WK-Grand Cherokee	AHBM -- Automatic High Beam	√	√	√	√	√	
2006\WK-Grand Cherokee	EOM -- Electronic Overhead	√	√	√	√		
2006\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2006\WK-Grand Cherokee	RSM -- Rain Sensor Module	√	√	√	√		
2006\WK-Grand Cherokee	SDAR -- Satellite Radio	√	√	√	√		
2006\WK-Grand Cherokee	AMP -- Amplifier	√	√	√	√		
2006\WK-Grand Cherokee	HFM -- Hands Free Module	√	√	√	√	√	
2006\WK-Grand Cherokee	VES -- Vehicle Entertainment System	√	√	√	√	√	
2006\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2006\XK-Commander	ECM -- Engine Control Module	√	√	√	√	√	
2006\XK-Commander	TCM -- Transmission Control Module	√	√	√	√	√	
2006\XK-Commander	ABS -- Anti Lock Brakes	√	√	√	√	√	
2006\XK-Commander	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2006\XK-Commander	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2006\XK-Commander	CGW -- Central Gateway	√	√	√	√	√	
2006\XK-Commander	WCM/TPMS -- Wireless Control	√	√	√	√		
2006\XK-Commander	PTS -- Parktronic	√	√	√	√	√	
2006\XK-Commander	RADIO -- Radio	√	√	√	√		
2006\XK-Commander	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2006\XK-Commander	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2006\XK-Commander	DDM -- Driver Door Module	√	√	√	√	√	
2006\XK-Commander	PDM -- Passenger Door Module	√	√	√	√	√	
2006\XK-Commander	SCM -- Steering Column	√	√	√	√		
2006\XK-Commander	ESM -- Electronic Shifter	√	√	√	√	√	
2006\XK-Commander	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2006\XK-Commander	OCM -- Occupant Classification	√	√	√	√		
2006\XK-Commander	TM -- Trailer		√	√			
2006\XK-Commander	SUNR -- Sunroof	√	√	√	√	√	
2006\XK-Commander	AHBM -- Automatic High Beam	√	√	√	√	√	
2006\XK-Commander	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2006\XK-Commander	RSM -- Rain Sensor Module	√	√	√	√		
2006\XK-Commander	SDAR -- Satellite Radio	√	√	√	√		
2006\XK-Commander	AMP -- Amplifier	√	√	√	√		
2006\XK-Commander	HFM -- Hands Free Module	√	√	√	√	√	
2006\XK-Commander	HSM -- Heated Seat Module	√	√	√	√	√	
2007\CS-Pacifica	ECM -- Engine Control Module	√	√	√	√	√	
2007\CS-Pacifica	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\CS-Pacifica	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\CS-Pacifica	CGW -- Central Gateway	√	√	√	√	√	
2007\CS-Pacifica	SAS -- Steering Angle Sensor	√	√	√	√		
2007\CS-Pacifica	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2007\CS-Pacifica	PLGM -- Power Liftgate Module	√	√	√	√	√	
2007\DR-RAM	ECM -- Engine Control Module	√	√	√	√	√	0031, 0032, 0031
2007\DR-RAM	TCM -- Transmission Control Module	√	√	√	√	√	



2007\DR-RAM	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\DR-RAM	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\DR-RAM	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\DR-RAM	CGW -- Central Gateway	√	√	√	√	√	
2007\DR-RAM	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\DR-RAM	SAS -- Steering Angle Sensor	√	√	√	√		
2007\DR-RAM	RADIO -- Radio	√	√	√	√		
2007\DR-RAM	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2007\DR-RAM	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2007\DR-RAM	SUNR -- Sunroof	√	√	√	√	√	
2007\DR-RAM	EOM -- Electronic Overhead	√	√	√	√	√	
2007\DR-RAM	SDAR -- Satellite Radio	√	√	√	√		
2007\DR-RAM	AMP -- Amplifier	√	√	√	√		
2007\DR-RAM	HFM -- Hands Free Module	√	√	√	√	√	
2007\DR-RAM	VES -- Vehicle Entertainment System	√	√	√	√	√	
2007\HB-Durango	ECM -- Engine Control Module	√	√	√	√	√	
2007\HB-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\HB-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\HB-Durango	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\HB-Durango	CGW -- Central Gateway	√	√	√	√	√	
2007\HB-Durango	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\HB-Durango	SAS -- Steering Angle Sensor	√	√	√	√		
2007\HB-Durango	PTS -- Parktronics	√	√	√	√	√	
2007\HB-Durango	RADIO -- Radio	√	√	√	√		
2007\HB-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2007\HB-Durango	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2007\HB-Durango	DDM -- Driver Door Module	√	√	√	√	√	
2007\HB-Durango	PDM -- Passenger Door Module	√	√	√	√	√	
2007\HB-Durango	PLGM -- Power Liftgate Module	√	√	√	√	√	
2007\HB-Durango	EOM -- Electronic Overhead	√	√	√	√	√	
2007\HB-Durango	SDAR -- Satellite Radio	√	√	√	√		
2007\HB-Durango	AMP -- Amplifier	√	√	√	√		
2007\HB-Durango	HFM -- Hands Free Module	√	√	√	√	√	
2007\HB-Durango	VES -- Vehicle Entertainment System	√	√	√	√	√	
2007\HB-Durango	HSM -- Heated Seat Module	√	√	√	√	√	
2007\HG-Aspen	ECM -- Engine Control Module	√	√	√	√	√	
2007\HG-Aspen	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\HG-Aspen	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\HG-Aspen	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\HG-Aspen	CGW -- Central Gateway	√	√	√	√	√	
2007\HG-Aspen	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\HG-Aspen	SAS -- Steering Angle Sensor	√	√	√	√		
2007\HG-Aspen	PTS -- Parktronics	√	√	√	√	√	
2007\HG-Aspen	RADIO -- Radio	√	√	√	√		
2007\HG-Aspen	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	

2007\HG-Aspen	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2007\HG-Aspen	DDM -- Driver Door Module	√	√	√	√	√	
2007\HG-Aspen	PDM -- Passenger Door Module	√	√	√	√	√	
2007\HG-Aspen	PLGM -- Power Liftgate Module	√	√	√	√	√	
2007\HG-Aspen	EOM -- Electronic Overhead	√	√	√	√	√	
2007\HG-Aspen	SDAR -- Satellite Radio	√	√	√	√		
2007\HG-Aspen	AMP -- Amplifier	√	√	√	√		
2007\HG-Aspen	HFM -- Hands Free Module	√	√	√	√		
2007\HG-Aspen	VES -- Vehicle Entertainment System	√	√	√	√	√	
2007\HG-Aspen	HSM -- Heated Seat Module	√	√	√	√	√	
2007\JK-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2007\JK-Wrangler	TCM -- Transmission Control Module	√	√	√	√	√	
2007\JK-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\JK-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\JK-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2007\JK-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\JK-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2007\JK-Wrangler	RADIO -- Radio	√	√	√	√	√	
2007\JK-Wrangler	OCM -- Occupant Classification	√	√	√	√		
2007\JK-Wrangler	ASBS -- Automatic Sway Bar System	√	√	√	√		
2007\JK-Wrangler	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2007\JK-Wrangler	AMP -- Amplifier	√	√	√	√		
2007\JS-Avenger,Sebring,Convertible-Sedan	TCM -- Transmission Control Module	√	√	√	√	√	
2007\JS-Avenger,Sebring,Convertible-Sedan	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\JS-Avenger,Sebring,Convertible-Sedan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\JS-Avenger,Sebring,Convertible-Sedan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\JS-Avenger,Sebring,Convertible-Sedan	CGW -- Central Gateway	√	√	√	√	√	
2007\JS-Avenger,Sebring,Convertible-Sedan	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\JS-Avenger,Sebring,Convertible-Sedan	SAS -- Steering Angle Sensor	√	√	√	√		
2007\JS-Avenger,Sebring,Convertible-Sedan	RADIO -- Radio	√	√	√	√	√	
2007\JS-Avenger,Sebring,Convertible-Sedan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2007\JS-Avenger,Sebring,Convertible-Sedan	DDM -- Driver Door Module	√	√	√	√	√	
2007\JS-Avenger,Sebring,Convertible-Sedan	PDM -- Passenger Door Module	√	√	√	√	√	
2007\JS-Avenger,Sebring,Convertible-Sedan	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		

2007\JS-Avenger,Sebring,Convertible-Sedan	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2007\JS-Avenger,Sebring,Convertible-Sedan	PTCM -- Power Top Control Module	√	√	√	√		
2007\JS-Avenger,Sebring,Convertible-Sedan	AMP -- Amplifier	√	√	√	√		
2007\JS-Avenger,Sebring,Convertible-Sedan	HFM -- Hands Free Module	√	√	√	√	√	
2007\JS-Avenger,Sebring,Convertible-Sedan	VES3 -- Last Row Screen	√	√	√	√	√	
2007\KA-Nitro	ECM -- Engine Control Module	√	√	√	√	√	
2007\KA-Nitro	TCM -- Transmission Control Module	√	√	√	√		
2007\KA-Nitro	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\KA-Nitro	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\KA-Nitro	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\KA-Nitro	CGW -- Central Gateway	√	√	√	√	√	0003
2007\KA-Nitro	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\KA-Nitro	SAS -- Steering Angle Sensor	√	√	√	√		
2007\KA-Nitro	PTS -- Parktronics	√	√	√	√	√	
2007\KA-Nitro	RADIO -- Radio	√	√	√	√	√	
2007\KA-Nitro	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2007\KA-Nitro	DMFR -- Door Module Front Right	√	√	√	√	√	
2007\KA-Nitro	DMFL -- Door Module Front Left	√	√	√	√	√	
2007\KA-Nitro	ESM -- Electronic Shifter	√	√	√	√	√	
2007\KA-Nitro	OCM -- Occupant Classification	√	√	√	√		
2007\KA-Nitro	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2007\KA-Nitro	AMP -- Amplifier	√	√	√	√		
2007\KA-Nitro	HFM -- Hands Free Module	√	√	√	√	√	
2007\KA-Nitro	VES3 -- Last Row Screen	√	√	√	√	√	
2007\KJ-Liberty	ECM -- Engine Control Module	√	√	√	√	√	
2007\KJ-Liberty	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\KJ-Liberty	SAS -- Steering Angle Sensor	√	√	√	√		
2007\LX-300,Charger,Magnum,Grand Voyager	TCM -- Transmission Control Module	√	√	√	√		
2007\LX-300,Charger,Magnum,Grand Voyager	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\LX-300,Charger,Magnum,Grand Voyager	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	CGW -- Central Gateway	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\LX-300,Charger,Magnum,Grand Voyager	PTS -- Parktronics	√	√	√	√	√	

2007\LX-300,Charger,Magnum,Grand Voyager	RADIO -- Radio	√	√	√	√		
2007\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	ACC -- Adaptive Cruise Control	√	√	√	√		
2007\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2007\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	SCM -- Steering Column	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	SUNR -- Sunroof	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	PTIM -- Police/Taxi Interface Module	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	AHBM -- Automatic High Beam	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	EOM -- Electronic Overhead	√	√	√	√		
2007\LX-300,Charger,Magnum,Grand Voyager	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	RSM -- Rain Sensor Module	√	√	√	√		
2007\LX-300,Charger,Magnum,Grand Voyager	SDAR -- Satellite Radio	√	√	√	√		
2007\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√		
2007\LX-300,Charger,Magnum,Grand Voyager	HFM -- Hands Free Module	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	VES -- Vehicle Entertainment System	√	√	√	√	√	
2007\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2007\MK-Compass,Patriot	ECM -- Engine Control Module	√	√	√	√	√	
2007\MK-Compass,Patriot	TCM -- Transmission Control Module	√	√	√	√	√	
2007\MK-Compass,Patriot	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\MK-Compass,Patriot	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\MK-Compass,Patriot	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\MK-Compass,Patriot	CGW -- Central Gateway	√	√	√	√	√	
2007\MK-Compass,Patriot	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\MK-Compass,Patriot	SAS -- Steering Angle Sensor	√	√	√	√		

2007\MK-Compass,Patriot	RADIO -- Radio	√	√	√	√		
2007\MK-Compass,Patriot	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2007\MK-Compass,Patriot	OCM -- Occupant Classification	√	√	√	√		
2007\MK-Compass,Patriot	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2007\MK-Compass,Patriot	AMP -- Amplifier	√	√	√	√		
2007\MK-Compass,Patriot	HFM -- Hands Free Module	√	√	√	√	√	
2007\ND-Dakota	ECM -- Engine Control Module	√	√	√	√	√	
2007\ND-Dakota	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\ND-Dakota	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\ND-Dakota	CGW -- Central Gateway	√	√	√	√	√	
2007\ND-Dakota	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\ND-Dakota	RADIO -- Radio	√	√	√	√		
2007\ND-Dakota	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2007\ND-Dakota	OCM -- Occupant Classification	√	√	√	√		
2007\ND-Dakota	EOM -- Electronic Overhead	√	√	√	√	√	
2007\ND-Dakota	SDAR -- Satellite Radio	√	√	√	√		
2007\ND-Dakota	AMP -- Amplifier	√	√	√	√		
2007\NM-Raider	ECM -- Engine Control Module	√	√	√	√	√	
2007\NM-Raider	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\NM-Raider	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\NM-Raider	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\NM-Raider	CGW -- Central Gateway	√	√	√	√	√	
2007\NM-Raider	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\NM-Raider	RADIO -- Radio	√	√	√	√		
2007\NM-Raider	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2007\NM-Raider	OCM -- Occupant Classification	√	√	√	√		
2007\NM-Raider	EOM -- Electronic Overhead	√	√	√	√	√	
2007\NM-Raider	SDAR -- Satellite Radio	√	√	√	√		
2007\NM-Raider	AMP -- Amplifier	√	√	√	√		
2007\PM-Caliber	ECM -- Engine Control Module	√	√	√	√	√	
2007\PM-Caliber	TCM -- Transmission Control Module	√	√	√	√	√	
2007\PM-Caliber	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\PM-Caliber	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\PM-Caliber	CGW -- Central Gateway	√	√	√	√	√	
2007\PM-Caliber	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\PM-Caliber	SAS -- Steering Angle Sensor	√	√	√	√		
2007\PM-Caliber	RADIO -- Radio	√	√	√	√		
2007\PM-Caliber	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2007\PM-Caliber	OCM -- Occupant Classification	√	√	√	√		
2007\PM-Caliber	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2007\PM-Caliber	SDAR -- Satellite Radio	√	√	√	√		
2007\PM-Caliber	HFM -- Hands Free Module	√	√	√	√	√	
2007\PT-PT Cruiser	ECM -- Engine Control Module	√	√	√	√	√	0050, 0017, 0031, 0031

2007\PT-PT Cruiser	TCM -- Transmission Control Module	√	√	√	√	√	
2007\PT-PT Cruiser	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005, 0028, 0030
2007\PT-PT Cruiser	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\PT-PT Cruiser	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\PT-PT Cruiser	CGW -- Central Gateway	√	√	√	√	√	0003
2007\PT-PT Cruiser	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\PT-PT Cruiser	RADIO -- Radio	√	√	√	√		
2007\PT-PT Cruiser	DDM -- Driver Door Module	√	√	√	√	√	
2007\PT-PT Cruiser	PDM -- Passenger Door Module	√	√	√	√	√	
2007\PT-PT Cruiser	OCM -- Occupant Classification	√	√	√	√		
2007\PT-PT Cruiser	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2007\PT-PT Cruiser	SDAR -- Satellite Radio	√	√	√	√		
2007\PT-PT Cruiser	AMP -- Amplifier	√	√	√	√		
2007\PT-PT Cruiser	HFM -- Hands Free Module	√	√	√	√	√	
2007\VB-Sprinter	ECM -- Engine Control Module	√	√	√	√	√	0052, 0031
2007\VB-Sprinter	TCM -- Transmission Control Module	√	√	√	√		
2007\VB-Sprinter	ABS -- Anti Lock Brakes	√	√	√	√		0005
2007\VB-Sprinter	ORC -- AirBag/Occupant Restraint	√	√	√			
2007\VB-Sprinter	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√		0038
2007\VB-Sprinter	TPM -- Tire Pressure Monitor	√	√	√	√		0034, 0035, 0046, 0047, 0054, 0055, 0057
2007\VB-Sprinter	BCM -- Body Controller	√	√	√	√	√	
2007\VB-Sprinter	CGW -- Central Gateway	√	√	√	√		
2007\VB-Sprinter	PTS -- Parktronic	√	√	√	√	√	
2007\VB-Sprinter	RADIO -- Radio	√	√	√	√		
2007\VB-Sprinter	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2007\VB-Sprinter	DDM -- Driver Door Module	√	√	√	√	√	
2007\VB-Sprinter	SCM -- Steering Column	√	√	√	√	√	
2007\VB-Sprinter	SBM -- Center Console / Switch Bank Module	√	√	√	√	√	
2007\VB-Sprinter	ESM -- Electronic Shifter	√	√	√	√	√	
2007\VB-Sprinter	BCH -- Booster Cabin Heater Module (ZHZ)	√	√	√	√	√	
2007\VB-Sprinter	ACH -- Auxiliary Cabin Heater (STH)	√	√	√	√	√	
2007\VB-Sprinter	TM -- Trailer	√	√	√	√		
2007\VB-Sprinter	AHLM -- Headlamp Leveling	√	√	√	√	√	
2007\VB-Sprinter	RCM -- Roof Control Module	√	√	√	√	√	
2007\VB-Sprinter	AEHM -- Auxiliary Electrical Heating Module	√	√	√	√		
2007\VB-Sprinter	CDC -- CD Changer	√	√	√	√		
2007\VB-Sprinter	PSM -- Universal/Special ECU	√	√	√	√	√	
2007\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	
2007\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2007\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\WK-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	

2007\WK-Grand Cherokee	CGW -- Central Gateway	√	√	√	√	√	
2007\WK-Grand Cherokee	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\WK-Grand Cherokee	PTS -- Parktronics	√	√	√	√	√	
2007\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√		
2007\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2007\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2007\WK-Grand Cherokee	DDM -- Driver Door Module	√	√	√	√	√	
2007\WK-Grand Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2007\WK-Grand Cherokee	SCM -- Steering Column	√	√	√	√		
2007\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2007\WK-Grand Cherokee	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2007\WK-Grand Cherokee	TM -- Trailer		√	√			
2007\WK-Grand Cherokee	SUNR -- Sunroof	√	√	√	√	√	
2007\WK-Grand Cherokee	AHBM -- Automatic High Beam	√	√	√	√	√	
2007\WK-Grand Cherokee	EOM -- Electronic Overhead	√	√	√	√		
2007\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2007\WK-Grand Cherokee	RSM -- Rain Sensor Module	√	√	√	√		
2007\WK-Grand Cherokee	SDAR -- Satellite Radio	√	√	√	√		
2007\WK-Grand Cherokee	AMP -- Amplifier	√	√	√	√		
2007\WK-Grand Cherokee	HFM -- Hands Free Module	√	√	√	√	√	
2007\WK-Grand Cherokee	VES -- Vehicle Entertainment System	√	√	√	√	√	
2007\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2007\XK-Commander	ECM -- Engine Control Module	√	√	√	√	√	
2007\XK-Commander	TCM -- Transmission Control Module	√	√	√	√		
2007\XK-Commander	ABS -- Anti Lock Brakes	√	√	√	√	√	
2007\XK-Commander	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2007\XK-Commander	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2007\XK-Commander	CGW -- Central Gateway	√	√	√	√	√	
2007\XK-Commander	WCM/TPMS -- Wireless Control	√	√	√	√		
2007\XK-Commander	PTS -- Parktronics	√	√	√	√	√	
2007\XK-Commander	RADIO -- Radio	√	√	√	√		
2007\XK-Commander	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2007\XK-Commander	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2007\XK-Commander	PDM -- Passenger Door Module	√	√	√	√	√	
2007\XK-Commander	SCM -- Steering Column	√	√	√	√		
2007\XK-Commander	ESM -- Electronic Shifter	√	√	√	√	√	
2007\XK-Commander	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2007\XK-Commander	PLGM -- Power Liftgate Module	√	√	√	√	√	
2007\XK-Commander	TM -- Trailer		√	√			
2007\XK-Commander	SUNR -- Sunroof	√	√	√	√	√	
2007\XK-Commander	AHBM -- Automatic High Beam	√	√	√	√	√	
2007\XK-Commander	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2007\XK-Commander	RSM -- Rain Sensor Module	√	√	√	√		
2007\XK-Commander	SDAR -- Satellite Radio	√	√	√	√		
2007\XK-Commander	AMP -- Amplifier	√	√	√	√		

2007\XK-Commander	HFM -- Hands Free Module	√	√	√	√	√	
2007\XK-Commander	VES -- Vehicle Entertainment System	√	√	√	√	√	
2007\XK-Commander	HSM -- Heated Seat Module	√	√	√	√	√	
2008\CS-Pacifica	ECM -- Engine Control Module	√	√	√	√	√	
2008\CS-Pacifica	ABS -- Anti Lock Brakes	√	√	√	√	√	
2008\CS-Pacifica	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\CS-Pacifica	CGW -- Central Gateway	√	√	√	√	√	
2008\CS-Pacifica	SAS -- Steering Angle Sensor	√	√	√	√		
2008\CS-Pacifica	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2008\CS-Pacifica	PLGM -- Power Liftgate Module	√	√	√	√	√	
2008\DR-RAM	ECM -- Engine Control Module	√	√	√	√	√	0031, 0032, 0031
2008\DR-RAM	TCM -- Transmission Control Module	√	√	√	√	√	
2008\DR-RAM	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\DR-RAM	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\DR-RAM	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\DR-RAM	CGW -- Central Gateway	√	√	√	√	√	
2008\DR-RAM	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\DR-RAM	SAS -- Steering Angle Sensor	√	√	√	√		
2008\DR-RAM	RADIO -- Radio	√	√	√	√		
2008\DR-RAM	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\DR-RAM	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2008\DR-RAM	SUNR -- Sunroof	√	√	√	√	√	
2008\DR-RAM	EOM -- Electronic Overhead	√	√	√	√	√	
2008\DR-RAM	SDAR -- Satellite Radio	√	√	√	√		
2008\DR-RAM	AMP -- Amplifier	√	√	√	√		
2008\DR-RAM	HFM -- Hands Free Module	√	√	√	√	√	
2008\DR-RAM	VES -- Vehicle Entertainment System	√	√	√	√	√	
2008\HB-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\HB-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\HB-Durango	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\HB-Durango	CGW -- Central Gateway	√	√	√	√	√	
2008\HB-Durango	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\HB-Durango	SAS -- Steering Angle Sensor	√	√	√	√		
2008\HB-Durango	PTS -- Parktronics	√	√	√	√	√	
2008\HB-Durango	RADIO -- Radio	√	√	√	√	√	
2008\HB-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\HB-Durango	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2008\HB-Durango	DDM -- Driver Door Module	√	√	√	√	√	
2008\HB-Durango	PDM -- Passenger Door Module	√	√	√	√	√	
2008\HB-Durango	PLGM -- Power Liftgate Module	√	√	√	√	√	
2008\HB-Durango	PTIM -- Police/Taxi Interface Module	√	√	√	√	√	
2008\HB-Durango	EOM -- Electronic Overhead	√	√	√	√	√	
2008\HB-Durango	AMP -- Amplifier	√	√	√	√		
2008\HB-Durango	HFM -- Hands Free Module	√	√	√	√	√	
2008\HB-Durango	VES3 -- Last Row Screen	√	√	√	√	√	



2008\HB-Durango	HSM -- Heated Seat Module	√	√	√	√	√	
2008\HG-Aspen	ECM -- Engine Control Module	√	√	√	√	√	
2008\HG-Aspen	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\HG-Aspen	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\HG-Aspen	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\HG-Aspen	CGW -- Central Gateway	√	√	√	√	√	
2008\HG-Aspen	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\HG-Aspen	SAS -- Steering Angle Sensor	√	√	√	√		
2008\HG-Aspen	PTS -- Parktronics	√	√	√	√	√	
2008\HG-Aspen	RADIO -- Radio	√	√	√	√	√	
2008\HG-Aspen	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\HG-Aspen	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2008\HG-Aspen	DDM -- Driver Door Module	√	√	√	√	√	
2008\HG-Aspen	PDM -- Passenger Door Module	√	√	√	√	√	
2008\HG-Aspen	PLGM -- Power Liftgate Module	√	√	√	√	√	
2008\HG-Aspen	PTIM -- Police/Taxi Interface Module	√	√	√	√	√	
2008\HG-Aspen	EOM -- Electronic Overhead	√	√	√	√	√	
2008\HG-Aspen	AMP -- Amplifier	√	√	√	√		
2008\HG-Aspen	HFM -- Hands Free Module	√	√	√	√	√	
2008\HG-Aspen	VES3 -- Last Row Screen	√	√	√	√	√	
2008\HG-Aspen	HSM -- Heated Seat Module	√	√	√	√	√	
2008\J8-Wrangler	TCM -- Transmission Control Module	√	√	√	√	√	
2008\J8-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\J8-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\J8-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2008\J8-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\J8-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2008\J8-Wrangler	RADIO -- Radio	√	√	√	√	√	
2008\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\JC-Journey	ECM -- Engine Control Module	√	√	√	√	√	
2008\JC-Journey	TCM -- Transmission Control Module	√	√	√	√	√	
2008\JC-Journey	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\JC-Journey	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\JC-Journey	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\JC-Journey	CGW -- Central Gateway	√	√	√	√	√	0003
2008\JC-Journey	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2008\JC-Journey	SAS -- Steering Angle Sensor	√	√	√	√		
2008\JC-Journey	RADIO -- Radio	√	√	√	√	√	
2008\JC-Journey	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\JC-Journey	DMFR -- Door Module Front Right	√	√	√	√	√	
2008\JC-Journey	DMFL -- Door Module Front Left	√	√	√	√	√	
2008\JC-Journey	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2008\JC-Journey	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2008\JC-Journey	AMP -- Amplifier	√	√	√	√		

2008\JC-Journey	HFM -- Hands Free Module	√	√	√	√	√	
2008\JC-Journey	VES3 -- Last Row Screen	√	√	√	√	√	
2008\JC-Journey	DISP -- Front Display	√	√	√	√		
2008\JK-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2008\JK-Wrangler	TCM -- Transmission Control Module	√	√	√	√	√	
2008\JK-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\JK-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\JK-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2008\JK-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\JK-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2008\JK-Wrangler	RADIO -- Radio	√	√	√	√	√	
2008\JK-Wrangler	ASBS -- Automatic Sway Bar System	√	√	√	√		
2008\JK-Wrangler	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2008\JK-Wrangler	AMP -- Amplifier	√	√	√	√		
2008\JS-Avenger,Sebring,Convertible-Sedan	TCM -- Transmission Control Module	√	√	√	√	√	
2008\JS-Avenger,Sebring,Convertible-Sedan	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\JS-Avenger,Sebring,Convertible-Sedan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\JS-Avenger,Sebring,Convertible-Sedan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\JS-Avenger,Sebring,Convertible-Sedan	CGW -- Central Gateway	√	√	√	√	√	
2008\JS-Avenger,Sebring,Convertible-Sedan	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\JS-Avenger,Sebring,Convertible-Sedan	SAS -- Steering Angle Sensor	√	√	√	√		
2008\JS-Avenger,Sebring,Convertible-Sedan	RADIO -- Radio	√	√	√	√	√	
2008\JS-Avenger,Sebring,Convertible-Sedan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\JS-Avenger,Sebring,Convertible-Sedan	DDM -- Driver Door Module	√	√	√	√	√	
2008\JS-Avenger,Sebring,Convertible-Sedan	PDM -- Passenger Door Module	√	√	√	√	√	
2008\JS-Avenger,Sebring,Convertible-Sedan	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2008\JS-Avenger,Sebring,Convertible-Sedan	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2008\JS-Avenger,Sebring,Convertible-Sedan	PTCM -- Power Top Control Module	√	√	√	√		
2008\JS-Avenger,Sebring,Convertible-Sedan	AMP -- Amplifier	√	√	√	√		
2008\JS-Avenger,Sebring,Convertible-Sedan	HFM -- Hands Free Module	√	√	√	√	√	

2008\JS-Avenger,Sebring,Convertible-Sedan	VES3 -- Last Row Screen	√	√	√	√	√	
2008\KA-Nitro	ECM -- Engine Control Module	√	√	√	√	√	
2008\KA-Nitro	TCM -- Transmission Control Module	√	√	√	√		
2008\KA-Nitro	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\KA-Nitro	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\KA-Nitro	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\KA-Nitro	CGW -- Central Gateway	√	√	√	√	√	0003
2008\KA-Nitro	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\KA-Nitro	SAS -- Steering Angle Sensor	√	√	√	√		
2008\KA-Nitro	PTS -- Parktronics	√	√	√	√	√	
2008\KA-Nitro	RADIO -- Radio	√	√	√	√	√	
2008\KA-Nitro	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\KA-Nitro	DMFR -- Door Module Front Right	√	√	√	√	√	
2008\KA-Nitro	DMFL -- Door Module Front Left	√	√	√	√	√	
2008\KA-Nitro	ESM -- Electronic Shifter	√	√	√	√	√	
2008\KA-Nitro	OCM -- Occupant Classification	√	√	√	√		
2008\KA-Nitro	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2008\KA-Nitro	AMP -- Amplifier	√	√	√	√		
2008\KA-Nitro	HFM -- Hands Free Module	√	√	√	√	√	
2008\KA-Nitro	VES3 -- Last Row Screen	√	√	√	√	√	
2008\KK-Liberty	ECM -- Engine Control Module	√	√	√	√	√	
2008\KK-Liberty	TCM -- Transmission Control Module	√	√	√	√		
2008\KK-Liberty	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\KK-Liberty	CGW -- Central Gateway	√	√	√	√	√	0003
2008\KK-Liberty	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\KK-Liberty	SAS -- Steering Angle Sensor	√	√	√	√		
2008\KK-Liberty	PTS -- Parktronics	√	√	√	√	√	
2008\KK-Liberty	RADIO -- Radio	√	√	√	√	√	
2008\KK-Liberty	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2008\KK-Liberty	DMFR -- Door Module Front Right	√	√	√	√	√	
2008\KK-Liberty	DMFL -- Door Module Front Left	√	√	√	√	√	
2008\KK-Liberty	ESM -- Electronic Shifter	√	√	√	√	√	
2008\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2008\KK-Liberty	OCM -- Occupant Classification	√	√	√	√		
2008\KK-Liberty	SUNR -- Sunroof	√	√	√	√		
2008\KK-Liberty	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2008\KK-Liberty	AMP -- Amplifier	√	√	√	√		
2008\KK-Liberty	HFM -- Hands Free Module	√	√	√	√	√	
2008\KK-Liberty	VES3 -- Last Row Screen	√	√	√	√	√	
2008\LC-Challenger	ECM -- Engine Control Module	√	√	√	√	√	
2008\LC-Challenger	TCM -- Transmission Control Module	√	√	√	√		
2008\LC-Challenger	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005

2008\LC-Challenger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\LC-Challenger	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\LC-Challenger	TPM -- Tire Pressure Monitor	√	√	√	√		
2008\LC-Challenger	CGW -- Central Gateway	√	√	√	√	√	
2008\LC-Challenger	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2008\LC-Challenger	RADIO -- Radio	√	√	√	√	√	
2008\LC-Challenger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\LC-Challenger	DDM -- Driver Door Module	√	√	√	√	√	
2008\LC-Challenger	PDM -- Passenger Door Module	√	√	√	√	√	
2008\LC-Challenger	SCM -- Steering Column	√	√	√	√	√	
2008\LC-Challenger	ESM -- Electronic Shifter	√	√	√	√	√	
2008\LC-Challenger	SUNR -- Sunroof	√	√	√	√	√	
2008\LC-Challenger	EOM -- Electronic Overhead	√	√	√	√		
2008\LC-Challenger	AMP -- Amplifier	√	√	√	√		
2008\LC-Challenger	HFM -- Hands Free Module	√	√	√	√	√	
2008\LC-Challenger	HSM -- Heated Seat Module	√	√	√	√	√	
2008\LC-Challenger	PEM -- Passive Entry Module	√	√	√	√		
2008\LX-300,Charger,Magnum,Grand Voyager	ECM -- Engine Control Module	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\LX-300,Charger,Magnum,Grand Voyager	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\LX-300,Charger,Magnum,Grand Voyager	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	CGW -- Central Gateway	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	PTS -- Parktronics	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	RADIO -- Radio	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	ACC -- Adaptive Cruise Control	√	√	√	√		
2008\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2008\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	SCM -- Steering Column	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	

2008\LX-300,Charger,Magnum,Grand Voyager	SUNR -- Sunroof	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	PTIM -- Police/Taxi Interface Module	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	AHBM -- Automatic High Beam	√	√	√	√		
2008\LX-300,Charger,Magnum,Grand Voyager	EOM -- Electronic Overhead	√	√	√	√		
2008\LX-300,Charger,Magnum,Grand Voyager	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	RSM -- Rain Sensor Module	√	√	√	√		
2008\LX-300,Charger,Magnum,Grand Voyager	SDARV -- Satellite Video Receiver	√	√	√	√		
2008\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√		
2008\LX-300,Charger,Magnum,Grand Voyager	HFM -- Hands Free Module	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	VES3 -- Last Row Screen	√	√	√	√	√	
2008\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2008\MK-Compass,Patriot	ECM -- Engine Control Module	√	√	√	√	√	
2008\MK-Compass,Patriot	TCM -- Transmission Control Module	√	√	√	√	√	
2008\MK-Compass,Patriot	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\MK-Compass,Patriot	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\MK-Compass,Patriot	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\MK-Compass,Patriot	CGW -- Central Gateway	√	√	√	√	√	
2008\MK-Compass,Patriot	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\MK-Compass,Patriot	SAS -- Steering Angle Sensor	√	√	√	√		
2008\MK-Compass,Patriot	RADIO -- Radio	√	√	√	√		
2008\MK-Compass,Patriot	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2008\MK-Compass,Patriot	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2008\MK-Compass,Patriot	SDAR -- Satellite Radio	√	√	√	√		
2008\MK-Compass,Patriot	AMP -- Amplifier	√	√	√	√		
2008\ND-Dakota	ECM -- Engine Control Module	√	√	√	√	√	
2008\ND-Dakota	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\ND-Dakota	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\ND-Dakota	CGW -- Central Gateway	√	√	√	√	√	
2008\ND-Dakota	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\ND-Dakota	RADIO -- Radio	√	√	√	√	√	
2008\ND-Dakota	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\ND-Dakota	EOM -- Electronic Overhead	√	√	√	√		
2008\ND-Dakota	AMP -- Amplifier	√	√	√	√		

2008\ND-Dakota	HFM -- Hands Free Module	√	√	√	√	√	
2008\NM-Raider	ECM -- Engine Control Module	√	√	√	√	√	
2008\NM-Raider	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\NM-Raider	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\NM-Raider	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\NM-Raider	CGW -- Central Gateway	√	√	√	√	√	
2008\NM-Raider	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\NM-Raider	RADIO -- Radio	√	√	√	√	√	
2008\NM-Raider	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\NM-Raider	EOM -- Electronic Overhead	√	√	√	√		
2008\NM-Raider	AMP -- Amplifier	√	√	√	√		
2008\NM-Raider	HFM -- Hands Free Module	√	√	√	√	√	
2008\PM-Caliber	ECM -- Engine Control Module	√	√	√	√	√	
2008\PM-Caliber	TCM -- Transmission Control Module	√	√	√	√	√	
2008\PM-Caliber	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\PM-Caliber	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\PM-Caliber	CGW -- Central Gateway	√	√	√	√	√	
2008\PM-Caliber	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\PM-Caliber	SAS -- Steering Angle Sensor	√	√	√	√		
2008\PM-Caliber	RADIO -- Radio	√	√	√	√	√	
2008\PM-Caliber	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2008\PM-Caliber	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2008\PM-Caliber	SDAR -- Satellite Radio	√	√	√	√		
2008\PM-Caliber	AMP -- Amplifier	√	√	√	√		
2008\PM-Caliber	HFM -- Hands Free Module	√	√	√	√	√	
2008\PM-Caliber	EBG -- Electronic Booster Gauge	√	√	√	√		
2008\PT-PT Cruiser	ECM -- Engine Control Module	√	√	√	√	√	0050, 0017, 0031, 0031
2008\PT-PT Cruiser	TCM -- Transmission Control Module	√	√	√	√	√	
2008\PT-PT Cruiser	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\PT-PT Cruiser	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\PT-PT Cruiser	CGW -- Central Gateway	√	√	√	√	√	0003
2008\PT-PT Cruiser	WCM/TPMS -- Wireless Control	√	√	√	√		
2008\PT-PT Cruiser	RADIO -- Radio	√	√	√	√		
2008\PT-PT Cruiser	DDM -- Driver Door Module	√	√	√	√	√	
2008\PT-PT Cruiser	PDM -- Passenger Door Module	√	√	√	√	√	
2008\PT-PT Cruiser	OCM -- Occupant Classification	√	√	√	√		
2008\PT-PT Cruiser	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2008\PT-PT Cruiser	SDAR -- Satellite Radio	√	√	√	√		
2008\PT-PT Cruiser	AMP -- Amplifier	√	√	√	√		
2008\PT-PT Cruiser	HFM -- Hands Free Module	√	√	√	√	√	
2008\R2-Mini-Van	ECM -- Engine Control Module		√		√	√	
2008\RT-Caravan,Town & Country	ECM -- Engine Control Module	√	√	√	√	√	
2008\RT-Caravan,Town & Country	TCM -- Transmission Control Module	√	√	√	√	√	
2008\RT-Caravan,Town & Country	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005

2008\RT-Caravan,Town & Country	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\RT-Caravan,Town & Country	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\RT-Caravan,Town & Country	CGW -- Central Gateway	√	√	√	√	√	0003
2008\RT-Caravan,Town & Country	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2008\RT-Caravan,Town & Country	SAS -- Steering Angle Sensor	√	√	√	√		
2008\RT-Caravan,Town & Country	PTS -- Parktronics	√	√	√	√	√	
2008\RT-Caravan,Town & Country	RADIO -- Radio	√	√	√	√	√	
2008\RT-Caravan,Town & Country	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\RT-Caravan,Town & Country	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2008\RT-Caravan,Town & Country	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2008\RT-Caravan,Town & Country	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2008\RT-Caravan,Town & Country	DMFR -- Door Module Front Right	√	√	√	√	√	
2008\RT-Caravan,Town & Country	DMFL -- Door Module Front Left	√	√	√	√	√	
2008\RT-Caravan,Town & Country	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2008\RT-Caravan,Town & Country	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2008\RT-Caravan,Town & Country	PLGM -- Power Liftgate Module	√	√	√	√	√	
2008\RT-Caravan,Town & Country	FSM -- Fold Stow Module	√	√	√	√	√	
2008\RT-Caravan,Town & Country	SUNR -- Sunroof	√	√	√	√	√	
2008\RT-Caravan,Town & Country	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2008\RT-Caravan,Town & Country	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2008\RT-Caravan,Town & Country	DVD -- DVD Changer	√	√	√	√		
2008\RT-Caravan,Town & Country	SDARV -- Satellite Video Receiver	√	√	√	√		
2008\RT-Caravan,Town & Country	AMP -- Amplifier	√	√	√	√		
2008\RT-Caravan,Town & Country	VES2 -- Second Row Screen	√	√	√	√	√	
2008\RT-Caravan,Town & Country	VES3 -- Last Row Screen	√	√	√	√	√	
2008\VB-Sprinter	ECM -- Engine Control Module	√	√	√	√	√	0052, 0031
2008\VB-Sprinter	TCM -- Transmission Control Module	√	√	√	√		
2008\VB-Sprinter	ABS -- Anti Lock Brakes	√	√	√	√		0005
2008\VB-Sprinter	ORC -- AirBag/Occupant Restraint	√	√	√			
2008\VB-Sprinter	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√		0038
2008\VB-Sprinter	TPM -- Tire Pressure Monitor	√	√	√	√		0034, 0035, 0046, 0047, 0054, 0055, 0057
2008\VB-Sprinter	BCM -- Body Controller	√	√	√	√	√	
2008\VB-Sprinter	CGW -- Central Gateway	√	√	√	√		
2008\VB-Sprinter	PTS -- Parktronics	√	√	√	√	√	
2008\VB-Sprinter	RADIO -- Radio	√	√	√	√		
2008\VB-Sprinter	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\VB-Sprinter	PSDMR -- Power Sliding Doors (Right)	√	√	√	√	√	
2008\VB-Sprinter	PSDML -- Power Sliding Doors (Left)	√	√	√	√	√	
2008\VB-Sprinter	DDM -- Driver Door Module	√	√	√	√	√	
2008\VB-Sprinter	SCM -- Steering Column	√	√	√	√	√	
2008\VB-Sprinter	SBM -- Center Console / Switch Bank Module	√	√	√	√	√	
2008\VB-Sprinter	ESM -- Electronic Shifter	√	√	√	√	√	

2008\VB-Sprinter	BCH -- Booster Cabin Heater Module (ZHZ)	√	√	√	√	√	
2008\VB-Sprinter	ACH -- Auxiliary Cabin Heater (STH)	√	√	√	√	√	
2008\VB-Sprinter	TM -- Trailer	√	√	√	√		
2008\VB-Sprinter	AHLM -- Headlamp Leveling	√	√	√	√	√	
2008\VB-Sprinter	RCM -- Roof Control Module	√	√	√	√	√	
2008\VB-Sprinter	AEHM -- Auxiliary Electrical Heating Module	√	√	√	√		
2008\VB-Sprinter	CDC -- CD Changer	√	√	√	√		
2008\VB-Sprinter	HFM -- Hands Free Module	√	√	√	√		
2008\VB-Sprinter	PSM -- Universal/Special ECU	√	√	√	√	√	
2008\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	
2008\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2008\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\WK-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\WK-Grand Cherokee	CGW -- Central Gateway	√	√	√	√	√	
2008\WK-Grand Cherokee	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2008\WK-Grand Cherokee	SAS -- Steering Angle Sensor	√	√	√	√		
2008\WK-Grand Cherokee	PTS -- Parktronics	√	√	√	√	√	
2008\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√	√	
2008\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2008\WK-Grand Cherokee	DDM -- Driver Door Module	√	√	√	√	√	
2008\WK-Grand Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2008\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2008\WK-Grand Cherokee	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2008\WK-Grand Cherokee	TM -- Trailer		√	√			
2008\WK-Grand Cherokee	SUNR -- Sunroof	√	√	√	√	√	
2008\WK-Grand Cherokee	AHLM -- Headlamp Leveling	√	√	√	√	√	
2008\WK-Grand Cherokee	AHBM -- Automatic High Beam	√	√	√	√		
2008\WK-Grand Cherokee	EOM -- Electronic Overhead	√	√	√	√		
2008\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2008\WK-Grand Cherokee	RSM -- Rain Sensor Module	√	√	√	√		
2008\WK-Grand Cherokee	SDARV -- Satellite Video Receiver	√	√	√	√		
2008\WK-Grand Cherokee	AMP -- Amplifier	√	√	√	√		
2008\WK-Grand Cherokee	HFM -- Hands Free Module	√	√	√	√	√	
2008\WK-Grand Cherokee	VES3 -- Last Row Screen	√	√	√	√	√	
2008\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2008\XK-Commander	ECM -- Engine Control Module	√	√	√	√	√	
2008\XK-Commander	TCM -- Transmission Control Module	√	√	√	√		
2008\XK-Commander	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2008\XK-Commander	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\XK-Commander	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2008\XK-Commander	CGW -- Central Gateway	√	√	√	√	√	
2008\XK-Commander	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2008\XK-Commander	SAS -- Steering Angle Sensor	√	√	√	√		
2008\XK-Commander	PTS -- Parktronics	√	√	√	√	√	



2008\XK-Commander	RADIO -- Radio	√	√	√	√	√	
2008\XK-Commander	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\XK-Commander	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2008\XK-Commander	DDM -- Driver Door Module	√	√	√	√	√	
2008\XK-Commander	PDM -- Passenger Door Module	√	√	√	√	√	
2008\XK-Commander	ESM -- Electronic Shifter	√	√	√	√	√	
2008\XK-Commander	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2008\XK-Commander	PLGM -- Power Liftgate Module	√	√	√	√	√	
2008\XK-Commander	TM -- Trailer		√	√			
2008\XK-Commander	SUNR -- Sunroof	√	√	√	√	√	
2008\XK-Commander	AHBM -- Automatic High Beam	√	√	√	√		
2008\XK-Commander	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2008\XK-Commander	RSM -- Rain Sensor Module	√	√	√	√		
2008\XK-Commander	AMP -- Amplifier	√	√	√	√		
2008\XK-Commander	HFM -- Hands Free Module	√	√	√	√	√	
2008\XK-Commander	VES3 -- Last Row Screen	√	√	√	√	√	
2008\XK-Commander	HSM -- Heated Seat Module	√	√	√	√	√	
2008\ZB-Viper	ECM -- Engine Control Module	√	√	√	√	√	0017, 0031
2008\ZB-Viper	OCM -- Occupant Classification	√	√	√	√		
2008\ZH-Crossfire(NAFTA)	ECM -- Engine Control Module	√	√	√	√	√	
2008\ZH-Crossfire(NAFTA)	TCM -- Transmission Control Module	√	√	√	√		
2008\ZH-Crossfire(NAFTA)	ESP -- Electronic Stability Program	√	√	√	√	√	
2008\ZH-Crossfire(NAFTA)	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2008\ZH-Crossfire(NAFTA)	IC -- Instrument Cluster	√	√	√	√	√	
2008\ZH-Crossfire(NAFTA)	TPM -- Tire Pressure Monitor	√	√	√	√		
2008\ZH-Crossfire(NAFTA)	BCM -- Body Controller	√	√	√	√	√	
2008\ZH-Crossfire(NAFTA)	SKM -- SKIM/SKREEM/TPM	√	√	√	√	√	
2008\ZH-Crossfire(NAFTA)	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2008\ZH-Crossfire(NAFTA)	SLA -- Shift Lever Sensor Assembly	√	√	√	√	√	
2008\ZH-Crossfire(NAFTA)	OCM -- Occupant Classification	√	√	√	√		
2008\ZH-Crossfire(NAFTA)	PTCM -- Power Top Control Module	√	√	√	√	√	
2008\ZH-Crossfire(NAFTA)	CLP	√	√	√		√	
2009\DR-RAM	ECM -- Engine Control Module	√	√	√	√	√	0031, 0032, 0031
2009\DR-RAM	TCM -- Transmission Control Module	√	√	√	√	√	
2009\DR-RAM	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\DR-RAM	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\DR-RAM	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\DR-RAM	CGW -- Central Gateway	√	√	√	√	√	
2009\DR-RAM	WCM/TPMS -- Wireless Control	√	√	√	√		
2009\DR-RAM	SAS -- Steering Angle Sensor	√	√	√	√		
2009\DR-RAM	RADIO -- Radio	√	√	√	√		
2009\DR-RAM	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\DR-RAM	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2009\DR-RAM	SUNR -- Sunroof	√	√	√	√	√	
2009\DR-RAM	EOM -- Electronic Overhead	√	√	√	√	√	

2009\DR-RAM	SDAR -- Satellite Radio	√	√	√	√		
2009\DR-RAM	AMP -- Amplifier	√	√	√	√		
2009\DR-RAM	HFM -- Hands Free Module	√	√	√	√	√	
2009\DR-RAM	VES -- Vehicle Entertainment System	√	√	√	√	√	
2009\DS-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2009\DS-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2009\DS-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\DS-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\DS-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	
2009\DS-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2009\DS-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2009\DS-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2009\DS-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2009\DS-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√		
2009\DS-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2009\DS-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2009\DS-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2009\DS-Ram Truck	SDARV -- Satellite Video Receiver	√	√	√	√		
2009\DS-Ram Truck	AMP -- Amplifier	√	√	√	√		
2009\DS-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2009\DS-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2009\DS-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2009\HB-Durango	ECM -- Engine Control Module	√	√	√	√	√	
2009\HB-Durango	TCM -- Transmission Control Module	√	√	√	√		
2009\HB-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	0005, 0002
2009\HB-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\HB-Durango	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\HB-Durango	CGW -- Central Gateway	√	√	√	√	√	
2009\HB-Durango	HGM -- Hybrid Gateway Module	√	√	√	√	√	
2009\HB-Durango	WCM/TPMS -- Wireless Control	√	√	√	√		
2009\HB-Durango	SAS -- Steering Angle Sensor	√	√	√	√		
2009\HB-Durango	EPS -- Electric Power Steering	√	√	√	√		
2009\HB-Durango	PTS -- Parktronics	√	√	√	√	√	
2009\HB-Durango	RADIO -- Radio	√	√	√	√	√	
2009\HB-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\HB-Durango	APM -- Adjustable Pedal Module	√					
2009\HB-Durango	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2009\HB-Durango	DDM -- Driver Door Module	√	√	√	√	√	
2009\HB-Durango	PDM -- Passenger Door Module	√	√	√	√	√	
2009\HB-Durango	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2009\HB-Durango	PLGM -- Power Liftgate Module	√	√	√	√	√	
2009\HB-Durango	EOM -- Electronic Overhead	√	√	√	√	√	
2009\HB-Durango	SDARV -- Satellite Video Receiver	√	√	√	√		
2009\HB-Durango	AMP -- Amplifier	√	√	√	√		
2009\HB-Durango	HFM -- Hands Free Module	√	√	√	√	√	

2009\HB-Durango	VES3 -- Last Row Screen	√	√	√	√	√	
2009\HB-Durango	BPCM -- Battery Pack Control Module	√			√		0004, 0026, 0040, 0045, 0058
2009\HB-Durango	EAC -- Electric A/C Compressor	√	√	√	√		
2009\HB-Durango	HCP -- Hybrid Control Processor	√	√	√	√		0042, 0021, 0056
2009\HB-Durango	MCPA -- Motor Control Processor A	√			√		
2009\HB-Durango	MCPB -- Motor Control Processor B	√			√		
2009\HG-Aspen	ECM -- Engine Control Module	√	√	√	√	√	
2009\HG-Aspen	TCM -- Transmission Control Module	√	√	√	√		
2009\HG-Aspen	ABS -- Anti Lock Brakes	√	√	√	√	√	0005, 0002
2009\HG-Aspen	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\HG-Aspen	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\HG-Aspen	CGW -- Central Gateway	√	√	√	√	√	
2009\HG-Aspen	HGM -- Hybrid Gateway Module	√	√	√	√	√	
2009\HG-Aspen	WCM/TPMS -- Wireless Control	√	√	√	√		
2009\HG-Aspen	SAS -- Steering Angle Sensor	√	√	√	√		
2009\HG-Aspen	EPS -- Electric Power Steering	√	√	√	√		
2009\HG-Aspen	PTS -- Parktronics	√	√	√	√	√	
2009\HG-Aspen	RADIO -- Radio	√	√	√	√	√	
2009\HG-Aspen	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\HG-Aspen	APM -- Adjustable Pedal Module	√					
2009\HG-Aspen	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2009\HG-Aspen	DDM -- Driver Door Module	√	√	√	√	√	
2009\HG-Aspen	PDM -- Passenger Door Module	√	√	√	√	√	
2009\HG-Aspen	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2009\HG-Aspen	PLGM -- Power Liftgate Module	√	√	√	√	√	
2009\HG-Aspen	EOM -- Electronic Overhead	√	√	√	√	√	
2009\HG-Aspen	SDARV -- Satellite Video Receiver	√	√	√	√		
2009\HG-Aspen	AMP -- Amplifier	√	√	√	√		
2009\HG-Aspen	HFM -- Hands Free Module	√	√	√	√	√	
2009\HG-Aspen	VES3 -- Last Row Screen	√	√	√	√	√	
2009\HG-Aspen	HSM -- Heated Seat Module	√	√	√	√	√	
2009\HG-Aspen	BPCM -- Battery Pack Control Module	√			√		0004, 0026, 0040, 0045, 0058
2009\HG-Aspen	EAC -- Electric A/C Compressor	√	√	√	√		
2009\HG-Aspen	HCP -- Hybrid Control Processor	√	√	√	√		0042, 0021, 0056
2009\HG-Aspen	MCPA -- Motor Control Processor A	√			√		
2009\HG-Aspen	MCPB -- Motor Control Processor B	√			√		
2009\J8-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2009\J8-Wrangler	TCM -- Transmission Control Module	√	√	√	√	√	
2009\J8-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\J8-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003

2009\J8-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2009\J8-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2009\J8-Wrangler	RADIO -- Radio	√	√	√	√	√	
2009\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\JC-Journey	ECM -- Engine Control Module	√	√	√	√	√	
2009\JC-Journey	TCM -- Transmission Control Module	√	√	√	√	√	
2009\JC-Journey	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\JC-Journey	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\JC-Journey	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\JC-Journey	CGW -- Central Gateway	√	√	√	√	√	0003
2009\JC-Journey	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2009\JC-Journey	SAS -- Steering Angle Sensor	√	√	√	√		
2009\JC-Journey	RADIO -- Radio	√	√	√	√	√	
2009\JC-Journey	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\JC-Journey	DMFR -- Door Module Front Right	√	√	√	√	√	
2009\JC-Journey	DMFL -- Door Module Front Left	√	√	√	√	√	
2009\JC-Journey	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2009\JC-Journey	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2009\JC-Journey	SDARV -- Satellite Video Receiver	√	√	√	√		
2009\JC-Journey	AMP -- Amplifier	√	√	√	√		
2009\JC-Journey	HFM -- Hands Free Module	√	√	√	√	√	
2009\JC-Journey	VES3 -- Last Row Screen	√	√	√	√	√	
2009\JC-Journey	DISP -- Front Display	√	√	√	√		
2009\JK-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2009\JK-Wrangler	TCM -- Transmission Control Module	√	√	√	√	√	
2009\JK-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\JK-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\JK-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2009\JK-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2009\JK-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2009\JK-Wrangler	RADIO -- Radio	√	√	√	√	√	
2009\JK-Wrangler	ASBS -- Automatic Sway Bar System	√	√	√	√		
2009\JK-Wrangler	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2009\JK-Wrangler	AMP -- Amplifier	√	√	√	√		
2009\JK-Wrangler	HFM -- Hands Free Module	√	√	√	√	√	
2009\JS-Avenger,Sebring,Convertible-Sedan	ECM -- Engine Control Module	√	√	√	√	√	
2009\JS-Avenger,Sebring,Convertible-Sedan	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\JS-Avenger,Sebring,Convertible-Sedan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\JS-Avenger,Sebring,Convertible-Sedan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\JS-Avenger,Sebring,Convertible-Sedan	CGW -- Central Gateway	√	√	√	√	√	

2009\JS-Avenger,Sebring,Convertible-Sedan	WCM/TPMS -- Wireless Control	√	√	√	√		
2009\JS-Avenger,Sebring,Convertible-Sedan	SAS -- Steering Angle Sensor	√	√	√	√		
2009\JS-Avenger,Sebring,Convertible-Sedan	RADIO -- Radio	√	√	√	√	√	
2009\JS-Avenger,Sebring,Convertible-Sedan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\JS-Avenger,Sebring,Convertible-Sedan	DDM -- Driver Door Module	√	√	√	√	√	
2009\JS-Avenger,Sebring,Convertible-Sedan	PDM -- Passenger Door Module	√	√	√	√	√	
2009\JS-Avenger,Sebring,Convertible-Sedan	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2009\JS-Avenger,Sebring,Convertible-Sedan	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2009\JS-Avenger,Sebring,Convertible-Sedan	PTCM -- Power Top Control Module	√	√	√	√		
2009\JS-Avenger,Sebring,Convertible-Sedan	AMP -- Amplifier	√	√	√	√		
2009\JS-Avenger,Sebring,Convertible-Sedan	HFM -- Hands Free Module	√	√	√	√	√	
2009\JS-Avenger,Sebring,Convertible-Sedan	VES3 -- Last Row Screen	√	√	√	√	√	
2009\KA-Nitro	ECM -- Engine Control Module	√	√	√	√	√	
2009\KA-Nitro	TCM -- Transmission Control Module	√	√	√	√		
2009\KA-Nitro	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\KA-Nitro	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\KA-Nitro	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\KA-Nitro	CGW -- Central Gateway	√	√	√	√	√	0003
2009\KA-Nitro	WCM/TPMS -- Wireless Control	√	√	√	√		
2009\KA-Nitro	SAS -- Steering Angle Sensor	√	√	√	√		
2009\KA-Nitro	PTS -- Parktronic	√	√	√	√	√	
2009\KA-Nitro	RADIO -- Radio	√	√	√	√	√	
2009\KA-Nitro	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\KA-Nitro	DMFR -- Door Module Front Right	√	√	√	√	√	
2009\KA-Nitro	DMFL -- Door Module Front Left	√	√	√	√	√	
2009\KA-Nitro	ESM -- Electronic Shifter	√	√	√	√	√	
2009\KA-Nitro	OCM -- Occupant Classification	√	√	√	√		
2009\KA-Nitro	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2009\KA-Nitro	AMP -- Amplifier	√	√	√	√		
2009\KA-Nitro	HFM -- Hands Free Module	√	√	√	√	√	
2009\KA-Nitro	VES3 -- Last Row Screen	√	√	√	√	√	
2009\KK-Liberty	ECM -- Engine Control Module	√	√	√	√	√	
2009\KK-Liberty	TCM -- Transmission Control Module	√	√	√	√		
2009\KK-Liberty	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\KK-Liberty	ORC -- AirBag/Occupant Restraint	√	√	√	√		

2009\KK-Liberty	CGW -- Central Gateway	√	√	√	√	√	0003
2009\KK-Liberty	WCM/TPMS -- Wireless Control	√	√	√	√		
2009\KK-Liberty	SAS -- Steering Angle Sensor	√	√	√	√		
2009\KK-Liberty	PTS -- Parktronics	√	√	√	√	√	
2009\KK-Liberty	RADIO -- Radio	√	√	√	√	√	
2009\KK-Liberty	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2009\KK-Liberty	DMFR -- Door Module Front Right	√	√	√	√	√	
2009\KK-Liberty	DMFL -- Door Module Front Left	√	√	√	√	√	
2009\KK-Liberty	ESM -- Electronic Shifter	√	√	√	√	√	
2009\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2009\KK-Liberty	OCM -- Occupant Classification	√	√	√	√		
2009\KK-Liberty	SUNR -- Sunroof	√	√	√	√		
2009\KK-Liberty	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2009\KK-Liberty	AMP -- Amplifier	√	√	√	√		
2009\KK-Liberty	HFM -- Hands Free Module	√	√	√	√	√	
2009\KK-Liberty	VES3 -- Last Row Screen	√	√	√	√	√	
2009\LC-Challenger	ECM -- Engine Control Module	√	√	√	√	√	
2009\LC-Challenger	TCM -- Transmission Control Module	√	√	√	√		
2009\LC-Challenger	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\LC-Challenger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\LC-Challenger	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\LC-Challenger	TPM -- Tire Pressure Monitor	√	√	√	√		
2009\LC-Challenger	CGW -- Central Gateway	√	√	√	√	√	
2009\LC-Challenger	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2009\LC-Challenger	RADIO -- Radio	√	√	√	√	√	
2009\LC-Challenger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\LC-Challenger	DDM -- Driver Door Module	√	√	√	√	√	
2009\LC-Challenger	PDM -- Passenger Door Module	√	√	√	√	√	
2009\LC-Challenger	SCM -- Steering Column	√	√	√	√	√	
2009\LC-Challenger	ESM -- Electronic Shifter	√	√	√	√	√	
2009\LC-Challenger	SUNR -- Sunroof	√	√	√	√	√	
2009\LC-Challenger	EOM -- Electronic Overhead	√	√	√	√		
2009\LC-Challenger	AMP -- Amplifier	√	√	√	√		
2009\LC-Challenger	HFM -- Hands Free Module	√	√	√	√	√	
2009\LC-Challenger	HSM -- Heated Seat Module	√	√	√	√	√	
2009\LC-Challenger	PEM -- Passive Entry Module	√	√	√	√		
2009\LX-300,Charger,Magnum,Grand Voyager	ECM -- Engine Control Module	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	TCM -- Transmission Control Module	√	√	√	√		
2009\LX-300,Charger,Magnum,Grand Voyager	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\LX-300,Charger,Magnum,Grand Voyager	ORC -- AirBag/Occupant Restraint	√	√	√	√		

2009\LX-300,Charger,Magnum,Grand Voyager	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	TPM -- Tire Pressure Monitor	√	√	√	√		
2009\LX-300,Charger,Magnum,Grand Voyager	CGW -- Central Gateway	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	PTS -- Parktronics	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	RADIO -- Radio	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	ACC -- Adaptive Cruise Control	√	√	√	√		
2009\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2009\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	SCM -- Steering Column	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	SUNR -- Sunroof	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	PTIM -- Police/Taxi Interface Module	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	AHBM -- Automatic High Beam	√	√	√	√		
2009\LX-300,Charger,Magnum,Grand Voyager	EOM -- Electronic Overhead	√	√	√	√		
2009\LX-300,Charger,Magnum,Grand Voyager	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	RSM -- Rain Sensor Module	√	√	√	√		
2009\LX-300,Charger,Magnum,Grand Voyager	SDARV -- Satellite Video Receiver	√	√	√	√		
2009\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√		
2009\LX-300,Charger,Magnum,Grand Voyager	HFM -- Hands Free Module	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	VES3 -- Last Row Screen	√	√	√	√	√	

2009\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2009\LX-300,Charger,Magnum,Grand Voyager	PEM -- Passive Entry Module	√	√	√	√		
2009\MK-Compass,Patriot	ECM -- Engine Control Module	√	√	√	√	√	
2009\MK-Compass,Patriot	TCM -- Transmission Control Module	√	√	√	√	√	
2009\MK-Compass,Patriot	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\MK-Compass,Patriot	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\MK-Compass,Patriot	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\MK-Compass,Patriot	CGW -- Central Gateway	√	√	√	√	√	
2009\MK-Compass,Patriot	WCM/TPMS -- Wireless Control	√	√	√	√		
2009\MK-Compass,Patriot	SAS -- Steering Angle Sensor	√	√	√	√		
2009\MK-Compass,Patriot	RADIO -- Radio	√	√	√	√	√	
2009\MK-Compass,Patriot	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2009\MK-Compass,Patriot	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2009\MK-Compass,Patriot	HFM -- Hands Free Module	√	√	√	√	√	
2009\ND-Dakota	ECM -- Engine Control Module	√	√	√	√	√	
2009\ND-Dakota	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\ND-Dakota	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\ND-Dakota	CGW -- Central Gateway	√	√	√	√	√	
2009\ND-Dakota	WCM/TPMS -- Wireless Control	√	√	√	√		
2009\ND-Dakota	RADIO -- Radio	√	√	√	√	√	
2009\ND-Dakota	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\ND-Dakota	EOM -- Electronic Overhead	√	√	√	√		
2009\ND-Dakota	AMP -- Amplifier	√	√	√	√		
2009\ND-Dakota	HFM -- Hands Free Module	√	√	√	√	√	
2009\NM-Raider	ECM -- Engine Control Module	√	√	√	√	√	
2009\NM-Raider	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\NM-Raider	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\NM-Raider	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\NM-Raider	CGW -- Central Gateway	√	√	√	√	√	
2009\NM-Raider	WCM/TPMS -- Wireless Control	√	√	√	√		
2009\NM-Raider	RADIO -- Radio	√	√	√	√	√	
2009\NM-Raider	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\NM-Raider	EOM -- Electronic Overhead	√	√	√	√		
2009\NM-Raider	AMP -- Amplifier	√	√	√	√		
2009\NM-Raider	HFM -- Hands Free Module	√	√	√	√	√	
2009\PM-Caliber	ECM -- Engine Control Module	√	√	√	√	√	
2009\PM-Caliber	TCM -- Transmission Control Module	√	√	√	√	√	
2009\PM-Caliber	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\PM-Caliber	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\PM-Caliber	CGW -- Central Gateway	√	√	√	√	√	
2009\PM-Caliber	WCM/TPMS -- Wireless Control	√	√	√	√		



2009\PM-Caliber	SAS -- Steering Angle Sensor	√	√	√	√		
2009\PM-Caliber	RADIO -- Radio	√	√	√	√	√	
2009\PM-Caliber	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2009\PM-Caliber	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2009\PM-Caliber	AMP -- Amplifier	√	√	√	√		
2009\PM-Caliber	HFM -- Hands Free Module	√	√	√	√	√	
2009\PM-Caliber	EBG -- Electronic Booster Gauge	√	√	√	√		
2009\PT-PT Cruiser	ECM -- Engine Control Module	√	√	√	√	√	0050, 0017, 0031, 0031
2009\PT-PT Cruiser	TCM -- Transmission Control Module	√	√	√	√	√	
2009\PT-PT Cruiser	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\PT-PT Cruiser	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\PT-PT Cruiser	CGW -- Central Gateway	√	√	√	√	√	0003
2009\PT-PT Cruiser	WCM/TPMS -- Wireless Control	√	√	√	√		
2009\PT-PT Cruiser	RADIO -- Radio	√	√	√	√		
2009\PT-PT Cruiser	DDM -- Driver Door Module	√	√	√	√	√	
2009\PT-PT Cruiser	PDM -- Passenger Door Module	√	√	√	√	√	
2009\PT-PT Cruiser	OCM -- Occupant Classification	√	√	√	√		
2009\PT-PT Cruiser	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2009\PT-PT Cruiser	SDAR -- Satellite Radio	√	√	√	√		
2009\PT-PT Cruiser	AMP -- Amplifier	√	√	√	√		
2009\PT-PT Cruiser	HFM -- Hands Free Module	√	√	√	√	√	
2009\R2-Mini-Van	ECM -- Engine Control Module		√		√	√	
2009\RM-Routan	ECM -- Engine Control Module	√	√	√	√	√	
2009\RM-Routan	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\RM-Routan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\RM-Routan	CGW -- Central Gateway	√	√	√	√	√	0003
2009\RM-Routan	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2009\RM-Routan	SAS -- Steering Angle Sensor	√	√	√	√		
2009\RM-Routan	PTS -- Parktronics	√	√	√	√	√	
2009\RM-Routan	RADIO -- Radio	√	√	√	√	√	
2009\RM-Routan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2009\RM-Routan	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2009\RM-Routan	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2009\RM-Routan	DMFR -- Door Module Front Right	√	√	√	√	√	
2009\RM-Routan	DMFL -- Door Module Front Left	√	√	√	√	√	
2009\RM-Routan	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2009\RM-Routan	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2009\RM-Routan	PLGM -- Power Liftgate Module	√	√	√	√	√	
2009\RM-Routan	FSM -- Fold Stow Module	√	√	√	√	√	
2009\RM-Routan	SUNR -- Sunroof	√	√	√	√	√	
2009\RM-Routan	DVD -- DVD Changer	√	√	√	√		
2009\RM-Routan	AMP -- Amplifier	√	√	√	√		
2009\RM-Routan	HFM -- Hands Free Module	√	√	√	√	√	

2009\RM-Routan	VES2 -- Second Row Screen	√	√	√	√	√	
2009\RM-Routan	VES3 -- Last Row Screen	√	√	√	√	√	
2009\RT-Caravan,Town & Country	ECM -- Engine Control Module	√	√	√	√	√	
2009\RT-Caravan,Town & Country	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\RT-Caravan,Town & Country	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\RT-Caravan,Town & Country	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\RT-Caravan,Town & Country	CGW -- Central Gateway	√	√	√	√	√	0003
2009\RT-Caravan,Town & Country	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2009\RT-Caravan,Town & Country	SAS -- Steering Angle Sensor	√	√	√	√		
2009\RT-Caravan,Town & Country	PTS -- Parktronic	√	√	√	√	√	
2009\RT-Caravan,Town & Country	RADIO -- Radio	√	√	√	√	√	
2009\RT-Caravan,Town & Country	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\RT-Caravan,Town & Country	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2009\RT-Caravan,Town & Country	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2009\RT-Caravan,Town & Country	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2009\RT-Caravan,Town & Country	DMFR -- Door Module Front Right	√	√	√	√	√	
2009\RT-Caravan,Town & Country	DMFL -- Door Module Front Left	√	√	√	√	√	
2009\RT-Caravan,Town & Country	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2009\RT-Caravan,Town & Country	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2009\RT-Caravan,Town & Country	PLGM -- Power Liftgate Module	√	√	√	√	√	
2009\RT-Caravan,Town & Country	FSM -- Fold Stow Module	√	√	√	√	√	
2009\RT-Caravan,Town & Country	SUNR -- Sunroof	√	√	√	√	√	
2009\RT-Caravan,Town & Country	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2009\RT-Caravan,Town & Country	AHBM -- Automatic High Beam	√	√	√	√		
2009\RT-Caravan,Town & Country	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2009\RT-Caravan,Town & Country	DVD -- DVD Changer	√	√	√	√		
2009\RT-Caravan,Town & Country	SDARV -- Satellite Video Receiver	√	√	√	√		
2009\RT-Caravan,Town & Country	AMP -- Amplifier	√	√	√	√		
2009\RT-Caravan,Town & Country	HFM -- Hands Free Module	√	√	√	√	√	
2009\RT-Caravan,Town & Country	VES2 -- Second Row Screen	√	√	√	√	√	
2009\RT-Caravan,Town & Country	VES3 -- Last Row Screen	√	√	√	√	√	
2009\RT-Caravan,Town & Country	BSM -- Blind Spot Module	√	√	√	√		
2009\VB-Sprinter	ECM -- Engine Control Module	√	√	√	√	√	0052, 0031
2009\VB-Sprinter	TCM -- Transmission Control Module	√	√	√	√		
2009\VB-Sprinter	ABS -- Anti Lock Brakes	√	√	√	√		0005
2009\VB-Sprinter	ORC -- AirBag/Occupant Restraint	√	√	√			
2009\VB-Sprinter	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√		0038
2009\VB-Sprinter	TPM -- Tire Pressure Monitor	√	√	√	√		0034, 0035, 0046, 0047, 0054, 0055, 0057
2009\VB-Sprinter	BCM -- Body Controller	√	√	√	√	√	
2009\VB-Sprinter	CGW -- Central Gateway	√	√	√	√		
2009\VB-Sprinter	PTS -- Parktronic	√	√	√	√	√	
2009\VB-Sprinter	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\VB-Sprinter	PSDMR -- Power Sliding Doors (Right)	√	√	√	√	√	

2009\VB-Sprinter	PSDML -- Power Sliding Doors (Left)	√	√	√	√	√	
2009\VB-Sprinter	DDM -- Driver Door Module	√	√	√	√	√	
2009\VB-Sprinter	SCM -- Steering Column	√	√	√	√	√	
2009\VB-Sprinter	SBM -- Center Console / Switch Bank Module	√	√	√	√	√	
2009\VB-Sprinter	ESM -- Electronic Shifter	√	√	√	√	√	
2009\VB-Sprinter	BCH -- Booster Cabin Heater Module (ZHZ)	√	√	√	√	√	
2009\VB-Sprinter	ACH -- Auxiliary Cabin Heater (STH)	√	√	√	√	√	
2009\VB-Sprinter	TM -- Trailer	√	√	√	√		
2009\VB-Sprinter	AHLM -- Headlamp Leveling	√	√	√	√	√	
2009\VB-Sprinter	RCM -- Roof Control Module	√	√	√	√	√	
2009\VB-Sprinter	AEHM -- Auxiliary Electrical Heating Module	√	√	√	√		
2009\VB-Sprinter	CDC -- CD Changer	√	√	√	√		
2009\VB-Sprinter	HFM -- Hands Free Module	√	√	√	√		
2009\VB-Sprinter	PSM -- Universal/Special ECU	√	√	√	√	√	
2009\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	
2009\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2009\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2009\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\WK-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\WK-Grand Cherokee	CGW -- Central Gateway	√	√	√	√	√	
2009\WK-Grand Cherokee	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2009\WK-Grand Cherokee	SAS -- Steering Angle Sensor	√	√	√	√		
2009\WK-Grand Cherokee	PTS -- Parktronic	√	√	√	√	√	
2009\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√	√	
2009\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2009\WK-Grand Cherokee	DDM -- Driver Door Module	√	√	√	√	√	
2009\WK-Grand Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2009\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2009\WK-Grand Cherokee	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2009\WK-Grand Cherokee	TM -- Trailer		√	√			
2009\WK-Grand Cherokee	SUNR -- Sunroof	√	√	√	√	√	
2009\WK-Grand Cherokee	AHLM -- Headlamp Leveling	√	√	√	√	√	
2009\WK-Grand Cherokee	AHBM -- Automatic High Beam	√	√	√	√		
2009\WK-Grand Cherokee	EOM -- Electronic Overhead	√	√	√	√		
2009\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2009\WK-Grand Cherokee	RSM -- Rain Sensor Module	√	√	√	√		
2009\WK-Grand Cherokee	AMP -- Amplifier	√	√	√	√		
2009\WK-Grand Cherokee	HFM -- Hands Free Module	√	√	√	√	√	
2009\WK-Grand Cherokee	VES3 -- Last Row Screen	√	√	√	√	√	
2009\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2009\XK-Commander	ECM -- Engine Control Module	√	√	√	√	√	
2009\XK-Commander	TCM -- Transmission Control Module	√	√	√	√		
2009\XK-Commander	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005

2009\XK-Commander	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2009\XK-Commander	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2009\XK-Commander	CGW -- Central Gateway	√	√	√	√	√	
2009\XK-Commander	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2009\XK-Commander	SAS -- Steering Angle Sensor	√	√	√	√		
2009\XK-Commander	PTS -- Parktronics	√	√	√	√	√	
2009\XK-Commander	RADIO -- Radio	√	√	√	√	√	
2009\XK-Commander	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2009\XK-Commander	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2009\XK-Commander	DDM -- Driver Door Module	√	√	√	√	√	
2009\XK-Commander	PDM -- Passenger Door Module	√	√	√	√	√	
2009\XK-Commander	ESM -- Electronic Shifter	√	√	√	√	√	
2009\XK-Commander	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2009\XK-Commander	PLGM -- Power Liftgate Module	√	√	√	√	√	
2009\XK-Commander	TM -- Trailer		√	√			
2009\XK-Commander	SUNR -- Sunroof	√	√	√	√	√	
2009\XK-Commander	AHLM -- Headlamp Leveling	√	√	√	√	√	
2009\XK-Commander	AHBM -- Automatic High Beam	√	√	√	√		
2009\XK-Commander	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2009\XK-Commander	RSM -- Rain Sensor Module	√	√	√	√		
2009\XK-Commander	SDARV -- Satellite Video Receiver	√	√	√	√		
2009\XK-Commander	AMP -- Amplifier	√	√	√	√		
2009\XK-Commander	HFM -- Hands Free Module	√	√	√	√	√	
2009\XK-Commander	VES3 -- Last Row Screen	√	√	√	√	√	
2009\XK-Commander	HSM -- Heated Seat Module	√	√	√	√	√	
2009\ZB-Viper	ECM -- Engine Control Module	√	√	√	√	√	0017, 0031
2009\ZB-Viper	OCM -- Occupant Classification	√	√	√	√		
2010\D2-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0017, 0031, 0032, 0037
2010\D2-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2010\D2-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\D2-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\D2-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\D2-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2010\D2-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2010\D2-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2010\D2-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2010\D2-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√		
2010\D2-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2010\D2-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2010\D2-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2010\D2-Ram Truck	SDARV -- Satellite Video Receiver	√	√	√	√		
2010\D2-Ram Truck	AMP -- Amplifier	√	√	√	√		
2010\D2-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2010\D2-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2010\D2-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	

2010\D2-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2010\DJ-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0032, 0037, 0031
2010\DJ-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2010\DJ-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\DJ-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\DJ-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\DJ-Ram Truck	TPM -- Tire Pressure Monitor	√	√	√	√		
2010\DJ-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	
2010\DJ-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2010\DJ-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2010\DJ-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2010\DJ-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2010\DJ-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√		
2010\DJ-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2010\DJ-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2010\DJ-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2010\DJ-Ram Truck	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2010\DJ-Ram Truck	SDARV -- Satellite Video Receiver	√	√	√	√		
2010\DJ-Ram Truck	AMP -- Amplifier	√	√	√	√		
2010\DJ-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2010\DJ-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2010\DJ-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2010\DJ-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2010\DR-RAM	ECM -- Engine Control Module	√	√	√	√	√	0031, 0032, 0031
2010\DR-RAM	TCM -- Transmission Control Module	√	√	√	√	√	
2010\DR-RAM	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\DR-RAM	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\DR-RAM	CGW -- Central Gateway	√	√	√	√	√	
2010\DR-RAM	WCM/TPMS -- Wireless Control	√	√	√	√		
2010\DR-RAM	SAS -- Steering Angle Sensor	√	√	√	√		
2010\DR-RAM	RADIO -- Radio	√	√	√	√		
2010\DR-RAM	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\DR-RAM	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2010\DR-RAM	SUNR -- Sunroof	√	√	√	√	√	
2010\DR-RAM	EOM -- Electronic Overhead	√	√	√	√	√	
2010\DR-RAM	SDAR -- Satellite Radio	√	√	√	√		
2010\DR-RAM	AMP -- Amplifier	√	√	√	√		
2010\DR-RAM	HFM -- Hands Free Module	√	√	√	√	√	
2010\DR-RAM	VES -- Vehicle Entertainment System	√	√	√	√	√	
2010\DS-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2010\DS-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2010\DS-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\DS-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\DS-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\DS-Ram Truck	TPM -- Tire Pressure Monitor	√	√	√	√		

2010\DS-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	
2010\DS-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2010\DS-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2010\DS-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2010\DS-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2010\DS-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√		
2010\DS-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2010\DS-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2010\DS-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2010\DS-Ram Truck	SDARV -- Satellite Video Receiver	√	√	√	√		
2010\DS-Ram Truck	AMP -- Amplifier	√	√	√	√		
2010\DS-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2010\DS-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2010\DS-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2010\DS-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2010\DX-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0032, 0037, 0031
2010\DX-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2010\DX-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\DX-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\DX-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\DX-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	
2010\DX-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2010\DX-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2010\DX-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2010\DX-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2010\DX-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√		
2010\DX-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2010\DX-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2010\DX-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2010\DX-Ram Truck	SDARV -- Satellite Video Receiver	√	√	√	√		
2010\DX-Ram Truck	AMP -- Amplifier	√	√	√	√		
2010\DX-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2010\DX-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2010\DX-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2010\DX-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2010\J8-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2010\J8-Wrangler	TCM -- Transmission Control Module	√	√	√	√	√	
2010\J8-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\J8-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\J8-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2010\J8-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2010\J8-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2010\J8-Wrangler	RADIO -- Radio	√	√	√	√	√	
2010\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	

2010\JC-Journey	ECM -- Engine Control Module	√	√	√	√	√	0017, 0013, 0031
2010\JC-Journey	TCM -- Transmission Control Module	√	√	√	√	√	
2010\JC-Journey	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\JC-Journey	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\JC-Journey	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\JC-Journey	CGW -- Central Gateway	√	√	√	√	√	0003
2010\JC-Journey	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2010\JC-Journey	SAS -- Steering Angle Sensor	√	√	√	√		
2010\JC-Journey	RADIO -- Radio	√	√	√	√	√	
2010\JC-Journey	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\JC-Journey	DMFR -- Door Module Front Right	√	√	√	√	√	
2010\JC-Journey	DMFL -- Door Module Front Left	√	√	√	√	√	
2010\JC-Journey	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2010\JC-Journey	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2010\JC-Journey	AMP -- Amplifier	√	√	√	√		
2010\JC-Journey	HFM -- Hands Free Module	√	√	√	√	√	
2010\JC-Journey	VES3 -- Last Row Screen	√	√	√	√	√	
2010\JC-Journey	DISP -- Front Display	√	√	√	√		
2010\JK-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2010\JK-Wrangler	TCM -- Transmission Control Module	√	√	√	√	√	
2010\JK-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\JK-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\JK-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2010\JK-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2010\JK-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2010\JK-Wrangler	RADIO -- Radio	√	√	√	√	√	
2010\JK-Wrangler	ASBS -- Automatic Sway Bar System	√	√	√	√		
2010\JK-Wrangler	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2010\JK-Wrangler	AMP -- Amplifier	√	√	√	√		
2010\JK-Wrangler	HFM -- Hands Free Module	√	√	√	√	√	
2010\JS-Avenger,Sebring,Convertible-Sedan	ECM -- Engine Control Module	√	√	√	√	√	0013
2010\JS-Avenger,Sebring,Convertible-Sedan	TCM -- Transmission Control Module	√	√	√	√	√	
2010\JS-Avenger,Sebring,Convertible-Sedan	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\JS-Avenger,Sebring,Convertible-Sedan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\JS-Avenger,Sebring,Convertible-Sedan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\JS-Avenger,Sebring,Convertible-Sedan	CGW -- Central Gateway	√	√	√	√	√	0003
2010\JS-Avenger,Sebring,Convertible-Sedan	WCM/TPMS -- Wireless Control	√	√	√	√		

2010\JS-Avenger,Sebring,Convertible-Sedan	SAS -- Steering Angle Sensor	√	√	√	√		
2010\JS-Avenger,Sebring,Convertible-Sedan	RADIO -- Radio	√	√	√	√	√	
2010\JS-Avenger,Sebring,Convertible-Sedan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\JS-Avenger,Sebring,Convertible-Sedan	DDM -- Driver Door Module	√	√	√	√	√	
2010\JS-Avenger,Sebring,Convertible-Sedan	PDM -- Passenger Door Module	√	√	√	√	√	
2010\JS-Avenger,Sebring,Convertible-Sedan	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2010\JS-Avenger,Sebring,Convertible-Sedan	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2010\JS-Avenger,Sebring,Convertible-Sedan	PTCM -- Power Top Control Module	√	√	√	√		
2010\JS-Avenger,Sebring,Convertible-Sedan	AMP -- Amplifier	√	√	√	√		
2010\JS-Avenger,Sebring,Convertible-Sedan	HFM -- Hands Free Module	√	√	√	√	√	
2010\JS-Avenger,Sebring,Convertible-Sedan	VES3 -- Last Row Screen	√	√	√	√	√	
2010\KA-Nitro	ECM -- Engine Control Module	√	√	√	√	√	
2010\KA-Nitro	TCM -- Transmission Control Module	√	√	√	√		
2010\KA-Nitro	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\KA-Nitro	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\KA-Nitro	CGW -- Central Gateway	√	√	√	√	√	0003
2010\KA-Nitro	WCM/TPMS -- Wireless Control	√	√	√	√		
2010\KA-Nitro	SAS -- Steering Angle Sensor	√	√	√	√		
2010\KA-Nitro	PTS -- Parktronics	√	√	√	√	√	
2010\KA-Nitro	RADIO -- Radio	√	√	√	√	√	
2010\KA-Nitro	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\KA-Nitro	DMFR -- Door Module Front Right	√	√	√	√	√	
2010\KA-Nitro	DMFL -- Door Module Front Left	√	√	√	√	√	
2010\KA-Nitro	ESM -- Electronic Shifter	√	√	√	√	√	
2010\KA-Nitro	OCM -- Occupant Classification	√	√	√	√		
2010\KA-Nitro	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2010\KA-Nitro	AMP -- Amplifier	√	√	√	√		
2010\KA-Nitro	HFM -- Hands Free Module	√	√	√	√	√	
2010\KK-Liberty	ECM -- Engine Control Module	√	√	√	√	√	
2010\KK-Liberty	TCM -- Transmission Control Module	√	√	√	√		
2010\KK-Liberty	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\KK-Liberty	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\KK-Liberty	CGW -- Central Gateway	√	√	√	√	√	0003
2010\KK-Liberty	WCM/TPMS -- Wireless Control	√	√	√	√		
2010\KK-Liberty	SAS -- Steering Angle Sensor	√	√	√	√		



2010\KK-Liberty	PTS -- Parktronics	√	√	√	√	√	
2010\KK-Liberty	RADIO -- Radio	√	√	√	√	√	
2010\KK-Liberty	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2010\KK-Liberty	DMFR -- Door Module Front Right	√	√	√	√	√	
2010\KK-Liberty	DMFL -- Door Module Front Left	√	√	√	√	√	
2010\KK-Liberty	ESM -- Electronic Shifter	√	√	√	√	√	
2010\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2010\KK-Liberty	OCM -- Occupant Classification	√	√	√	√		
2010\KK-Liberty	SUNR -- Sunroof	√	√	√	√		
2010\KK-Liberty	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2010\KK-Liberty	AMP -- Amplifier	√	√	√	√		
2010\KK-Liberty	HFM -- Hands Free Module	√	√	√	√	√	
2010\LC-Challenger	ECM -- Engine Control Module	√	√	√	√	√	
2010\LC-Challenger	TCM -- Transmission Control Module	√	√	√	√		
2010\LC-Challenger	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\LC-Challenger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\LC-Challenger	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\LC-Challenger	CGW -- Central Gateway	√	√	√	√	√	
2010\LC-Challenger	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2010\LC-Challenger	RADIO -- Radio	√	√	√	√	√	
2010\LC-Challenger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\LC-Challenger	DDM -- Driver Door Module	√	√	√	√	√	
2010\LC-Challenger	PDM -- Passenger Door Module	√	√	√	√	√	
2010\LC-Challenger	SCM -- Steering Column	√	√	√	√	√	
2010\LC-Challenger	ESM -- Electronic Shifter	√	√	√	√	√	
2010\LC-Challenger	SUNR -- Sunroof	√	√	√	√	√	
2010\LC-Challenger	EOM -- Electronic Overhead	√	√	√	√		
2010\LC-Challenger	AMP -- Amplifier	√	√	√	√		
2010\LC-Challenger	HFM -- Hands Free Module	√	√	√	√	√	
2010\LC-Challenger	HSM -- Heated Seat Module	√	√	√	√	√	
2010\LC-Challenger	PEM -- Passive Entry Module	√	√	√	√		
2010\LX-300,Charger,Magnum,Grand Voyager	ECM -- Engine Control Module	√	√	√	√	√	0031
2010\LX-300,Charger,Magnum,Grand Voyager	TCM -- Transmission Control Module	√	√	√	√		
2010\LX-300,Charger,Magnum,Grand Voyager	DTCM -- Drive Train Control Module	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\LX-300,Charger,Magnum,Grand Voyager	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\LX-300,Charger,Magnum,Grand Voyager	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	TPM -- Tire Pressure Monitor	√	√	√	√		

2010\LX-300,Charger,Magnum,Grand Voyager	CGW -- Central Gateway	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	PTS -- Parktronics	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	RADIO -- Radio	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	ACC -- Adaptive Cruise Control	√	√	√	√		
2010\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2010\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	SCM -- Steering Column	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	SUNR -- Sunroof	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	PTIM -- Police/Taxi Interface Module	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	AHBM -- Automatic High Beam	√	√	√	√		
2010\LX-300,Charger,Magnum,Grand Voyager	EOM -- Electronic Overhead	√	√	√	√		
2010\LX-300,Charger,Magnum,Grand Voyager	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	RSM -- Rain Sensor Module	√	√	√	√		
2010\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√		
2010\LX-300,Charger,Magnum,Grand Voyager	HFM -- Hands Free Module	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	VES3 -- Last Row Screen	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2010\LX-300,Charger,Magnum,Grand Voyager	PEM -- Passive Entry Module	√	√	√	√		
2010\MK-Compass,Patriot	ECM -- Engine Control Module	√	√	√	√	√	0012, 0036, 0053
2010\MK-Compass,Patriot	TCM -- Transmission Control Module	√	√	√	√	√	
2010\MK-Compass,Patriot	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005

2010\MK-Compass,Patriot	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\MK-Compass,Patriot	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\MK-Compass,Patriot	CGW -- Central Gateway	√	√	√	√	√	0003
2010\MK-Compass,Patriot	WCM/TPMS -- Wireless Control	√	√	√	√		
2010\MK-Compass,Patriot	SAS -- Steering Angle Sensor	√	√	√	√		
2010\MK-Compass,Patriot	RADIO -- Radio	√	√	√	√	√	
2010\MK-Compass,Patriot	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\MK-Compass,Patriot	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2010\MK-Compass,Patriot	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2010\MK-Compass,Patriot	AMP -- Amplifier	√	√	√	√		
2010\MK-Compass,Patriot	HFM -- Hands Free Module	√	√	√	√	√	
2010\ND-Dakota	ECM -- Engine Control Module	√	√	√	√	√	
2010\ND-Dakota	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\ND-Dakota	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\ND-Dakota	CGW -- Central Gateway	√	√	√	√	√	
2010\ND-Dakota	WCM/TPMS -- Wireless Control	√	√	√	√		
2010\ND-Dakota	RADIO -- Radio	√	√	√	√	√	
2010\ND-Dakota	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\ND-Dakota	EOM -- Electronic Overhead	√	√	√	√		
2010\ND-Dakota	AMP -- Amplifier	√	√	√	√		
2010\ND-Dakota	HFM -- Hands Free Module	√	√	√	√	√	
2010\NM-Raider	ECM -- Engine Control Module	√	√	√	√	√	
2010\NM-Raider	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\NM-Raider	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\NM-Raider	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\NM-Raider	CGW -- Central Gateway	√	√	√	√	√	
2010\NM-Raider	WCM/TPMS -- Wireless Control	√	√	√	√		
2010\NM-Raider	RADIO -- Radio	√	√	√	√	√	
2010\NM-Raider	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\NM-Raider	EOM -- Electronic Overhead	√	√	√	√		
2010\NM-Raider	HFM -- Hands Free Module	√	√	√	√	√	
2010\PM-Caliber	ECM -- Engine Control Module	√	√	√	√	√	0012, 0036, 0053
2010\PM-Caliber	TCM -- Transmission Control Module	√	√	√	√	√	
2010\PM-Caliber	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\PM-Caliber	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\PM-Caliber	CGW -- Central Gateway	√	√	√	√	√	0003
2010\PM-Caliber	WCM/TPMS -- Wireless Control	√	√	√	√		
2010\PM-Caliber	SAS -- Steering Angle Sensor	√	√	√	√		
2010\PM-Caliber	RADIO -- Radio	√	√	√	√	√	
2010\PM-Caliber	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\PM-Caliber	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2010\PM-Caliber	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2010\PM-Caliber	AMP -- Amplifier	√	√	√	√		

2010\PM-Caliber	HFM -- Hands Free Module	√	√	√	√	√	
2010\PM-Caliber	EBG -- Electronic Booster Gauge	√	√	√	√		
2010\PT-PT Cruiser	ECM -- Engine Control Module	√	√	√	√	√	0050, 0017, 0031, 0031
2010\PT-PT Cruiser	TCM -- Transmission Control Module	√	√	√	√	√	
2010\PT-PT Cruiser	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005, 0028, 0030
2010\PT-PT Cruiser	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\PT-PT Cruiser	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\PT-PT Cruiser	CGW -- Central Gateway	√	√	√	√	√	0003
2010\PT-PT Cruiser	WCM/TPMS -- Wireless Control	√	√	√	√		
2010\PT-PT Cruiser	RADIO -- Radio	√	√	√	√		
2010\PT-PT Cruiser	DDM -- Driver Door Module	√	√	√	√	√	
2010\PT-PT Cruiser	PDM -- Passenger Door Module	√	√	√	√	√	
2010\PT-PT Cruiser	OCM -- Occupant Classification	√	√	√	√		
2010\PT-PT Cruiser	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2010\PT-PT Cruiser	SDAR -- Satellite Radio	√	√	√	√		
2010\PT-PT Cruiser	AMP -- Amplifier	√	√	√	√		
2010\PT-PT Cruiser	HFM -- Hands Free Module	√	√	√	√	√	
2010\RM-Routan	ECM -- Engine Control Module	√	√	√	√	√	
2010\RM-Routan	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\RM-Routan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\RM-Routan	CGW -- Central Gateway	√	√	√	√	√	0003
2010\RM-Routan	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2010\RM-Routan	SAS -- Steering Angle Sensor	√	√	√	√		
2010\RM-Routan	PTS -- Parktronics	√	√	√	√	√	
2010\RM-Routan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2010\RM-Routan	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2010\RM-Routan	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2010\RM-Routan	DMFR -- Door Module Front Right	√	√	√	√	√	
2010\RM-Routan	DMFL -- Door Module Front Left	√	√	√	√	√	
2010\RM-Routan	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2010\RM-Routan	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2010\RM-Routan	PLGM -- Power Liftgate Module	√	√	√	√	√	
2010\RM-Routan	FSM -- Fold Stow Module	√	√	√	√	√	
2010\RM-Routan	SUNR -- Sunroof	√	√	√	√	√	
2010\RM-Routan	DVD -- DVD Changer	√	√	√	√		
2010\RM-Routan	AMP -- Amplifier	√	√	√	√		
2010\RM-Routan	HFM -- Hands Free Module	√	√	√	√	√	
2010\RM-Routan	VES2 -- Second Row Screen	√	√	√	√	√	
2010\RM-Routan	VES3 -- Last Row Screen	√	√	√	√	√	
2010\RT-Caravan,Town & Country	ECM -- Engine Control Module	√	√	√	√	√	
2010\RT-Caravan,Town & Country	TCM -- Transmission Control Module	√	√	√	√	√	
2010\RT-Caravan,Town & Country	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\RT-Caravan,Town & Country	ORC -- AirBag/Occupant Restraint	√	√	√	√		

2010\RT-Caravan,Town & Country	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\RT-Caravan,Town & Country	CGW -- Central Gateway	√	√	√	√	√	0003
2010\RT-Caravan,Town & Country	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2010\RT-Caravan,Town & Country	SAS -- Steering Angle Sensor	√	√	√	√		
2010\RT-Caravan,Town & Country	PTS -- Parktronics	√	√	√	√	√	
2010\RT-Caravan,Town & Country	RADIO -- Radio	√	√	√	√	√	
2010\RT-Caravan,Town & Country	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\RT-Caravan,Town & Country	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2010\RT-Caravan,Town & Country	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2010\RT-Caravan,Town & Country	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2010\RT-Caravan,Town & Country	DMFR -- Door Module Front Right	√	√	√	√	√	
2010\RT-Caravan,Town & Country	DMFL -- Door Module Front Left	√	√	√	√	√	
2010\RT-Caravan,Town & Country	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2010\RT-Caravan,Town & Country	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2010\RT-Caravan,Town & Country	PLGM -- Power Liftgate Module	√	√	√	√	√	
2010\RT-Caravan,Town & Country	FSM -- Fold Stow Module	√	√	√	√	√	
2010\RT-Caravan,Town & Country	SUNR -- Sunroof	√	√	√	√	√	
2010\RT-Caravan,Town & Country	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2010\RT-Caravan,Town & Country	AHBM -- Automatic High Beam	√	√	√	√		
2010\RT-Caravan,Town & Country	DVD -- DVD Changer	√	√	√	√		
2010\RT-Caravan,Town & Country	SDARV -- Satellite Video Receiver	√	√	√	√		
2010\RT-Caravan,Town & Country	AMP -- Amplifier	√	√	√	√		
2010\RT-Caravan,Town & Country	HFM -- Hands Free Module	√	√	√	√	√	
2010\RT-Caravan,Town & Country	VES2 -- Second Row Screen	√	√	√	√	√	
2010\RT-Caravan,Town & Country	VES3 -- Last Row Screen	√	√	√	√	√	
2010\RT-Caravan,Town & Country	BSM -- Blind Spot Module	√	√	√	√		
2010\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	0031
2010\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2010\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\WK-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2010\WK-Grand Cherokee	CGW -- Central Gateway	√	√	√	√	√	
2010\WK-Grand Cherokee	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2010\WK-Grand Cherokee	SAS -- Steering Angle Sensor	√	√	√	√		
2010\WK-Grand Cherokee	PTS -- Parktronics	√	√	√	√	√	
2010\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√	√	
2010\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2010\WK-Grand Cherokee	DDM -- Driver Door Module	√	√	√	√	√	
2010\WK-Grand Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2010\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2010\WK-Grand Cherokee	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2010\WK-Grand Cherokee	TM -- Trailer		√	√			
2010\WK-Grand Cherokee	SUNR -- Sunroof	√	√	√	√	√	
2010\WK-Grand Cherokee	AHLM -- Headlamp Leveling	√	√	√	√	√	

2010\WK-Grand Cherokee	AHBM -- Automatic High Beam	√	√	√	√		
2010\WK-Grand Cherokee	EOM -- Electronic Overhead	√	√	√	√		
2010\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2010\WK-Grand Cherokee	RSM -- Rain Sensor Module	√	√	√	√		
2010\WK-Grand Cherokee	SDARV -- Satellite Video Receiver	√	√	√	√		
2010\WK-Grand Cherokee	AMP -- Amplifier	√	√	√	√		
2010\WK-Grand Cherokee	HFM -- Hands Free Module	√	√	√	√	√	
2010\WK-Grand Cherokee	VES3 -- Last Row Screen	√	√	√	√	√	
2010\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2010\XK-Commander	ECM -- Engine Control Module	√	√	√	√	√	
2010\XK-Commander	TCM -- Transmission Control Module	√	√	√	√		
2010\XK-Commander	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2010\XK-Commander	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2010\XK-Commander	CGW -- Central Gateway	√	√	√	√	√	
2010\XK-Commander	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2010\XK-Commander	SAS -- Steering Angle Sensor	√	√	√	√		
2010\XK-Commander	PTS -- Parktronic	√	√	√	√	√	
2010\XK-Commander	RADIO -- Radio	√	√	√	√	√	
2010\XK-Commander	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2010\XK-Commander	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2010\XK-Commander	DDM -- Driver Door Module	√	√	√	√	√	
2010\XK-Commander	PDM -- Passenger Door Module	√	√	√	√	√	
2010\XK-Commander	ESM -- Electronic Shifter	√	√	√	√	√	
2010\XK-Commander	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2010\XK-Commander	PLGM -- Power Liftgate Module	√	√	√	√	√	
2010\XK-Commander	TM -- Trailer		√	√			
2010\XK-Commander	SUNR -- Sunroof	√	√	√	√	√	
2010\XK-Commander	AHLM -- Headlamp Leveling	√	√	√	√	√	
2010\XK-Commander	AHBM -- Automatic High Beam	√	√	√	√		
2010\XK-Commander	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2010\XK-Commander	RSM -- Rain Sensor Module	√	√	√	√		
2010\XK-Commander	SDARV -- Satellite Video Receiver	√	√	√	√		
2010\XK-Commander	AMP -- Amplifier	√	√	√	√		
2010\XK-Commander	HFM -- Hands Free Module	√	√	√	√	√	
2010\XK-Commander	VES3 -- Last Row Screen	√	√	√	√	√	
2010\XK-Commander	HSM -- Heated Seat Module	√	√	√	√	√	
2010\ZB-Viper	ECM -- Engine Control Module	√	√	√	√	√	0017, 0031
2010\ZB-Viper	OCM -- Occupant Classification	√	√	√	√		
2011\D2-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2011\D2-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2011\D2-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\D2-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\D2-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\D2-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	0003
2011\D2-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	

2011\D2-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2011\D2-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2011\D2-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2011\D2-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\D2-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2011\D2-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2011\D2-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2011\D2-Ram Truck	AMP -- Amplifier	√	√	√	√		
2011\D2-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2011\D2-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2011\D2-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2011\D2-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2011\DD-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0032, 0037, 0031
2011\DD-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2011\DD-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2011\DD-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\DD-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\DD-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\DD-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	
2011\DD-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2011\DD-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2011\DD-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2011\DD-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\DD-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2011\DD-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2011\DD-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2011\DD-Ram Truck	AMP -- Amplifier	√	√	√	√		
2011\DD-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2011\DD-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2011\DD-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2011\DD-Ram Truck	DCU -- Dosing Control Unit	√					
2011\DJ-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2011\DJ-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2011\DJ-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\DJ-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\DJ-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\DJ-Ram Truck	TPM -- Tire Pressure Monitor	√	√	√	√		
2011\DJ-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	0003
2011\DJ-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2011\DJ-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2011\DJ-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2011\DJ-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2011\DJ-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\DJ-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2011\DJ-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	

2011\DJ-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2011\DJ-Ram Truck	SDARV -- Satellite Video Receiver	√	√	√	√		
2011\DJ-Ram Truck	AMP -- Amplifier	√	√	√	√		
2011\DJ-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2011\DJ-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2011\DJ-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2011\DJ-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2011\DP-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0032, 0037, 0031
2011\DP-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2011\DP-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2011\DP-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\DP-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\DP-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\DP-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	
2011\DP-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2011\DP-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2011\DP-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2011\DP-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\DP-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2011\DP-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2011\DP-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2011\DP-Ram Truck	AMP -- Amplifier	√	√	√	√		
2011\DP-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2011\DP-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2011\DP-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2011\DP-Ram Truck	DCU -- Dosing Control Unit	√					
2011\DS-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0017, 0031
2011\DS-Ram Truck	TCM -- Transmission Control Module	√	√	√	√		
2011\DS-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2011\DS-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\DS-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\DS-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\DS-Ram Truck	TPM -- Tire Pressure Monitor	√	√	√	√		
2011\DS-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	0003
2011\DS-Ram Truck	HGM -- Hybrid Gateway Module	√	√	√	√	√	
2011\DS-Ram Truck	PHGM -- Plug In Hybrid Gateway Module	√	√	√	√	√	
2011\DS-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2011\DS-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2011\DS-Ram Truck	EPS -- Electric Power Steering	√	√	√	√		
2011\DS-Ram Truck	PTS -- Parktronic	√	√	√	√	√	
2011\DS-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\DS-Ram Truck	APM -- Adjustable Pedal Module	√					
2011\DS-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2011\DS-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2011\DS-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	



2011\DS-Ram Truck	SDARV -- Satellite Video Receiver	√	√	√	√		
2011\DS-Ram Truck	AMP -- Amplifier	√	√	√	√		
2011\DS-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2011\DS-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2011\DS-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2011\DS-Ram Truck	BPCM -- Battery Pack Control Module	√	√	√	√	√	0040
2011\DS-Ram Truck	EAC -- Electric A/C Compressor	√	√	√	√		
2011\DS-Ram Truck	HCP -- Hybrid Control Processor	√	√	√	√		
2011\DS-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2011\DS-Ram Truck	MCPA -- Motor Control Processor A	√			√		
2011\DS-Ram Truck	MCPB -- Motor Control Processor B	√			√		
2011\DS-Ram Truck	BTM -- Battery Thermal Module	√	√	√	√	√	
2011\DS-Ram Truck	DRM -- Data Recorder Module	√	√	√	√		
2011\DS-Ram Truck	OBCM -- On Board Charging Module	√	√	√	√	√	
2011\DX-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0032, 0037, 0031
2011\DX-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2011\DX-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\DX-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\DX-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\DX-Ram Truck	TPM -- Tire Pressure Monitor	√	√	√	√		
2011\DX-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	0003
2011\DX-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2011\DX-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2011\DX-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2011\DX-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2011\DX-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\DX-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2011\DX-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2011\DX-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2011\DX-Ram Truck	SDARV -- Satellite Video Receiver	√	√	√	√		
2011\DX-Ram Truck	AMP -- Amplifier	√	√	√	√		
2011\DX-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2011\DX-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2011\DX-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2011\J8-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2011\J8-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2011\J8-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\J8-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\J8-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2011\J8-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2011\J8-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2011\J8-Wrangler	RADIO -- Radio	√	√	√	√	√	
2011\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\JC-Journey	ECM -- Engine Control Module	√	√	√	√	√	0041

2011\JC-Journey	DTCM -- Drive Train Control Module	√	√	√	√	√	
2011\JC-Journey	ABS -- Anti Lock Brakes	√	√	√	√	√	
2011\JC-Journey	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\JC-Journey	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2011\JC-Journey	TPM -- Tire Pressure Monitor	√	√	√	√		
2011\JC-Journey	BCM -- Body Controller	√	√	√	√	√	
2011\JC-Journey	TGW -- Telematic Gateway Radio	√	√	√	√		
2011\JC-Journey	RFH -- Radio Frequency Hub	√	√	√	√	√	
2011\JC-Journey	PTS -- Parktronics	√	√	√	√	√	
2011\JC-Journey	ICS -- Integrated Center Stack	√	√	√	√	√	
2011\JC-Journey	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\JC-Journey	SCCM -- Steering Column Control Module	√	√	√	√		
2011\JC-Journey	DDM -- Driver Door Module	√	√	√	√	√	
2011\JC-Journey	PDM -- Passenger Door Module	√	√	√	√	√	
2011\JC-Journey	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2011\JC-Journey	AMP -- Amplifier	√	√	√	√		
2011\JC-Journey	HFM -- Hands Free Module	√	√	√	√		
2011\JC-Journey	VES3 -- Last Row Screen	√	√	√	√	√	
2011\JC-Journey	HSM -- Heated Seat Module	√	√	√	√	√	
2011\JF-Freemont	ECM -- Engine Control Module	√	√	√	√	√	0041
2011\JF-Freemont	DTCM -- Drive Train Control Module	√	√	√	√	√	
2011\JF-Freemont	ABS -- Anti Lock Brakes	√	√	√	√	√	
2011\JF-Freemont	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\JF-Freemont	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2011\JF-Freemont	TPM -- Tire Pressure Monitor	√	√	√	√		
2011\JF-Freemont	BCM -- Body Controller	√	√	√	√	√	
2011\JF-Freemont	TGW -- Telematic Gateway Radio	√	√	√	√		
2011\JF-Freemont	RFH -- Radio Frequency Hub	√	√	√	√	√	
2011\JF-Freemont	ICS -- Integrated Center Stack	√	√	√	√	√	
2011\JF-Freemont	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\JF-Freemont	SCCM -- Steering Column Control Module	√	√	√	√		
2011\JF-Freemont	DDM -- Driver Door Module	√	√	√	√	√	
2011\JF-Freemont	PDM -- Passenger Door Module	√	√	√	√	√	
2011\JF-Freemont	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2011\JF-Freemont	AMP -- Amplifier	√	√	√	√		
2011\JF-Freemont	HFM -- Hands Free Module	√	√	√	√		
2011\JF-Freemont	VES3 -- Last Row Screen	√	√	√	√	√	
2011\JF-Freemont	HSM -- Heated Seat Module	√	√	√	√	√	
2011\JK-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2011\JK-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2011\JK-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\JK-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\JK-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2011\JK-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		

2011\JK-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2011\JK-Wrangler	RADIO -- Radio	√	√	√	√	√	
2011\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\JK-Wrangler	ESM -- Electronic Shifter	√	√	√	√	√	
2011\JK-Wrangler	ASBS -- Automatic Sway Bar System	√	√	√	√		
2011\JK-Wrangler	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2011\JK-Wrangler	AMP -- Amplifier	√	√	√	√		
2011\JK-Wrangler	HFM -- Hands Free Module	√	√	√	√	√	
2011\JS-Avenger,Sebring,Convertible-Sedan	ECM -- Engine Control Module	√	√	√	√	√	
2011\JS-Avenger,Sebring,Convertible-Sedan	TCM -- Transmission Control Module	√	√	√	√	√	
2011\JS-Avenger,Sebring,Convertible-Sedan	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\JS-Avenger,Sebring,Convertible-Sedan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\JS-Avenger,Sebring,Convertible-Sedan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\JS-Avenger,Sebring,Convertible-Sedan	CGW -- Central Gateway	√	√	√	√	√	0003
2011\JS-Avenger,Sebring,Convertible-Sedan	WCM/TPMS -- Wireless Control	√	√	√	√		
2011\JS-Avenger,Sebring,Convertible-Sedan	SAS -- Steering Angle Sensor	√	√	√	√		
2011\JS-Avenger,Sebring,Convertible-Sedan	RADIO -- Radio	√	√	√	√	√	
2011\JS-Avenger,Sebring,Convertible-Sedan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\JS-Avenger,Sebring,Convertible-Sedan	DDM -- Driver Door Module	√	√	√	√	√	
2011\JS-Avenger,Sebring,Convertible-Sedan	PDM -- Passenger Door Module	√	√	√	√	√	
2011\JS-Avenger,Sebring,Convertible-Sedan	ESM -- Electronic Shifter	√	√	√	√	√	
2011\JS-Avenger,Sebring,Convertible-Sedan	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2011\JS-Avenger,Sebring,Convertible-Sedan	PTCM -- Power Top Control Module	√	√	√	√		
2011\JS-Avenger,Sebring,Convertible-Sedan	AMP -- Amplifier	√	√	√	√		
2011\JS-Avenger,Sebring,Convertible-Sedan	HFM -- Hands Free Module	√	√	√	√	√	
2011\JS-Avenger,Sebring,Convertible-Sedan	VES3 -- Last Row Screen	√	√	√	√	√	
2011\KA-Nitro	ECM -- Engine Control Module	√	√	√	√	√	
2011\KA-Nitro	TCM -- Transmission Control Module	√	√	√	√		
2011\KA-Nitro	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\KA-Nitro	ORC -- AirBag/Occupant Restraint	√	√	√	√		

2011\KA-Nitro	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\KA-Nitro	CGW -- Central Gateway	√	√	√	√	√	0003
2011\KA-Nitro	WCM/TPMS -- Wireless Control	√	√	√	√		
2011\KA-Nitro	SAS -- Steering Angle Sensor	√	√	√	√		
2011\KA-Nitro	PTS -- Parktronics	√	√	√	√	√	
2011\KA-Nitro	RADIO -- Radio	√	√	√	√	√	
2011\KA-Nitro	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\KA-Nitro	DMFR -- Door Module Front Right	√	√	√	√	√	
2011\KA-Nitro	DMFL -- Door Module Front Left	√	√	√	√	√	
2011\KA-Nitro	ESM -- Electronic Shifter	√	√	√	√	√	
2011\KA-Nitro	OCM -- Occupant Classification	√	√	√	√		
2011\KA-Nitro	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2011\KA-Nitro	AMP -- Amplifier	√	√	√	√		
2011\KA-Nitro	HFM -- Hands Free Module	√	√	√	√	√	
2011\KK-Liberty	ECM -- Engine Control Module	√	√	√	√	√	
2011\KK-Liberty	TCM -- Transmission Control Module	√	√	√	√		
2011\KK-Liberty	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\KK-Liberty	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\KK-Liberty	CGW -- Central Gateway	√	√	√	√	√	0003
2011\KK-Liberty	WCM/TPMS -- Wireless Control	√	√	√	√		
2011\KK-Liberty	SAS -- Steering Angle Sensor	√	√	√	√		
2011\KK-Liberty	PTS -- Parktronics	√	√	√	√	√	
2011\KK-Liberty	RADIO -- Radio	√	√	√	√	√	
2011\KK-Liberty	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2011\KK-Liberty	DMFR -- Door Module Front Right	√	√	√	√	√	
2011\KK-Liberty	DMFL -- Door Module Front Left	√	√	√	√	√	
2011\KK-Liberty	ESM -- Electronic Shifter	√	√	√	√	√	
2011\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2011\KK-Liberty	OCM -- Occupant Classification	√	√	√	√		
2011\KK-Liberty	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2011\KK-Liberty	AMP -- Amplifier	√	√	√	√		
2011\KK-Liberty	HFM -- Hands Free Module	√	√	√	√	√	
2011\LC-Challenger	ECM -- Engine Control Module	√	√	√	√	√	
2011\LC-Challenger	TCM -- Transmission Control Module	√	√	√	√		
2011\LC-Challenger	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2011\LC-Challenger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\LC-Challenger	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\LC-Challenger	TPM -- Tire Pressure Monitor	√	√	√	√		
2011\LC-Challenger	CGW -- Central Gateway	√	√	√	√	√	
2011\LC-Challenger	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2011\LC-Challenger	SAS -- Steering Angle Sensor	√	√	√	√	√	
2011\LC-Challenger	EPS -- Electric Power Steering	√	√	√	√		
2011\LC-Challenger	RADIO -- Radio	√	√	√	√	√	

2011\LC-Challenger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\LC-Challenger	DDM -- Driver Door Module	√	√	√	√	√	
2011\LC-Challenger	PDM -- Passenger Door Module	√	√	√	√	√	
2011\LC-Challenger	ESM -- Electronic Shifter	√	√	√	√	√	
2011\LC-Challenger	SUNR -- Sunroof	√	√	√	√	√	
2011\LC-Challenger	EOM -- Electronic Overhead	√	√	√	√		
2011\LC-Challenger	AMP -- Amplifier	√	√	√	√		
2011\LC-Challenger	HFM -- Hands Free Module	√	√	√	√	√	
2011\LC-Challenger	HSM -- Heated Seat Module	√	√	√	√	√	
2011\LC-Challenger	PEM -- Passive Entry Module	√	√	√	√		
2011\LD-Charger	ECM -- Engine Control Module	√	√	√	√	√	
2011\LD-Charger	TCM -- Transmission Control Module	√	√	√	√		
2011\LD-Charger	DTCM -- Drive Train Control Module	√	√	√	√	√	
2011\LD-Charger	ABS -- Anti Lock Brakes	√	√	√	√	√	
2011\LD-Charger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\LD-Charger	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2011\LD-Charger	TPM -- Tire Pressure Monitor	√	√	√	√		
2011\LD-Charger	BCM -- Body Controller	√	√	√	√	√	
2011\LD-Charger	TGW -- Telematic Gateway Radio	√	√	√	√		
2011\LD-Charger	RFH -- Radio Frequency Hub	√	√	√	√	√	
2011\LD-Charger	EPS -- Electric Power Steering	√	√	√	√		
2011\LD-Charger	PTS -- Parktronics	√	√	√	√	√	
2011\LD-Charger	ICS -- Integrated Center Stack	√	√	√	√	√	
2011\LD-Charger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\LD-Charger	ACC -- Adaptive Cruise Control	√	√	√	√		
2011\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2011\LD-Charger	DDM -- Driver Door Module	√	√	√	√	√	
2011\LD-Charger	PDM -- Passenger Door Module	√	√	√	√	√	
2011\LD-Charger	ESM -- Electronic Shifter	√	√	√	√	√	
2011\LD-Charger	AMP -- Amplifier	√	√	√	√		
2011\LD-Charger	HFM -- Hands Free Module	√	√	√	√		
2011\LD-Charger	HSM -- Heated Seat Module	√	√	√	√	√	
2011\LD-Charger	BSM -- Blind Spot Module	√	√	√	√		
2011\LD-Charger	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	ECM -- Engine Control Module	√	√	√	√	√	0041
2011\LX-300,Charger,Magnum,Grand Voyager	TCM -- Transmission Control Module	√	√	√	√		
2011\LX-300,Charger,Magnum,Grand Voyager	DTCM -- Drive Train Control Module	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	ABS -- Anti Lock Brakes	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\LX-300,Charger,Magnum,Grand Voyager	IPC -- Instrument Panel Cluster	√	√	√	√	√	

2011\LX-300,Charger,Magnum,Grand Voyager	TPM -- Tire Pressure Monitor	√	√	√	√		
2011\LX-300,Charger,Magnum,Grand Voyager	BCM -- Body Controller	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	TGW -- Telematic Gateway Radio	√	√	√	√		
2011\LX-300,Charger,Magnum,Grand Voyager	RFH -- Radio Frequency Hub	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	EPS -- Electric Power Steering	√	√	√	√		
2011\LX-300,Charger,Magnum,Grand Voyager	PTS -- Parktronics	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	ICS -- Integrated Center Stack	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	AFLS -- Adaptive Front Lighting System	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	ACC -- Adaptive Cruise Control	√	√	√	√		
2011\LX-300,Charger,Magnum,Grand Voyager	SCCM -- Steering Column Control Module	√	√	√	√		
2011\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√		
2011\LX-300,Charger,Magnum,Grand Voyager	HFM -- Hands Free Module	√	√	√	√		
2011\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2011\LX-300,Charger,Magnum,Grand Voyager	BSM -- Blind Spot Module	√	√	√	√		
2011\MK-Compass,Patriot	ECM -- Engine Control Module	√	√	√	√	√	0012, 0036, 0053
2011\MK-Compass,Patriot	TCM -- Transmission Control Module	√	√	√	√	√	
2011\MK-Compass,Patriot	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\MK-Compass,Patriot	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\MK-Compass,Patriot	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\MK-Compass,Patriot	WCM/TPMS -- Wireless Control	√	√	√	√		
2011\MK-Compass,Patriot	SAS -- Steering Angle Sensor	√	√	√	√		
2011\MK-Compass,Patriot	RADIO -- Radio	√	√	√	√	√	
2011\MK-Compass,Patriot	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\MK-Compass,Patriot	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	

2011\MK-Compass,Patriot	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2011\MK-Compass,Patriot	AMP -- Amplifier	√	√	√	√		
2011\MK-Compass,Patriot	HFM -- Hands Free Module	√	√	√	√	√	
2011\ND-Dakota	ECM -- Engine Control Module	√	√	√	√	√	
2011\ND-Dakota	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\ND-Dakota	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\ND-Dakota	CGW -- Central Gateway	√	√	√	√	√	
2011\ND-Dakota	WCM/TPMS -- Wireless Control	√	√	√	√		
2011\ND-Dakota	RADIO -- Radio	√	√	√	√	√	
2011\ND-Dakota	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\ND-Dakota	EOM -- Electronic Overhead	√	√	√	√		
2011\ND-Dakota	AMP -- Amplifier	√	√	√	√		
2011\ND-Dakota	HFM -- Hands Free Module	√	√	√	√	√	
2011\NY-Ypsilon	ECM -- Engine Control Module	√	√	√	√	√	
2011\NY-Ypsilon	TCM -- Transmission Control Module	√	√	√	√	√	
2011\NY-Ypsilon	ABS -- Anti Lock Brakes	√	√	√	√	√	
2011\NY-Ypsilon	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2011\NY-Ypsilon	IPC -- Instrument Panel Cluster	√	√	√	√	√	0043
2011\NY-Ypsilon	BCM -- Body Controller	√	√	√	√	√	
2011\NY-Ypsilon	EPS -- Electric Power Steering	√	√	√	√		
2011\NY-Ypsilon	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\NY-Ypsilon	AHM -- Additional Heater Module	√	√	√	√	√	
2011\PM-Caliber	ECM -- Engine Control Module	√	√	√	√	√	0012, 0036, 0053
2011\PM-Caliber	TCM -- Transmission Control Module	√	√	√	√	√	
2011\PM-Caliber	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\PM-Caliber	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\PM-Caliber	CGW -- Central Gateway	√	√	√	√	√	0003
2011\PM-Caliber	WCM/TPMS -- Wireless Control	√	√	√	√		
2011\PM-Caliber	SAS -- Steering Angle Sensor	√	√	√	√		
2011\PM-Caliber	RADIO -- Radio	√	√	√	√	√	
2011\PM-Caliber	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\PM-Caliber	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2011\PM-Caliber	HFM -- Hands Free Module	√	√	√	√	√	
2011\RM-Routan	ECM -- Engine Control Module	√	√	√	√	√	
2011\RM-Routan	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\RM-Routan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\RM-Routan	TPM -- Tire Pressure Monitor	√	√	√	√		
2011\RM-Routan	CGW -- Central Gateway	√	√	√	√	√	0003
2011\RM-Routan	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2011\RM-Routan	SAS -- Steering Angle Sensor	√	√	√	√		
2011\RM-Routan	PTS -- Parktronics	√	√	√	√	√	
2011\RM-Routan	RADIO -- Radio	√	√	√	√	√	

2011\RM-Routan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2011\RM-Routan	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2011\RM-Routan	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2011\RM-Routan	DMFR -- Door Module Front Right	√	√	√	√	√	
2011\RM-Routan	DMFL -- Door Module Front Left	√	√	√	√	√	
2011\RM-Routan	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2011\RM-Routan	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2011\RM-Routan	PLGM -- Power Liftgate Module	√	√	√	√	√	
2011\RM-Routan	FSM -- Fold Stow Module	√	√	√	√	√	
2011\RM-Routan	SUNR -- Sunroof	√	√	√	√	√	
2011\RM-Routan	DVD -- DVD Changer	√	√	√	√		
2011\RM-Routan	AMP -- Amplifier	√	√	√	√		
2011\RM-Routan	HFM -- Hands Free Module	√	√	√	√	√	
2011\RM-Routan	VES2 -- Second Row Screen	√	√	√	√	√	
2011\RM-Routan	VES3 -- Last Row Screen	√	√	√	√	√	
2011\RM-Routan	HSM -- Heated Seat Module	√	√	√	√	√	
2011\RM-Routan	PEM -- Passive Entry Module	√	√	√	√		
2011\RT-Caravan,Town & Country	ECM -- Engine Control Module	√	√	√	√	√	0015, 0016, 0031, 0032, 0048, 0049, 0059
2011\RT-Caravan,Town & Country	TCM -- Transmission Control Module	√	√	√	√	√	
2011\RT-Caravan,Town & Country	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2011\RT-Caravan,Town & Country	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\RT-Caravan,Town & Country	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\RT-Caravan,Town & Country	TPM -- Tire Pressure Monitor	√	√	√	√		
2011\RT-Caravan,Town & Country	CGW -- Central Gateway	√	√	√	√	√	0003
2011\RT-Caravan,Town & Country	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2011\RT-Caravan,Town & Country	SAS -- Steering Angle Sensor	√	√	√	√		
2011\RT-Caravan,Town & Country	RADIO -- Radio	√	√	√	√	√	
2011\RT-Caravan,Town & Country	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\RT-Caravan,Town & Country	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2011\RT-Caravan,Town & Country	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2011\RT-Caravan,Town & Country	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2011\RT-Caravan,Town & Country	DMFR -- Door Module Front Right	√	√	√	√	√	
2011\RT-Caravan,Town & Country	DMFL -- Door Module Front Left	√	√	√	√	√	
2011\RT-Caravan,Town & Country	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2011\RT-Caravan,Town & Country	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2011\RT-Caravan,Town & Country	PLGM -- Power Liftgate Module	√	√	√	√	√	
2011\RT-Caravan,Town & Country	FSM -- Fold Stow Module	√	√	√	√	√	
2011\RT-Caravan,Town & Country	SUNR -- Sunroof	√	√	√	√	√	
2011\RT-Caravan,Town & Country	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2011\RT-Caravan,Town & Country	AHBM -- Automatic High Beam	√	√	√	√		
2011\RT-Caravan,Town & Country	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2011\RT-Caravan,Town & Country	DVD -- DVD Changer	√	√	√	√		



2011\RT-Caravan,Town & Country	SDARV -- Satellite Video Receiver	√	√	√	√		
2011\RT-Caravan,Town & Country	AMP -- Amplifier	√	√	√	√		
2011\RT-Caravan,Town & Country	HFM -- Hands Free Module	√	√	√	√	√	
2011\RT-Caravan,Town & Country	VES2 -- Second Row Screen	√	√	√	√	√	
2011\RT-Caravan,Town & Country	VES3 -- Last Row Screen	√	√	√	√	√	
2011\RT-Caravan,Town & Country	HSM -- Heated Seat Module	√	√	√	√	√	
2011\RT-Caravan,Town & Country	BSM -- Blind Spot Module	√	√	√	√		
2011\RT-Caravan,Town & Country	PEM -- Passive Entry Module	√	√	√	√		
2011\WD-Durango	ECM -- Engine Control Module	√	√	√	√	√	
2011\WD-Durango	TCM -- Transmission Control Module	√	√	√	√		
2011\WD-Durango	DTCM -- Drive Train Control Module	√	√	√	√	√	
2011\WD-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2011\WD-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\WD-Durango	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\WD-Durango	TPM -- Tire Pressure Monitor	√	√	√	√		
2011\WD-Durango	CGW -- Central Gateway	√	√	√	√	√	0003
2011\WD-Durango	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2011\WD-Durango	SAS -- Steering Angle Sensor	√	√	√	√	√	
2011\WD-Durango	EPS -- Electric Power Steering	√	√	√	√		
2011\WD-Durango	PTS -- Parktronic	√	√	√	√	√	
2011\WD-Durango	RADIO -- Radio	√	√	√	√	√	
2011\WD-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\WD-Durango	ACC -- Adaptive Cruise Control	√	√	√	√		
2011\WD-Durango	DMFR -- Door Module Front Right	√	√	√	√	√	
2011\WD-Durango	DMFL -- Door Module Front Left	√	√	√	√	√	
2011\WD-Durango	ESM -- Electronic Shifter	√	√	√	√	√	
2011\WD-Durango	PLGM -- Power Liftgate Module	√	√	√	√	√	
2011\WD-Durango	AHLM -- Headlamp Leveling	√	√	√	√	√	
2011\WD-Durango	AHBM -- Automatic High Beam	√	√	√	√	√	
2011\WD-Durango	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2011\WD-Durango	SDARV -- Satellite Video Receiver	√	√	√	√		
2011\WD-Durango	AMP -- Amplifier	√	√	√	√		
2011\WD-Durango	HFM -- Hands Free Module	√	√	√	√	√	
2011\WD-Durango	VES3 -- Last Row Screen	√	√	√	√	√	
2011\WD-Durango	HSM -- Heated Seat Module	√	√	√	√	√	
2011\WD-Durango	BSM -- Blind Spot Module	√	√	√	√		
2011\WD-Durango	PEM -- Passive Entry Module	√	√	√	√		
2011\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	0041
2011\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2011\WK-Grand Cherokee	DTCM -- Drive Train Control Module	√	√	√	√	√	
2011\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2011\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2011\WK-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2011\WK-Grand Cherokee	TPM -- Tire Pressure Monitor	√	√	√	√		
2011\WK-Grand Cherokee	CGW -- Central Gateway	√	√	√	√	√	0003

2011\WK-Grand Cherokee	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2011\WK-Grand Cherokee	SAS -- Steering Angle Sensor	√	√	√	√	√	
2011\WK-Grand Cherokee	EPS -- Electric Power Steering	√	√	√	√		
2011\WK-Grand Cherokee	PTS -- Parktronic	√	√	√	√	√	
2011\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√	√	
2011\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2011\WK-Grand Cherokee	ACC -- Adaptive Cruise Control	√	√	√	√		
2011\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2011\WK-Grand Cherokee	DMFR -- Door Module Front Right	√	√	√	√	√	
2011\WK-Grand Cherokee	DMFL -- Door Module Front Left	√	√	√	√	√	
2011\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2011\WK-Grand Cherokee	PLGM -- Power Liftgate Module	√	√	√	√	√	
2011\WK-Grand Cherokee	AHLM -- Headlamp Leveling	√	√	√	√	√	
2011\WK-Grand Cherokee	AHBM -- Automatic High Beam	√	√	√	√	√	
2011\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2011\WK-Grand Cherokee	SDARV -- Satellite Video Receiver	√	√	√	√		
2011\WK-Grand Cherokee	AMP -- Amplifier	√	√	√	√		
2011\WK-Grand Cherokee	VES3 -- Last Row Screen	√	√	√	√	√	
2011\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2011\WK-Grand Cherokee	BSM -- Blind Spot Module	√	√	√	√		
2011\WK-Grand Cherokee	PEM -- Passive Entry Module	√	√	√	√		
2011\WK-Grand Cherokee	ASCM -- Air Suspension Control Module	√	√	√	√		
2011\WK-Grand Cherokee	ELSD -- Electronic Limited Slip Differential	√	√	√	√		
2012\D2-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0032, 0037, 0031
2012\D2-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2012\D2-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\D2-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\D2-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\D2-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	0003
2012\D2-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2012\D2-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2012\D2-Ram Truck	PTS -- Parktronic	√	√	√	√	√	
2012\D2-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2012\D2-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\D2-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\D2-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2012\D2-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2012\D2-Ram Truck	AMP -- Amplifier	√	√	√	√		
2012\D2-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2012\D2-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2012\D2-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2012\D2-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2012\DD-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0032, 0037, 0031
2012\DD-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2012\DD-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	

2012\DD-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\DD-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\DD-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\DD-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	0003
2012\DD-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2012\DD-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2012\DD-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2012\DD-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\DD-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\DD-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2012\DD-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2012\DD-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2012\DD-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2012\DD-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2012\DD-Ram Truck	DCU -- Dosing Control Unit	√					
2012\DJ-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0032, 0037, 0031
2012\DJ-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2012\DJ-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\DJ-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\DJ-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\DJ-Ram Truck	TPM -- Tire Pressure Monitor	√	√	√	√		
2012\DJ-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	0003
2012\DJ-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2012\DJ-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2012\DJ-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2012\DJ-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2012\DJ-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\DJ-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\DJ-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2012\DJ-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2012\DJ-Ram Truck	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2012\DJ-Ram Truck	AMP -- Amplifier	√	√	√	√		
2012\DJ-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2012\DJ-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2012\DJ-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2012\DJ-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2012\DP-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0032, 0037, 0031
2012\DP-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2012\DP-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2012\DP-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\DP-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\DP-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\DP-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	0003
2012\DP-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2012\DP-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		

2012\DP-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2012\DP-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\DP-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\DP-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2012\DP-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2012\DP-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2012\DP-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2012\DP-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2012\DP-Ram Truck	DCU -- Dosing Control Unit	√					
2012\DS-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2012\DS-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2012\DS-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\DS-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\DS-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\DS-Ram Truck	TPM -- Tire Pressure Monitor	√	√	√	√		
2012\DS-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	0003
2012\DS-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2012\DS-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2012\DS-Ram Truck	PTS -- Parktronic	√	√	√	√	√	
2012\DS-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2012\DS-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\DS-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\DS-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2012\DS-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2012\DS-Ram Truck	AMP -- Amplifier	√	√	√	√		
2012\DS-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	
2012\DS-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2012\DS-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2012\DS-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2012\DX-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0032, 0037, 0031
2012\DX-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2012\DX-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\DX-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\DX-Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\DX-Ram Truck	TPM -- Tire Pressure Monitor	√	√	√	√		
2012\DX-Ram Truck	CGW -- Central Gateway	√	√	√	√	√	0003
2012\DX-Ram Truck	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2012\DX-Ram Truck	SAS -- Steering Angle Sensor	√	√	√	√		
2012\DX-Ram Truck	PTS -- Parktronic	√	√	√	√	√	
2012\DX-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2012\DX-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\DX-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\DX-Ram Truck	DMFR -- Door Module Front Right	√	√	√	√	√	
2012\DX-Ram Truck	DMFL -- Door Module Front Left	√	√	√	√	√	
2012\DX-Ram Truck	HFM -- Hands Free Module	√	√	√	√	√	

2012\DX-Ram Truck	VES3 -- Last Row Screen	√	√	√	√	√	
2012\DX-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2012\DX-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2012\FF-500	ECM -- Engine Control Module	√	√	√	√	√	
2012\FF-500	TCM -- Transmission Control Module	√	√	√	√	√	
2012\FF-500	ABS -- Anti Lock Brakes	√	√	√	√	√	
2012\FF-500	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\FF-500	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2012\FF-500	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2012\FF-500	BCM -- Body Controller	√	√	√	√	√	
2012\FF-500	EPS -- Electric Power Steering	√	√	√	√		
2012\FF-500	PTS -- Parktronics	√	√	√	√		
2012\FF-500	RADIO -- Radio	√	√	√	√	√	
2012\FF-500	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\FF-500	CTM -- Convergence Telematic Module	√	√	√	√	√	
2012\FF-500	VTM -- Vehicle Tracking Module	√	√	√	√		
2012\J8-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2012\J8-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2012\J8-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\J8-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\J8-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2012\J8-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2012\J8-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2012\J8-Wrangler	RADIO -- Radio	√	√	√	√	√	
2012\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\JC-Journey	ECM -- Engine Control Module	√	√	√	√	√	0041
2012\JC-Journey	TCM -- Transmission Control Module	√	√	√	√	√	
2012\JC-Journey	DTCM -- Drive Train Control Module	√	√	√	√	√	
2012\JC-Journey	ABS -- Anti Lock Brakes	√	√	√	√	√	
2012\JC-Journey	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\JC-Journey	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2012\JC-Journey	TPM -- Tire Pressure Monitor	√	√	√	√		
2012\JC-Journey	BCM -- Body Controller	√	√	√	√	√	
2012\JC-Journey	TGW -- Telematic Gateway Radio	√	√	√	√		
2012\JC-Journey	RFH -- Radio Frequency Hub	√	√	√	√	√	
2012\JC-Journey	PTS -- Parktronics	√	√	√	√	√	
2012\JC-Journey	ICS -- Integrated Center Stack	√	√	√	√	√	
2012\JC-Journey	SCCM -- Steering Column Control Module	√	√	√	√		
2012\JC-Journey	DDM -- Driver Door Module	√	√	√	√	√	
2012\JC-Journey	PDM -- Passenger Door Module	√	√	√	√	√	
2012\JC-Journey	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2012\JC-Journey	AMP -- Amplifier	√	√	√	√		
2012\JC-Journey	HFM -- Hands Free Module	√	√	√	√		
2012\JC-Journey	VES3 -- Last Row Screen	√	√	√	√	√	

2012\JC-Journey	HSM -- Heated Seat Module	√	√	√	√	√	
2012\JC-Journey	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2012\JF-Freemont	ECM -- Engine Control Module	√	√	√	√	√	0041
2012\JF-Freemont	TCM -- Transmission Control Module	√	√	√	√	√	
2012\JF-Freemont	DTCM -- Drive Train Control Module	√	√	√	√	√	
2012\JF-Freemont	ABS -- Anti Lock Brakes	√	√	√	√	√	
2012\JF-Freemont	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\JF-Freemont	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2012\JF-Freemont	TPM -- Tire Pressure Monitor	√	√	√	√		
2012\JF-Freemont	BCM -- Body Controller	√	√	√	√	√	
2012\JF-Freemont	TGW -- Telematic Gateway Radio	√	√	√	√		
2012\JF-Freemont	RFH -- Radio Frequency Hub	√	√	√	√	√	
2012\JF-Freemont	PTS -- Parktronics	√	√	√	√	√	
2012\JF-Freemont	ICS -- Integrated Center Stack	√	√	√	√	√	
2012\JF-Freemont	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\JF-Freemont	SCCM -- Steering Column Control Module	√	√	√	√		
2012\JF-Freemont	DDM -- Driver Door Module	√	√	√	√	√	
2012\JF-Freemont	PDM -- Passenger Door Module	√	√	√	√	√	
2012\JF-Freemont	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2012\JF-Freemont	AMP -- Amplifier	√	√	√	√		
2012\JF-Freemont	HFM -- Hands Free Module	√	√	√	√		
2012\JF-Freemont	VES3 -- Last Row Screen	√	√	√	√	√	
2012\JF-Freemont	HSM -- Heated Seat Module	√	√	√	√	√	
2012\JF-Freemont	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2012\JK-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2012\JK-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2012\JK-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\JK-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\JK-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2012\JK-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2012\JK-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2012\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\JK-Wrangler	ESM -- Electronic Shifter	√	√	√	√	√	
2012\JK-Wrangler	ASBS -- Automatic Sway Bar System	√	√	√	√		
2012\JK-Wrangler	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2012\JK-Wrangler	AMP -- Amplifier	√	√	√	√		
2012\JK-Wrangler	HFM -- Hands Free Module	√	√	√	√	√	
2012\JS-Avenger,Sebring,Convertible-Sedan	ECM -- Engine Control Module	√	√	√	√	√	
2012\JS-Avenger,Sebring,Convertible-Sedan	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\JS-Avenger,Sebring,Convertible-Sedan	ORC -- AirBag/Occupant Restraint	√	√	√	√		

2012\JS-Avenger,Sebring,Convertible-Sedan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\JS-Avenger,Sebring,Convertible-Sedan	CGW -- Central Gateway	√	√	√	√	√	0003
2012\JS-Avenger,Sebring,Convertible-Sedan	WCM/TPMS -- Wireless Control	√	√	√	√		
2012\JS-Avenger,Sebring,Convertible-Sedan	SAS -- Steering Angle Sensor	√	√	√	√		
2012\JS-Avenger,Sebring,Convertible-Sedan	RADIO -- Radio	√	√	√	√	√	
2012\JS-Avenger,Sebring,Convertible-Sedan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\JS-Avenger,Sebring,Convertible-Sedan	DDM -- Driver Door Module	√	√	√	√	√	
2012\JS-Avenger,Sebring,Convertible-Sedan	PDM -- Passenger Door Module	√	√	√	√	√	
2012\JS-Avenger,Sebring,Convertible-Sedan	PTCM -- Power Top Control Module	√	√	√	√		
2012\JS-Avenger,Sebring,Convertible-Sedan	AMP -- Amplifier	√	√	√	√		
2012\JS-Avenger,Sebring,Convertible-Sedan	HFM -- Hands Free Module	√	√	√	√	√	
2012\KA-Nitro	ECM -- Engine Control Module	√	√	√	√	√	
2012\KA-Nitro	TCM -- Transmission Control Module	√	√	√	√		
2012\KA-Nitro	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\KA-Nitro	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\KA-Nitro	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\KA-Nitro	CGW -- Central Gateway	√	√	√	√	√	0003
2012\KA-Nitro	WCM/TPMS -- Wireless Control	√	√	√	√		
2012\KA-Nitro	SAS -- Steering Angle Sensor	√	√	√	√		
2012\KA-Nitro	PTS -- Parktronic	√	√	√	√	√	
2012\KA-Nitro	RADIO -- Radio	√	√	√	√	√	
2012\KA-Nitro	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\KA-Nitro	DMFR -- Door Module Front Right	√	√	√	√	√	
2012\KA-Nitro	DMFL -- Door Module Front Left	√	√	√	√	√	
2012\KA-Nitro	ESM -- Electronic Shifter	√	√	√	√	√	
2012\KA-Nitro	OCM -- Occupant Classification	√	√	√	√		
2012\KA-Nitro	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2012\KA-Nitro	AMP -- Amplifier	√	√	√	√		
2012\KA-Nitro	HFM -- Hands Free Module	√	√	√	√	√	
2012\KK-Liberty	ECM -- Engine Control Module	√	√	√	√	√	
2012\KK-Liberty	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\KK-Liberty	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\KK-Liberty	CGW -- Central Gateway	√	√	√	√	√	0003
2012\KK-Liberty	WCM/TPMS -- Wireless Control	√	√	√	√		
2012\KK-Liberty	SAS -- Steering Angle Sensor	√	√	√	√		

2012\KK-Liberty	PTS -- Parktronics	√	√	√	√	√	
2012\KK-Liberty	RADIO -- Radio	√	√	√	√	√	
2012\KK-Liberty	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\KK-Liberty	DMFR -- Door Module Front Right	√	√	√	√	√	
2012\KK-Liberty	DMFL -- Door Module Front Left	√	√	√	√	√	
2012\KK-Liberty	ESM -- Electronic Shifter	√	√	√	√	√	
2012\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2012\KK-Liberty	OCM -- Occupant Classification	√	√	√	√		
2012\KK-Liberty	SUNR -- Sunroof	√	√	√	√		
2012\KK-Liberty	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2012\KK-Liberty	AMP -- Amplifier	√	√	√	√		
2012\KK-Liberty	HFM -- Hands Free Module	√	√	√	√	√	
2012\LC-Challenger	ECM -- Engine Control Module	√	√	√	√	√	
2012\LC-Challenger	TCM -- Transmission Control Module	√	√	√	√		
2012\LC-Challenger	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2012\LC-Challenger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\LC-Challenger	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\LC-Challenger	TPM -- Tire Pressure Monitor	√	√	√	√		
2012\LC-Challenger	CGW -- Central Gateway	√	√	√	√	√	
2012\LC-Challenger	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2012\LC-Challenger	SAS -- Steering Angle Sensor	√	√	√	√	√	
2012\LC-Challenger	EPS -- Electric Power Steering	√	√	√	√		
2012\LC-Challenger	RADIO -- Radio	√	√	√	√	√	
2012\LC-Challenger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\LC-Challenger	DDM -- Driver Door Module	√	√	√	√	√	
2012\LC-Challenger	PDM -- Passenger Door Module	√	√	√	√	√	
2012\LC-Challenger	ESM -- Electronic Shifter	√	√	√	√	√	
2012\LC-Challenger	SUNR -- Sunroof	√	√	√	√	√	
2012\LC-Challenger	EOM -- Electronic Overhead	√	√	√	√		
2012\LC-Challenger	AMP -- Amplifier	√	√	√	√		
2012\LC-Challenger	HFM -- Hands Free Module	√	√	√	√	√	
2012\LC-Challenger	HSM -- Heated Seat Module	√	√	√	√	√	
2012\LC-Challenger	ADCM -- Active Damping Control Module	√	√	√	√		
2012\LD-Charger	ECM -- Engine Control Module	√	√	√	√	√	
2012\LD-Charger	TCM -- Transmission Control Module	√	√	√	√		
2012\LD-Charger	DTCM -- Drive Train Control Module	√	√	√	√	√	
2012\LD-Charger	ABS -- Anti Lock Brakes	√	√	√	√	√	
2012\LD-Charger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\LD-Charger	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2012\LD-Charger	TPM -- Tire Pressure Monitor	√	√	√	√		
2012\LD-Charger	BCM -- Body Controller	√	√	√	√	√	
2012\LD-Charger	TGW -- Telematic Gateway Radio	√	√	√	√		
2012\LD-Charger	RFH -- Radio Frequency Hub	√	√	√	√	√	
2012\LD-Charger	EPS -- Electric Power Steering	√	√	√	√		



2012\LD-Charger	PTS -- Parktronics	√	√	√	√	√	
2012\LD-Charger	ICS -- Integrated Center Stack	√	√	√	√	√	
2012\LD-Charger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\LD-Charger	ACC -- Adaptive Cruise Control	√	√	√	√		
2012\LD-Charger	SCCM -- Steering Column Control Module	√	√	√	√		
2012\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\LD-Charger	DDM -- Driver Door Module	√	√	√	√	√	
2012\LD-Charger	PDM -- Passenger Door Module	√	√	√	√	√	
2012\LD-Charger	ESM -- Electronic Shifter	√	√	√	√	√	
2012\LD-Charger	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2012\LD-Charger	AMP -- Amplifier	√	√	√	√		
2012\LD-Charger	HFM -- Hands Free Module	√	√	√	√		
2012\LD-Charger	HSM -- Heated Seat Module	√	√	√	√	√	
2012\LD-Charger	BSM -- Blind Spot Module	√	√	√	√		
2012\LD-Charger	ADCM -- Active Damping Control Module	√	√	√	√		
2012\LD-Charger	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	ECM -- Engine Control Module	√	√	√	√	√	0041
2012\LX-300,Charger,Magnum,Grand Voyager	TCM -- Transmission Control Module	√	√	√	√		
2012\LX-300,Charger,Magnum,Grand Voyager	DTCM -- Drive Train Control Module	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	ABS -- Anti Lock Brakes	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\LX-300,Charger,Magnum,Grand Voyager	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	TPM -- Tire Pressure Monitor	√	√	√	√		
2012\LX-300,Charger,Magnum,Grand Voyager	BCM -- Body Controller	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	TGW -- Telematic Gateway Radio	√	√	√	√		
2012\LX-300,Charger,Magnum,Grand Voyager	RFH -- Radio Frequency Hub	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	EPS -- Electric Power Steering	√	√	√	√		
2012\LX-300,Charger,Magnum,Grand Voyager	ICS -- Integrated Center Stack	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	AFLS -- Adaptive Front Lighting System	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	ACC -- Adaptive Cruise Control	√	√	√	√		
2012\LX-300,Charger,Magnum,Grand Voyager	SCCM -- Steering Column Control Module	√	√	√	√		

2012\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√		
2012\LX-300,Charger,Magnum,Grand Voyager	HFM -- Hands Free Module	√	√	√	√		
2012\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2012\LX-300,Charger,Magnum,Grand Voyager	BSM -- Blind Spot Module	√	√	√	√		
2012\LX-300,Charger,Magnum,Grand Voyager	ADCM -- Active Damping Control Module	√	√	√	√		
2012\MK-Compass,Patriot	ECM -- Engine Control Module	√	√	√	√	√	0012, 0036, 0053
2012\MK-Compass,Patriot	TCM -- Transmission Control Module	√	√	√	√	√	
2012\MK-Compass,Patriot	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\MK-Compass,Patriot	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\MK-Compass,Patriot	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\MK-Compass,Patriot	CGW -- Central Gateway	√	√	√	√	√	0003
2012\MK-Compass,Patriot	WCM/TPMS -- Wireless Control	√	√	√	√		
2012\MK-Compass,Patriot	SAS -- Steering Angle Sensor	√	√	√	√		
2012\MK-Compass,Patriot	RADIO -- Radio	√	√	√	√	√	
2012\MK-Compass,Patriot	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\MK-Compass,Patriot	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2012\MK-Compass,Patriot	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2012\MK-Compass,Patriot	AMP -- Amplifier	√	√	√	√		
2012\MK-Compass,Patriot	HFM -- Hands Free Module	√	√	√	√	√	
2012\ND-Dakota	ECM -- Engine Control Module	√	√	√	√	√	
2012\ND-Dakota	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\ND-Dakota	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\ND-Dakota	CGW -- Central Gateway	√	√	√	√	√	
2012\ND-Dakota	WCM/TPMS -- Wireless Control	√	√	√	√		
2012\ND-Dakota	RADIO -- Radio	√	√	√	√	√	
2012\ND-Dakota	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\ND-Dakota	EOM -- Electronic Overhead	√	√	√	√		
2012\ND-Dakota	AMP -- Amplifier	√	√	√	√		
2012\PF-Dart	ECM -- Engine Control Module	√	√	√	√	√	
2012\PF-Dart	TCM -- Transmission Control Module	√	√	√	√	√	
2012\PF-Dart	ABS -- Anti Lock Brakes	√	√	√	√	√	

2012\PF-Dart	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\PF-Dart	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2012\PF-Dart	BCM -- Body Controller	√	√	√	√	√	
2012\PF-Dart	RFH -- Radio Frequency Hub	√	√	√	√	√	
2012\PF-Dart	EPS -- Electric Power Steering	√	√	√	√		
2012\PF-Dart	ICS -- Integrated Center Stack	√	√	√	√	√	
2012\PF-Dart	RADIO -- Radio	√	√	√	√	√	
2012\PF-Dart	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\PF-Dart	SCCM -- Steering Column Control Module	√	√	√	√		
2012\PF-Dart	PAM -- Park Assist Module	√	√	√	√		
2012\PF-Dart	ESM -- Electronic Shifter	√	√	√	√		
2012\PF-Dart	OCM -- Occupant Classification	√	√	√	√		
2012\PF-Dart	AMP -- Amplifier	√	√	√	√		
2012\PF-Dart	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2012\PF-Dart	CTM -- Convergence Telematic Module	√	√	√	√		
2012\PF-Dart	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2012\PF-Dart	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	
2012\PF-Dart	EDM -- External Disc Module	√	√	√		√	
2012\PM-Caliber	ECM -- Engine Control Module	√	√	√	√	√	0012, 0036, 0053
2012\PM-Caliber	TCM -- Transmission Control Module	√	√	√	√	√	
2012\PM-Caliber	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2012\PM-Caliber	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\PM-Caliber	CGW -- Central Gateway	√	√	√	√	√	0003
2012\PM-Caliber	WCM/TPMS -- Wireless Control	√	√	√	√		
2012\PM-Caliber	SAS -- Steering Angle Sensor	√	√	√	√		
2012\PM-Caliber	RADIO -- Radio	√	√	√	√	√	
2012\PM-Caliber	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\PM-Caliber	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2012\PM-Caliber	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2012\PM-Caliber	AMP -- Amplifier	√	√	√	√		
2012\PM-Caliber	HFM -- Hands Free Module	√	√	√	√	√	
2012\RM-Routan	ECM -- Engine Control Module	√	√	√	√	√	
2012\RM-Routan	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0001, 0005, 0002
2012\RM-Routan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\RM-Routan	CGW -- Central Gateway	√	√	√	√	√	0003
2012\RM-Routan	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2012\RM-Routan	SAS -- Steering Angle Sensor	√	√	√	√		
2012\RM-Routan	PTS -- Parktronics	√	√	√	√	√	
2012\RM-Routan	RADIO -- Radio	√	√	√	√	√	
2012\RM-Routan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\RM-Routan	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2012\RM-Routan	DMRR -- Rear Door Module (Right)	√	√	√	√	√	

2012\RM-Routan	DMFR -- Door Module Front Right	√	√	√	√	√	
2012\RM-Routan	DMFL -- Door Module Front Left	√	√	√	√	√	
2012\RM-Routan	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2012\RM-Routan	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2012\RM-Routan	PLGM -- Power Liftgate Module	√	√	√	√	√	
2012\RM-Routan	FSM -- Fold Stow Module	√	√	√	√	√	
2012\RM-Routan	SUNR -- Sunroof	√	√	√	√	√	
2012\RM-Routan	DVD -- DVD Changer	√	√	√	√		
2012\RM-Routan	AMP -- Amplifier	√	√	√	√		
2012\RM-Routan	HFM -- Hands Free Module	√	√	√	√	√	
2012\RM-Routan	VES2 -- Second Row Screen	√	√	√	√	√	
2012\RM-Routan	VES3 -- Last Row Screen	√	√	√	√	√	
2012\RM-Routan	HSM -- Heated Seat Module	√	√	√	√	√	
2012\RM-Routan	BSM -- Blind Spot Module	√	√	√	√		
2012\RM-Routan	PEM -- Passive Entry Module	√	√	√	√		
2012\RT-Caravan,Town & Country	ECM -- Engine Control Module	√	√	√	√	√	
2012\RT-Caravan,Town & Country	TCM -- Transmission Control Module	√	√	√	√	√	
2012\RT-Caravan,Town & Country	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0001, 0005, 0002
2012\RT-Caravan,Town & Country	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\RT-Caravan,Town & Country	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\RT-Caravan,Town & Country	TPM -- Tire Pressure Monitor	√	√	√	√		
2012\RT-Caravan,Town & Country	CGW -- Central Gateway	√	√	√	√	√	0003
2012\RT-Caravan,Town & Country	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2012\RT-Caravan,Town & Country	SAS -- Steering Angle Sensor	√	√	√	√		
2012\RT-Caravan,Town & Country	PTS -- Parktronics	√	√	√	√	√	
2012\RT-Caravan,Town & Country	RADIO -- Radio	√	√	√	√	√	
2012\RT-Caravan,Town & Country	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\RT-Caravan,Town & Country	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\RT-Caravan,Town & Country	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2012\RT-Caravan,Town & Country	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2012\RT-Caravan,Town & Country	DMFL -- Door Module Front Left	√	√	√	√	√	
2012\RT-Caravan,Town & Country	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2012\RT-Caravan,Town & Country	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2012\RT-Caravan,Town & Country	PLGM -- Power Liftgate Module	√	√	√	√	√	
2012\RT-Caravan,Town & Country	FSM -- Fold Stow Module	√	√	√	√	√	
2012\RT-Caravan,Town & Country	SUNR -- Sunroof	√	√	√	√	√	
2012\RT-Caravan,Town & Country	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2012\RT-Caravan,Town & Country	AHBM -- Automatic High Beam	√	√	√	√		
2012\RT-Caravan,Town & Country	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2012\RT-Caravan,Town & Country	DVD -- DVD Changer	√	√	√	√		
2012\RT-Caravan,Town & Country	AMP -- Amplifier	√	√	√	√		
2012\RT-Caravan,Town & Country	HFM -- Hands Free Module	√	√	√	√	√	
2012\RT-Caravan,Town & Country	VES2 -- Second Row Screen	√	√	√	√	√	
2012\RT-Caravan,Town & Country	VES3 -- Last Row Screen	√	√	√	√	√	
2012\RT-Caravan,Town & Country	HSM -- Heated Seat Module	√	√	√	√	√	

2012\RT-Caravan,Town & Country	BSM -- Blind Spot Module	√	√	√	√		
2012\RT-Caravan,Town & Country	PEM -- Passive Entry Module	√	√	√	√		
2012\RT-Caravan,Town & Country	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2012\WD-Durango	ECM -- Engine Control Module	√	√	√	√	√	
2012\WD-Durango	TCM -- Transmission Control Module	√	√	√	√		
2012\WD-Durango	DTCM -- Drive Train Control Module	√	√	√	√	√	
2012\WD-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2012\WD-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\WD-Durango	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\WD-Durango	TPM -- Tire Pressure Monitor	√	√	√	√		
2012\WD-Durango	CGW -- Central Gateway	√	√	√	√	√	0003
2012\WD-Durango	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2012\WD-Durango	SAS -- Steering Angle Sensor	√	√	√	√	√	
2012\WD-Durango	EPS -- Electric Power Steering	√	√	√	√		
2012\WD-Durango	PTS -- Parktronic	√	√	√	√	√	
2012\WD-Durango	RADIO -- Radio	√	√	√	√	√	
2012\WD-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\WD-Durango	ACC -- Adaptive Cruise Control	√	√	√	√		
2012\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\WD-Durango	DMFR -- Door Module Front Right	√	√	√	√	√	
2012\WD-Durango	DMFL -- Door Module Front Left	√	√	√	√	√	
2012\WD-Durango	ESM -- Electronic Shifter	√	√	√	√	√	
2012\WD-Durango	PLGM -- Power Liftgate Module	√	√	√	√	√	
2012\WD-Durango	AHLM -- Headlamp Leveling	√	√	√	√	√	
2012\WD-Durango	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2012\WD-Durango	AMP -- Amplifier	√	√	√	√		
2012\WD-Durango	HFM -- Hands Free Module	√	√	√	√	√	
2012\WD-Durango	VES3 -- Last Row Screen	√	√	√	√	√	
2012\WD-Durango	HSM -- Heated Seat Module	√	√	√	√	√	
2012\WD-Durango	BSM -- Blind Spot Module	√	√	√	√		
2012\WD-Durango	PEM -- Passive Entry Module	√	√	√	√		
2012\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	0041
2012\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2012\WK-Grand Cherokee	DTCM -- Drive Train Control Module	√	√	√	√	√	
2012\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2012\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2012\WK-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2012\WK-Grand Cherokee	TPM -- Tire Pressure Monitor	√	√	√	√		
2012\WK-Grand Cherokee	CGW -- Central Gateway	√	√	√	√	√	0003
2012\WK-Grand Cherokee	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2012\WK-Grand Cherokee	SAS -- Steering Angle Sensor	√	√	√	√	√	
2012\WK-Grand Cherokee	EPS -- Electric Power Steering	√	√	√	√		
2012\WK-Grand Cherokee	PTS -- Parktronic	√	√	√	√	√	
2012\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√	√	

2012\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2012\WK-Grand Cherokee	ACC -- Adaptive Cruise Control	√	√	√	√		
2012\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2012\WK-Grand Cherokee	DMFR -- Door Module Front Right	√	√	√	√	√	
2012\WK-Grand Cherokee	DMFL -- Door Module Front Left	√	√	√	√	√	
2012\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2012\WK-Grand Cherokee	PLGM -- Power Liftgate Module	√	√	√	√	√	
2012\WK-Grand Cherokee	AHLM -- Headlamp Leveling	√	√	√	√	√	
2012\WK-Grand Cherokee	AHBM -- Automatic High Beam	√	√	√	√	√	
2012\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2012\WK-Grand Cherokee	AMP -- Amplifier	√	√	√	√		
2012\WK-Grand Cherokee	HFM -- Hands Free Module	√	√	√	√	√	
2012\WK-Grand Cherokee	VES3 -- Last Row Screen	√	√	√	√	√	
2012\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2012\WK-Grand Cherokee	BSM -- Blind Spot Module	√	√	√	√		
2012\WK-Grand Cherokee	PEM -- Passive Entry Module	√	√	√	√		
2012\WK-Grand Cherokee	ADCM -- Active Damping Control Module	√	√	√	√		
2012\WK-Grand Cherokee	ASCM -- Air Suspension Control Module	√	√	√	√		
2012\WK-Grand Cherokee	ELSD -- Electronic Limited Slip Differential	√	√	√	√		
2013\D2-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2013\D2-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2013\D2-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013\D2-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2013\D2-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2013\D2-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2013\D2-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2013\D2-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2013\D2-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2013\D2-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2013\D2-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\D2-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2013\D2-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\D2-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2013\D2-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2013\D2-Ram Truck	AMP -- Amplifier	√	√	√	√		
2013\D2-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2013\D2-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2013\D2-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2013\D2-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2013\D2-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2013\D2-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2013\D2-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2013\DD-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2013\DD-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2013\DD-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	

2013\DD-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013\DD-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2013\DD-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2013\DD-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2013\DD-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2013\DD-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2013\DD-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2013\DD-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2013\DD-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\DD-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2013\DD-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\DD-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2013\DD-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2013\DD-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2013\DD-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2013\DD-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2013\DD-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2013\DD-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2013\DD-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2013\DJ-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2013\DJ-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2013\DJ-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2013\DJ-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013\DJ-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2013\DJ-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2013\DJ-Ram Truck	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\DJ-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2013\DJ-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2013\DJ-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2013\DJ-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2013\DJ-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2013\DJ-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\DJ-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2013\DJ-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\DJ-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2013\DJ-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2013\DJ-Ram Truck	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2013\DJ-Ram Truck	AMP -- Amplifier	√	√	√	√		
2013\DJ-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2013\DJ-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2013\DJ-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2013\DJ-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2013\DJ-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2013\DJ-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2013\DJ-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	

2013\DP-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2013\DP-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2013\DP-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2013\DP-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013\DP-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2013\DP-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2013\DP-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2013\DP-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2013\DP-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2013\DP-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2013\DP-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\DP-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2013\DP-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\DP-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2013\DP-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2013\DP-Ram Truck	AMP -- Amplifier	√	√	√	√		
2013\DP-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2013\DP-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2013\DP-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2013\DP-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2013\DP-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2013\DP-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2013\DS-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2013\DS-Ram Truck	TCM -- Transmission Control Module	√	√	√	√		
2013\DS-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2013\DS-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013\DS-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2013\DS-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2013\DS-Ram Truck	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\DS-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2013\DS-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2013\DS-Ram Truck	EPS -- Electric Power Steering	√	√	√	√		
2013\DS-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2013\DS-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2013\DS-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2013\DS-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\DS-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2013\DS-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\DS-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2013\DS-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2013\DS-Ram Truck	ESM -- Electronic Shifter	√	√	√	√		
2013\DS-Ram Truck	AMP -- Amplifier	√	√	√	√		
2013\DS-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2013\DS-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2013\DS-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		



2013\DS-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2013\DX-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2013\DX-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2013\DX-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013\DX-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2013\DX-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2013\DX-Ram Truck	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\DX-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2013\DX-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2013\DX-Ram Truck	EPS -- Electric Power Steering	√	√	√	√		
2013\DX-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2013\DX-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2013\DX-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2013\DX-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\DX-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2013\DX-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\DX-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2013\DX-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2013\DX-Ram Truck	ESM -- Electronic Shifter	√	√	√	√		
2013\DX-Ram Truck	AMP -- Amplifier	√	√	√	√		
2013\DX-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2013\DX-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2013\DX-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2013\DX-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2013\DX-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2013\DX-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2013\DX-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2013\FF-500	ECM -- Engine Control Module	√	√	√	√	√	
2013\FF-500	TCM -- Transmission Control Module	√	√	√	√	√	
2013\FF-500	ABS -- Anti Lock Brakes	√	√	√	√		
2013\FF-500	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\FF-500	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2013\FF-500	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2013\FF-500	BCM -- Body Controller	√	√	√	√	√	
2013\FF-500	EPS -- Electric Power Steering	√	√	√	√		
2013\FF-500	PTS -- Parktronics	√	√	√	√		
2013\FF-500	RADIO -- Radio	√	√	√	√	√	
2013\FF-500	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\FF-500	EVCU -- Electronic Vehicle Control Unit	√	√	√	√	√	
2013\FF-500	ESM -- Electronic Shifter	√	√	√			
2013\FF-500	EAC -- Electric A/C Compressor	√	√	√	√		
2013\FF-500	OBCM -- On Board Charging Module	√	√	√	√		
2013\FF-500	CTM -- Convergence Telematic Module	√	√	√	√	√	
2013\FF-500	VTM -- Vehicle Tracking Module	√	√	√	√		
2013\FF-500	RBC -- Regenerative Brake Controller	√	√	√	√		

2013\FF-500	PIM -- Power Inverter Module	√	√	√	√		
2013\J8-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2013\J8-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2013\J8-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2013\J8-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2013\J8-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2013\J8-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2013\J8-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2013\J8-Wrangler	RADIO -- Radio	√	√	√	√	√	
2013\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\J8-Wrangler	ESM -- Electronic Shifter	√	√	√	√	√	
2013\JC-Journey	ECM -- Engine Control Module	√	√	√	√	√	0041
2013\JC-Journey	TCM -- Transmission Control Module	√	√	√	√	√	
2013\JC-Journey	DTCM -- Drive Train Control Module	√	√	√	√	√	
2013\JC-Journey	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013\JC-Journey	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\JC-Journey	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2013\JC-Journey	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\JC-Journey	BCM -- Body Controller	√	√	√	√	√	
2013\JC-Journey	TGW -- Telematic Gateway Radio	√	√	√	√		
2013\JC-Journey	RFH -- Radio Frequency Hub	√	√	√	√	√	
2013\JC-Journey	PTS -- Parktronics	√	√	√	√	√	
2013\JC-Journey	ICS -- Integrated Center Stack	√	√	√	√	√	
2013\JC-Journey	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\JC-Journey	SCCM -- Steering Column Control Module	√	√	√	√		
2013\JC-Journey	DDM -- Driver Door Module	√	√	√	√	√	
2013\JC-Journey	PDM -- Passenger Door Module	√	√	√	√	√	
2013\JC-Journey	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2013\JC-Journey	AMP -- Amplifier	√	√	√	√		
2013\JC-Journey	HFM -- Hands Free Module	√	√	√	√		
2013\JC-Journey	VES3 -- Last Row Screen	√	√	√	√	√	
2013\JC-Journey	HSM -- Heated Seat Module	√	√	√	√	√	
2013\JC-Journey	VTM -- Vehicle Tracking Module	√	√	√	√		
2013\JF-Freemont	ECM -- Engine Control Module	√	√	√	√	√	0041
2013\JF-Freemont	TCM -- Transmission Control Module	√	√	√	√	√	
2013\JF-Freemont	DTCM -- Drive Train Control Module	√	√	√	√	√	
2013\JF-Freemont	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013\JF-Freemont	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\JF-Freemont	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2013\JF-Freemont	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\JF-Freemont	BCM -- Body Controller	√	√	√	√	√	
2013\JF-Freemont	TGW -- Telematic Gateway Radio	√	√	√	√		
2013\JF-Freemont	RFH -- Radio Frequency Hub	√	√	√	√	√	
2013\JF-Freemont	PTS -- Parktronics	√	√	√	√	√	

2013\JF-Freemont	ICS -- Integrated Center Stack	√	√	√	√	√	
2013\JF-Freemont	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\JF-Freemont	SCCM -- Steering Column Control Module	√	√	√	√		
2013\JF-Freemont	DDM -- Driver Door Module	√	√	√	√	√	
2013\JF-Freemont	PDM -- Passenger Door Module	√	√	√	√	√	
2013\JF-Freemont	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2013\JF-Freemont	AMP -- Amplifier	√	√	√	√		
2013\JF-Freemont	HFM -- Hands Free Module	√	√	√	√		
2013\JF-Freemont	VES3 -- Last Row Screen	√	√	√	√	√	
2013\JF-Freemont	HSM -- Heated Seat Module	√	√	√	√	√	
2013\JF-Freemont	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2013\JF-Freemont	VTM -- Vehicle Tracking Module	√	√	√	√		
2013\JK-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2013\JK-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2013\JK-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2013\JK-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2013\JK-Wrangler	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\JK-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2013\JK-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2013\JK-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2013\JK-Wrangler	RADIO -- Radio	√	√	√	√	√	
2013\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\JK-Wrangler	ESM -- Electronic Shifter	√	√	√	√	√	
2013\JK-Wrangler	ASBS -- Automatic Sway Bar System	√	√	√	√		
2013\JK-Wrangler	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2013\JK-Wrangler	AMP -- Amplifier	√	√	√	√		
2013\JS-Avenger,Sebring,Convertible-Sedan	ECM -- Engine Control Module	√	√	√	√	√	
2013\JS-Avenger,Sebring,Convertible-Sedan	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2013\JS-Avenger,Sebring,Convertible-Sedan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\JS-Avenger,Sebring,Convertible-Sedan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2013\JS-Avenger,Sebring,Convertible-Sedan	CGW -- Central Gateway	√	√	√	√	√	0003
2013\JS-Avenger,Sebring,Convertible-Sedan	WCM/TPMS -- Wireless Control	√	√	√	√		
2013\JS-Avenger,Sebring,Convertible-Sedan	SAS -- Steering Angle Sensor	√	√	√	√		
2013\JS-Avenger,Sebring,Convertible-Sedan	RADIO -- Radio	√	√	√	√	√	
2013\JS-Avenger,Sebring,Convertible-Sedan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	

2013\JS-Avenger,Sebring,Convertible-Sedan	DDM -- Driver Door Module	√	√	√	√	√	
2013\JS-Avenger,Sebring,Convertible-Sedan	PDM -- Passenger Door Module	√	√	√	√	√	
2013\JS-Avenger,Sebring,Convertible-Sedan	PTCM -- Power Top Control Module	√	√	√	√		
2013\JS-Avenger,Sebring,Convertible-Sedan	AMP -- Amplifier	√	√	√	√		
2013\JS-Avenger,Sebring,Convertible-Sedan	HFM -- Hands Free Module	√	√	√	√	√	
2013\KK-Liberty	ECM -- Engine Control Module	√	√	√	√	√	
2013\KK-Liberty	TCM -- Transmission Control Module	√	√	√	√		
2013\KK-Liberty	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2013\KK-Liberty	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2013\KK-Liberty	CGW -- Central Gateway	√	√	√	√	√	0003
2013\KK-Liberty	WCM/TPMS -- Wireless Control	√	√	√	√		
2013\KK-Liberty	SAS -- Steering Angle Sensor	√	√	√	√		
2013\KK-Liberty	PTS -- Parktronics	√	√	√	√	√	
2013\KK-Liberty	RADIO -- Radio	√	√	√	√	√	
2013\KK-Liberty	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\KK-Liberty	DMFR -- Door Module Front Right	√	√	√	√	√	
2013\KK-Liberty	DMFL -- Door Module Front Left	√	√	√	√	√	
2013\KK-Liberty	ESM -- Electronic Shifter	√	√	√	√	√	
2013\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2013\KK-Liberty	OCM -- Occupant Classification	√	√	√	√		
2013\KK-Liberty	SUNR -- Sunroof	√	√	√	√		
2013\KK-Liberty	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2013\KK-Liberty	AMP -- Amplifier	√	√	√	√		
2013\KK-Liberty	HFM -- Hands Free Module	√	√	√	√	√	
2013\LC-Challenger	ECM -- Engine Control Module	√	√	√	√	√	
2013\LC-Challenger	TCM -- Transmission Control Module	√	√	√	√		
2013\LC-Challenger	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2013\LC-Challenger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\LC-Challenger	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\LC-Challenger	CGW -- Central Gateway	√	√	√	√	√	
2013\LC-Challenger	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2013\LC-Challenger	SAS -- Steering Angle Sensor	√	√	√	√	√	
2013\LC-Challenger	EPS -- Electric Power Steering	√	√	√	√		
2013\LC-Challenger	PTS -- Parktronics	√	√	√	√		
2013\LC-Challenger	RADIO -- Radio	√	√	√	√	√	
2013\LC-Challenger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\LC-Challenger	DDM -- Driver Door Module	√	√	√	√	√	
2013\LC-Challenger	PDM -- Passenger Door Module	√	√	√	√	√	
2013\LC-Challenger	ESM -- Electronic Shifter	√	√	√	√	√	

2013\LC-Challenger	SUNR -- Sunroof	√	√	√	√	√	
2013\LC-Challenger	EOM -- Electronic Overhead	√	√	√	√		
2013\LC-Challenger	AMP -- Amplifier	√	√	√	√		
2013\LC-Challenger	HFM -- Hands Free Module	√	√	√	√	√	
2013\LC-Challenger	HSM -- Heated Seat Module	√	√	√	√	√	
2013\LC-Challenger	PEM -- Passive Entry Module	√	√	√	√		
2013\LC-Challenger	ADCM -- Active Damping Control Module	√	√	√	√		
2013\LD-Charger	ECM -- Engine Control Module	√	√	√	√	√	
2013\LD-Charger	TCM -- Transmission Control Module	√	√	√	√		
2013\LD-Charger	DTCM -- Drive Train Control Module	√	√	√	√	√	
2013\LD-Charger	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013\LD-Charger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\LD-Charger	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2013\LD-Charger	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\LD-Charger	BCM -- Body Controller	√	√	√	√	√	
2013\LD-Charger	TGW -- Telematic Gateway Radio	√	√	√	√		
2013\LD-Charger	RFH -- Radio Frequency Hub	√	√	√	√	√	
2013\LD-Charger	EPS -- Electric Power Steering	√	√	√	√		
2013\LD-Charger	PTS -- Parktronics	√	√	√	√	√	
2013\LD-Charger	ICS -- Integrated Center Stack	√	√	√	√	√	
2013\LD-Charger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\LD-Charger	ACC -- Adaptive Cruise Control	√	√	√	√		
2013\LD-Charger	SCCM -- Steering Column Control Module	√	√	√	√		
2013\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\LD-Charger	DDM -- Driver Door Module	√	√	√	√	√	
2013\LD-Charger	PDM -- Passenger Door Module	√	√	√	√	√	
2013\LD-Charger	ESM -- Electronic Shifter	√	√	√	√	√	
2013\LD-Charger	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2013\LD-Charger	HFM -- Hands Free Module	√	√	√	√		
2013\LD-Charger	HSM -- Heated Seat Module	√	√	√	√	√	
2013\LD-Charger	ADCM -- Active Damping Control Module	√	√	√	√		
2013\LD-Charger	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2013\LD-Charger	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2013\LD-Charger	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2013\LX-300,Charger,Magnum,Grand Voyager	ECM -- Engine Control Module	√	√	√	√	√	0041
2013\LX-300,Charger,Magnum,Grand Voyager	TCM -- Transmission Control Module	√	√	√	√		
2013\LX-300,Charger,Magnum,Grand Voyager	DTCM -- Drive Train Control Module	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\LX-300,Charger,Magnum,Grand Voyager	IPC -- Instrument Panel Cluster	√	√	√	√	√	

2013\LX-300,Charger,Magnum,Grand Voyager	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\LX-300,Charger,Magnum,Grand Voyager	BCM -- Body Controller	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	TGW -- Telematic Gateway Radio	√	√	√	√		
2013\LX-300,Charger,Magnum,Grand Voyager	RFH -- Radio Frequency Hub	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	EPS -- Electric Power Steering	√	√	√	√		
2013\LX-300,Charger,Magnum,Grand Voyager	PTS -- Parktronics	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	ICS -- Integrated Center Stack	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	AFLS -- Adaptive Front Lighting System	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	ACC -- Adaptive Cruise Control	√	√	√	√		
2013\LX-300,Charger,Magnum,Grand Voyager	SCCM -- Steering Column Control Module	√	√	√	√		
2013\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√		
2013\LX-300,Charger,Magnum,Grand Voyager	HFM -- Hands Free Module	√	√	√	√		
2013\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2013\LX-300,Charger,Magnum,Grand Voyager	ADCM -- Active Damping Control Module	√	√	√	√		
2013\LX-300,Charger,Magnum,Grand Voyager	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2013\LX-300,Charger,Magnum,Grand Voyager	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2013\MK-Compass,Patriot	ECM -- Engine Control Module	√	√	√	√	√	0012, 0036, 0053
2013\MK-Compass,Patriot	TCM -- Transmission Control Module	√	√	√	√	√	
2013\MK-Compass,Patriot	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2013\MK-Compass,Patriot	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\MK-Compass,Patriot	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	

2013\MK-Compass,Patriot	WCM/TPMS -- Wireless Control	√	√	√	√		
2013\MK-Compass,Patriot	SAS -- Steering Angle Sensor	√	√	√	√		
2013\MK-Compass,Patriot	RADIO -- Radio	√	√	√	√	√	
2013\MK-Compass,Patriot	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\MK-Compass,Patriot	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2013\MK-Compass,Patriot	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2013\MK-Compass,Patriot	AMP -- Amplifier	√	√	√	√		
2013\MK-Compass,Patriot	HFM -- Hands Free Module	√	√	√	√	√	
2013\NY-Ypsilon	ECM -- Engine Control Module	√	√	√	√	√	
2013\NY-Ypsilon	TCM -- Transmission Control Module	√	√	√	√	√	
2013\NY-Ypsilon	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013\NY-Ypsilon	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2013\NY-Ypsilon	IPC -- Instrument Panel Cluster	√	√	√	√	√	0043
2013\NY-Ypsilon	BCM -- Body Controller	√	√	√	√	√	
2013\NY-Ypsilon	EPS -- Electric Power Steering	√	√	√	√		
2013\NY-Ypsilon	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\NY-Ypsilon	AHM -- Additional Heater Module	√	√	√	√	√	
2013\PF-Dart	ECM -- Engine Control Module	√	√	√	√	√	
2013\PF-Dart	TCM -- Transmission Control Module	√	√	√	√	√	
2013\PF-Dart	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013\PF-Dart	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\PF-Dart	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2013\PF-Dart	BCM -- Body Controller	√	√	√	√	√	
2013\PF-Dart	RFH -- Radio Frequency Hub	√	√	√	√	√	
2013\PF-Dart	EPS -- Electric Power Steering	√	√	√	√		
2013\PF-Dart	ICS -- Integrated Center Stack	√	√	√	√	√	
2013\PF-Dart	RADIO -- Radio	√	√	√	√	√	
2013\PF-Dart	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\PF-Dart	SCCM -- Steering Column Control Module	√	√	√	√		
2013\PF-Dart	PAM -- Park Assist Module	√	√	√	√		
2013\PF-Dart	ESM -- Electronic Shifter	√	√	√	√		
2013\PF-Dart	OCM -- Occupant Classification	√	√	√	√		
2013\PF-Dart	AMP -- Amplifier	√	√	√	√		
2013\PF-Dart	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2013\PF-Dart	CTM -- Convergence Telematic Module	√	√	√	√		
2013\PF-Dart	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2013\PF-Dart	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	
2013\PF-Dart	EDM -- External Disc Module	√	√	√		√	
2013\RM-Routan	ECM -- Engine Control Module	√	√	√	√	√	
2013\RM-Routan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2013\RM-Routan	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\RM-Routan	CGW -- Central Gateway	√	√	√	√	√	0003
2013\RM-Routan	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2013\RM-Routan	SAS -- Steering Angle Sensor	√	√	√	√		

2013\RM-Routan	PTS -- Parktronics	√	√	√	√	√	
2013\RM-Routan	RADIO -- Radio	√	√	√	√	√	
2013\RM-Routan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\RM-Routan	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2013\RM-Routan	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2013\RM-Routan	DMFR -- Door Module Front Right	√	√	√	√	√	
2013\RM-Routan	DMFL -- Door Module Front Left	√	√	√	√	√	
2013\RM-Routan	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2013\RM-Routan	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2013\RM-Routan	PLGM -- Power Liftgate Module	√	√	√	√	√	
2013\RM-Routan	FSM -- Fold Stow Module	√	√	√	√	√	
2013\RM-Routan	SUNR -- Sunroof	√	√	√	√	√	
2013\RM-Routan	DVD -- DVD Changer	√	√	√	√		
2013\RM-Routan	AMP -- Amplifier	√	√	√	√		
2013\RM-Routan	HFM -- Hands Free Module	√	√	√	√	√	
2013\RM-Routan	VES2 -- Second Row Screen	√	√	√	√	√	
2013\RM-Routan	VES3 -- Last Row Screen	√	√	√	√	√	
2013\RM-Routan	HSM -- Heated Seat Module	√	√	√	√	√	
2013\RM-Routan	PEM -- Passive Entry Module	√	√	√	√		
2013\RM-Routan	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2013\RM-Routan	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2013\RT-Caravan,Town & Country	ECM -- Engine Control Module	√	√	√	√	√	
2013\RT-Caravan,Town & Country	TCM -- Transmission Control Module	√	√	√	√	√	
2013\RT-Caravan,Town & Country	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0001, 0005, 0002
2013\RT-Caravan,Town & Country	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\RT-Caravan,Town & Country	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2013\RT-Caravan,Town & Country	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\RT-Caravan,Town & Country	CGW -- Central Gateway	√	√	√	√	√	0003
2013\RT-Caravan,Town & Country	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2013\RT-Caravan,Town & Country	SAS -- Steering Angle Sensor	√	√	√	√		
2013\RT-Caravan,Town & Country	PTS -- Parktronics	√	√	√	√	√	
2013\RT-Caravan,Town & Country	RADIO -- Radio	√	√	√	√	√	
2013\RT-Caravan,Town & Country	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\RT-Caravan,Town & Country	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2013\RT-Caravan,Town & Country	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2013\RT-Caravan,Town & Country	DMFR -- Door Module Front Right	√	√	√	√	√	
2013\RT-Caravan,Town & Country	DMFL -- Door Module Front Left	√	√	√	√	√	
2013\RT-Caravan,Town & Country	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2013\RT-Caravan,Town & Country	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2013\RT-Caravan,Town & Country	PLGM -- Power Liftgate Module	√	√	√	√	√	
2013\RT-Caravan,Town & Country	FSM -- Fold Stow Module	√	√	√	√	√	
2013\RT-Caravan,Town & Country	SUNR -- Sunroof	√	√	√	√	√	
2013\RT-Caravan,Town & Country	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2013\RT-Caravan,Town & Country	AHBM -- Automatic High Beam	√	√	√	√	√	



2013\RT-Caravan,Town & Country	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2013\RT-Caravan,Town & Country	DVD -- DVD Changer	√	√	√	√		
2013\RT-Caravan,Town & Country	AMP -- Amplifier	√	√	√	√		
2013\RT-Caravan,Town & Country	HFM -- Hands Free Module	√	√	√	√	√	
2013\RT-Caravan,Town & Country	VES2 -- Second Row Screen	√	√	√	√	√	
2013\RT-Caravan,Town & Country	VES3 -- Last Row Screen	√	√	√	√	√	
2013\RT-Caravan,Town & Country	HSM -- Heated Seat Module	√	√	√	√	√	
2013\RT-Caravan,Town & Country	PEM -- Passive Entry Module	√	√	√	√		
2013\RT-Caravan,Town & Country	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2013\RT-Caravan,Town & Country	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2013\RT-Caravan,Town & Country	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2013\WD-Durango	ECM -- Engine Control Module	√	√	√	√	√	
2013\WD-Durango	TCM -- Transmission Control Module	√	√	√	√		
2013\WD-Durango	DTCM -- Drive Train Control Module	√	√	√	√	√	
2013\WD-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2013\WD-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2013\WD-Durango	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2013\WD-Durango	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\WD-Durango	CGW -- Central Gateway	√	√	√	√	√	0003
2013\WD-Durango	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2013\WD-Durango	SAS -- Steering Angle Sensor	√	√	√	√	√	
2013\WD-Durango	EPS -- Electric Power Steering	√	√	√	√		
2013\WD-Durango	PTS -- Parktronic	√	√	√	√	√	
2013\WD-Durango	RADIO -- Radio	√	√	√	√	√	
2013\WD-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\WD-Durango	ACC -- Adaptive Cruise Control	√	√	√	√		
2013\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\WD-Durango	DMFL -- Door Module Front Left	√	√	√	√	√	
2013\WD-Durango	ESM -- Electronic Shifter	√	√	√	√	√	
2013\WD-Durango	PLGM -- Power Liftgate Module	√	√	√	√	√	
2013\WD-Durango	AHLM -- Headlamp Leveling	√	√	√	√	√	
2013\WD-Durango	AHBM -- Automatic High Beam	√	√	√	√	√	
2013\WD-Durango	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2013\WD-Durango	AMP -- Amplifier	√	√	√	√		
2013\WD-Durango	HFM -- Hands Free Module	√	√	√	√	√	
2013\WD-Durango	VES3 -- Last Row Screen	√	√	√	√	√	
2013\WD-Durango	HSM -- Heated Seat Module	√	√	√	√	√	
2013\WD-Durango	BSM -- Blind Spot Module	√	√	√	√		
2013\WD-Durango	PEM -- Passive Entry Module	√	√	√	√		
2013\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	0041
2013\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2013\WK-Grand Cherokee	DTCM -- Drive Train Control Module	√	√	√	√	√	
2013\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2013\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		

2013\WK-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2013\WK-Grand Cherokee	TPM -- Tire Pressure Monitor	√	√	√	√		
2013\WK-Grand Cherokee	CGW -- Central Gateway	√	√	√	√	√	0003
2013\WK-Grand Cherokee	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2013\WK-Grand Cherokee	SAS -- Steering Angle Sensor	√	√	√	√	√	
2013\WK-Grand Cherokee	EPS -- Electric Power Steering	√	√	√	√		
2013\WK-Grand Cherokee	PTS -- Parktronic	√	√	√	√	√	
2013\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√	√	
2013\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013\WK-Grand Cherokee	ACC -- Adaptive Cruise Control	√	√	√	√		
2013\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2013\WK-Grand Cherokee	DMFR -- Door Module Front Right	√	√	√	√	√	
2013\WK-Grand Cherokee	DMFL -- Door Module Front Left	√	√	√	√	√	
2013\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2013\WK-Grand Cherokee	PLGM -- Power Liftgate Module	√	√	√	√	√	
2013\WK-Grand Cherokee	AHLM -- Headlamp Leveling	√	√	√	√	√	
2013\WK-Grand Cherokee	AHBM -- Automatic High Beam	√	√	√	√	√	
2013\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2013\WK-Grand Cherokee	AMP -- Amplifier	√	√	√	√		
2013\WK-Grand Cherokee	HFM -- Hands Free Module	√	√	√	√	√	
2013\WK-Grand Cherokee	VES3 -- Last Row Screen	√	√	√	√	√	
2013\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2013\WK-Grand Cherokee	PEM -- Passive Entry Module	√	√	√	√		
2013\WK-Grand Cherokee	ADCM -- Active Damping Control Module	√	√	√	√		
2013\WK-Grand Cherokee	ASCM -- Air Suspension Control Module	√	√	√	√		
2013\WK-Grand Cherokee	ELSD -- Electronic Limited Slip Differential	√	√	√	√		
2013ZD-Viper (Post-2013)	ECM -- Engine Control Module	√	√	√	√	√	
2013ZD-Viper (Post-2013)	ABS -- Anti Lock Brakes	√	√	√	√	√	
2013ZD-Viper (Post-2013)	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2013ZD-Viper (Post-2013)	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2013ZD-Viper (Post-2013)	TPM -- Tire Pressure Monitor	√	√	√	√		
2013ZD-Viper (Post-2013)	BCM -- Body Controller	√	√	√	√	√	
2013ZD-Viper (Post-2013)	RFH -- Radio Frequency Hub	√	√	√	√	√	
2013ZD-Viper (Post-2013)	ICS -- Integrated Center Stack	√	√	√	√	√	
2013ZD-Viper (Post-2013)	RADIO -- Radio	√	√	√	√	√	
2013ZD-Viper (Post-2013)	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2013ZD-Viper (Post-2013)	SCCM -- Steering Column Control Module	√	√	√	√		
2013ZD-Viper (Post-2013)	DDM -- Driver Door Module	√	√	√	√	√	
2013ZD-Viper (Post-2013)	PDM -- Passenger Door Module	√	√	√	√	√	
2013ZD-Viper (Post-2013)	OCM -- Occupant Classification	√	√	√	√		
2013ZD-Viper (Post-2013)	AMP -- Amplifier	√	√	√	√		
2013ZD-Viper (Post-2013)	ADCM -- Active Damping Control Module	√	√	√	√		
20144C	ECM -- Engine Control Module	√	√	√	√	√	
20144C	TCM -- Transmission Control Module	√	√	√	√		
20144C	ABS -- Anti Lock Brakes	√	√	√	√	√	

2014\4C	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\4C	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\4C	TPM -- Tire Pressure Monitor	√	√	√	√		
2014\4C	BCM -- Body Controller	√	√	√	√	√	
2014\4C	PAM -- Park Assist Module	√	√	√	√		
2014\BF-Fiat 500L	ECM -- Engine Control Module	√	√	√	√	√	
2014\BF-Fiat 500L	TCM -- Transmission Control Module	√	√	√	√	√	
2014\BF-Fiat 500L	ABS -- Anti Lock Brakes	√	√	√	√		
2014\BF-Fiat 500L	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\BF-Fiat 500L	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\BF-Fiat 500L	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2014\BF-Fiat 500L	BCM -- Body Controller	√	√	√	√	√	
2014\BF-Fiat 500L	EPS -- Electric Power Steering	√	√	√	√		
2014\BF-Fiat 500L	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\BF-Fiat 500L	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2014\BF-Fiat 500L	PAM -- Park Assist Module	√	√	√	√		
2014\D2-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\D2-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2014\D2-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2014\D2-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014\D2-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2014\D2-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\D2-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2014\D2-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014\D2-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2014\D2-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2014\D2-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2014\D2-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\D2-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2014\D2-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2014\D2-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2014\D2-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2014\D2-Ram Truck	AMP -- Amplifier	√	√	√	√		
2014\D2-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2014\D2-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2014\D2-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2014\D2-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2014\D2-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2014\D2-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2014\D2-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2014\DD-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\DD-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2014\DD-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2014\DD-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014\DD-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	

2014DD-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014DD-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2014DD-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014DD-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2014DD-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2014DD-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2014DD-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014DD-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2014DD-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2014DD-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2014DD-Ram Truck	AMP -- Amplifier	√	√	√	√		
2014DD-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2014DD-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2014DD-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2014DD-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2014DD-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2014DD-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2014DJ-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2014DJ-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2014DJ-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2014DJ-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014DJ-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2014DJ-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014DJ-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2014DJ-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014DJ-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2014DJ-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2014DJ-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2014DJ-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014DJ-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2014DJ-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2014DJ-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2014DJ-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2014DJ-Ram Truck	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2014DJ-Ram Truck	AMP -- Amplifier	√	√	√	√		
2014DJ-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2014DJ-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2014DJ-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2014DJ-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2014DJ-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2014DJ-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2014DJ-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2014DP-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2014DP-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2014DP-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	

2014\DP-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014\DP-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2014\DP-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\DP-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2014\DP-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2014\DP-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2014\DP-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2014\DP-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\DP-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2014\DP-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2014\DP-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2014\DP-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2014\DP-Ram Truck	AMP -- Amplifier	√	√	√	√		
2014\DP-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2014\DP-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2014\DP-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2014\DP-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2014\DP-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2014\DP-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2014\DS-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\DS-Ram Truck	TCM -- Transmission Control Module	√	√	√	√		
2014\DS-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2014\DS-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014\DS-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2014\DS-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\DS-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2014\DS-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014\DS-Ram Truck	EPS -- Electric Power Steering	√	√	√	√		
2014\DS-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2014\DS-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2014\DS-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2014\DS-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\DS-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2014\DS-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2014\DS-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2014\DS-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2014\DS-Ram Truck	ESM -- Electronic Shifter	√	√	√	√		
2014\DS-Ram Truck	AMP -- Amplifier	√	√	√	√		
2014\DS-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2014\DS-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2014\DS-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2014\DS-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2014\DX-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\DX-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2014\DX-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	

2014\DX-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2014\DX-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\DX-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2014\DX-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014\DX-Ram Truck	EPS -- Electric Power Steering	√	√	√	√		
2014\DX-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2014\DX-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2014\DX-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2014\DX-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\DX-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2014\DX-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2014\DX-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2014\DX-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2014\DX-Ram Truck	ESM -- Electronic Shifter	√	√	√	√		
2014\DX-Ram Truck	AMP -- Amplifier	√	√	√	√		
2014\DX-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2014\DX-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2014\DX-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2014\DX-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2014\DX-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2014\DX-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2014\DX-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2014\FF-500	ECM -- Engine Control Module	√	√	√	√	√	
2014\FF-500	TCM -- Transmission Control Module	√	√	√	√	√	
2014\FF-500	ABS -- Anti Lock Brakes	√	√	√	√		
2014\FF-500	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\FF-500	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\FF-500	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2014\FF-500	BCM -- Body Controller	√	√	√	√	√	
2014\FF-500	EPS -- Electric Power Steering	√	√	√	√		
2014\FF-500	PTS -- Parktronics	√	√	√	√		
2014\FF-500	RADIO -- Radio	√	√	√	√	√	
2014\FF-500	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\FF-500	EVCU -- Electronic Vehicle Control Unit	√	√	√	√	√	0022
2014\FF-500	ESM -- Electronic Shifter	√	√	√			
2014\FF-500	BPCM -- Battery Pack Control Module	√	√	√	√	√	0018, 0025, 0024, 0040, 0023, 0042, 0033, 0020, 0045, 0019
2014\FF-500	OBCM -- On Board Charging Module	√	√	√	√		
2014\FF-500	CTM -- Convergence Telematic Module	√	√	√	√	√	
2014\FF-500	VTM -- Vehicle Tracking Module	√	√	√	√		
2014\FF-500	RBC -- Regenerative Brake Controller	√	√	√	√		
2014\FF-500	PIM -- Power Inverter Module	√	√	√	√		

2014J8-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2014J8-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2014J8-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2014J8-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2014J8-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2014J8-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2014J8-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2014J8-Wrangler	RADIO -- Radio	√	√	√	√	√	
2014J8-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014J8-Wrangler	ESM -- Electronic Shifter	√	√	√	√	√	
2014JC-Journey	ECM -- Engine Control Module	√	√	√	√	√	0041
2014JC-Journey	TCM -- Transmission Control Module	√	√	√	√	√	
2014JC-Journey	DTCM -- Drive Train Control Module	√	√	√	√	√	
2014JC-Journey	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014JC-Journey	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014JC-Journey	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014JC-Journey	TPM -- Tire Pressure Monitor	√	√	√	√		
2014JC-Journey	BCM -- Body Controller	√	√	√	√	√	
2014JC-Journey	TGW -- Telematic Gateway Radio	√	√	√	√		
2014JC-Journey	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014JC-Journey	PTS -- Parktronics	√	√	√	√	√	
2014JC-Journey	ICS -- Integrated Center Stack	√	√	√	√	√	
2014JC-Journey	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014JC-Journey	SCCM -- Steering Column Control Module	√	√	√	√		
2014JC-Journey	DDM -- Driver Door Module	√	√	√	√	√	
2014JC-Journey	PDM -- Passenger Door Module	√	√	√	√	√	
2014JC-Journey	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2014JC-Journey	AMP -- Amplifier	√	√	√	√		
2014JC-Journey	HFM -- Hands Free Module	√	√	√	√		
2014JC-Journey	VES3 -- Last Row Screen	√	√	√	√	√	
2014JC-Journey	HSM -- Heated Seat Module	√	√	√	√	√	
2014JC-Journey	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2014JC-Journey	VTM -- Vehicle Tracking Module	√	√	√	√		
2014JF-Freemont	TCM -- Transmission Control Module	√	√	√	√	√	
2014JF-Freemont	DTCM -- Drive Train Control Module	√	√	√	√	√	
2014JF-Freemont	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014JF-Freemont	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014JF-Freemont	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014JF-Freemont	TPM -- Tire Pressure Monitor	√	√	√	√		
2014JF-Freemont	BCM -- Body Controller	√	√	√	√	√	
2014JF-Freemont	TGW -- Telematic Gateway Radio	√	√	√	√		
2014JF-Freemont	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014JF-Freemont	PTS -- Parktronics	√	√	√	√	√	

2014\JF-Freemont	ICS -- Integrated Center Stack	√	√	√	√	√	
2014\JF-Freemont	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\JF-Freemont	SCCM -- Steering Column Control Module	√	√	√	√		
2014\JF-Freemont	DDM -- Driver Door Module	√	√	√	√	√	
2014\JF-Freemont	PDM -- Passenger Door Module	√	√	√	√	√	
2014\JF-Freemont	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2014\JF-Freemont	AMP -- Amplifier	√	√	√	√		
2014\JF-Freemont	HFM -- Hands Free Module	√	√	√	√		
2014\JF-Freemont	VES3 -- Last Row Screen	√	√	√	√	√	
2014\JF-Freemont	HSM -- Heated Seat Module	√	√	√	√	√	
2014\JF-Freemont	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2014\JF-Freemont	VTM -- Vehicle Tracking Module	√	√	√	√		
2014\JK-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\JK-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2014\JK-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2014\JK-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2014\JK-Wrangler	TPM -- Tire Pressure Monitor	√	√	√	√		
2014\JK-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2014\JK-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2014\JK-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2014\JK-Wrangler	RADIO -- Radio	√	√	√	√	√	
2014\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\JK-Wrangler	ESM -- Electronic Shifter	√	√	√	√	√	
2014\JK-Wrangler	ASBS -- Automatic Sway Bar System	√	√	√	√		
2014\JK-Wrangler	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2014\JK-Wrangler	AMP -- Amplifier	√	√	√	√		
2014\JK-Wrangler	HFM -- Hands Free Module	√	√	√	√	√	
2014\JS-Avenger,Sebring,Convertible-Sedan	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\JS-Avenger,Sebring,Convertible-Sedan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\JS-Avenger,Sebring,Convertible-Sedan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2014\JS-Avenger,Sebring,Convertible-Sedan	CGW -- Central Gateway	√	√	√	√	√	0003
2014\JS-Avenger,Sebring,Convertible-Sedan	WCM/TPMS -- Wireless Control	√	√	√	√		
2014\JS-Avenger,Sebring,Convertible-Sedan	SAS -- Steering Angle Sensor	√	√	√	√		
2014\JS-Avenger,Sebring,Convertible-Sedan	RADIO -- Radio	√	√	√	√	√	
2014\JS-Avenger,Sebring,Convertible-Sedan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\JS-Avenger,Sebring,Convertible-Sedan	DDM -- Driver Door Module	√	√	√	√	√	



2014\JS-Avenger,Sebring,Convertible-Sedan	PDM -- Passenger Door Module	√	√	√	√	√	
2014\JS-Avenger,Sebring,Convertible-Sedan	PTCM -- Power Top Control Module	√	√	√	√		
2014\JS-Avenger,Sebring,Convertible-Sedan	AMP -- Amplifier	√	√	√	√		
2014\JS-Avenger,Sebring,Convertible-Sedan	HFM -- Hands Free Module	√	√	√	√	√	
2014\KK-Liberty	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\KK-Liberty	TCM -- Transmission Control Module	√	√	√	√		
2014\KK-Liberty	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2014\KK-Liberty	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2014\KK-Liberty	CGW -- Central Gateway	√	√	√	√	√	0003
2014\KK-Liberty	WCM/TPMS -- Wireless Control	√	√	√	√		
2014\KK-Liberty	SAS -- Steering Angle Sensor	√	√	√	√		
2014\KK-Liberty	PTS -- Parktronics	√	√	√	√	√	
2014\KK-Liberty	RADIO -- Radio	√	√	√	√	√	
2014\KK-Liberty	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2014\KK-Liberty	DMFR -- Door Module Front Right	√	√	√	√	√	
2014\KK-Liberty	DMFL -- Door Module Front Left	√	√	√	√	√	
2014\KK-Liberty	ESM -- Electronic Shifter	√	√	√	√	√	
2014\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2014\KK-Liberty	OCM -- Occupant Classification	√	√	√	√		
2014\KK-Liberty	SUNR -- Sunroof	√	√	√	√		
2014\KK-Liberty	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2014\KK-Liberty	AMP -- Amplifier	√	√	√	√		
2014\KK-Liberty	HFM -- Hands Free Module	√	√	√	√	√	
2014\KL-Cherokee	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\KL-Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2014\KL-Cherokee	DTCM -- Drive Train Control Module	√	√	√	√	√	
2014\KL-Cherokee	ABS -- Anti Lock Brakes	√	√	√	√		
2014\KL-Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2014\KL-Cherokee	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\KL-Cherokee	BCM -- Body Controller	√	√	√	√	√	
2014\KL-Cherokee	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014\KL-Cherokee	ESL -- Electronic Steering Lock	√	√	√	√		
2014\KL-Cherokee	EPS -- Electric Power Steering	√	√	√	√		
2014\KL-Cherokee	ICS -- Integrated Center Stack	√	√	√	√	√	
2014\KL-Cherokee	RADIO -- Radio	√	√	√	√	√	
2014\KL-Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\KL-Cherokee	ACC -- Adaptive Cruise Control	√	√	√	√		
2014\KL-Cherokee	PTU -- Power Transfer Unit	√	√	√			
2014\KL-Cherokee	SCCM -- Steering Column Control Module	√	√	√	√	√	
2014\KL-Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		

2014\KL-Cherokee	DDM -- Driver Door Module	√	√	√	√	√	
2014\KL-Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2014\KL-Cherokee	PAM -- Park Assist Module	√	√	√	√	√	
2014\KL-Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2014\KL-Cherokee	PLGM -- Power Liftgate Module	√	√	√	√	√	
2014\KL-Cherokee	OCM -- Occupant Classification	√	√	√	√		
2014\KL-Cherokee	AHLM -- Headlamp Leveling	√	√	√	√		
2014\KL-Cherokee	AMP -- Amplifier	√	√	√	√		
2014\KL-Cherokee	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2014\KL-Cherokee	FFCM -- Forward Facing Camera Module	√	√	√	√		
2014\KL-Cherokee	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2014\KL-Cherokee	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2014\KL-Cherokee	RDM -- Rear Drive Module	√	√	√			
2014\KL-Cherokee	EDM -- External Disc Module	√	√	√		√	
2014\LC-Challenger	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\LC-Challenger	TCM -- Transmission Control Module	√	√	√	√		
2014\LC-Challenger	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2014\LC-Challenger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\LC-Challenger	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2014\LC-Challenger	TPM -- Tire Pressure Monitor	√	√	√	√		
2014\LC-Challenger	CGW -- Central Gateway	√	√	√	√	√	
2014\LC-Challenger	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2014\LC-Challenger	SAS -- Steering Angle Sensor	√	√	√	√	√	
2014\LC-Challenger	EPS -- Electric Power Steering	√	√	√	√		
2014\LC-Challenger	PTS -- Parktronics	√	√	√	√		
2014\LC-Challenger	RADIO -- Radio	√	√	√	√	√	
2014\LC-Challenger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\LC-Challenger	DDM -- Driver Door Module	√	√	√	√	√	
2014\LC-Challenger	ESM -- Electronic Shifter	√	√	√	√	√	
2014\LC-Challenger	SUNR -- Sunroof	√	√	√	√	√	
2014\LC-Challenger	EOM -- Electronic Overhead	√	√	√	√		
2014\LC-Challenger	AMP -- Amplifier	√	√	√	√		
2014\LC-Challenger	HFM -- Hands Free Module	√	√	√	√	√	
2014\LC-Challenger	HSM -- Heated Seat Module	√	√	√	√	√	
2014\LC-Challenger	PEM -- Passive Entry Module	√	√	√	√		
2014\LC-Challenger	ADCM -- Active Damping Control Module	√	√	√	√		
2014\LD-Charger	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\LD-Charger	TCM -- Transmission Control Module	√	√	√	√		
2014\LD-Charger	DTCM -- Drive Train Control Module	√	√	√	√	√	
2014\LD-Charger	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014\LD-Charger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\LD-Charger	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\LD-Charger	TPM -- Tire Pressure Monitor	√	√	√	√		
2014\LD-Charger	BCM -- Body Controller	√	√	√	√	√	
2014\LD-Charger	TGW -- Telematic Gateway Radio	√	√	√	√		

2014\LD-Charger	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014\LD-Charger	EPS -- Electric Power Steering	√	√	√	√		
2014\LD-Charger	PTS -- Parktronics	√	√	√	√	√	
2014\LD-Charger	ICS -- Integrated Center Stack	√	√	√	√	√	
2014\LD-Charger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\LD-Charger	ACC -- Adaptive Cruise Control	√	√	√	√		
2014\LD-Charger	SCCM -- Steering Column Control Module	√	√	√	√		
2014\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2014\LD-Charger	DDM -- Driver Door Module	√	√	√	√	√	
2014\LD-Charger	PDM -- Passenger Door Module	√	√	√	√	√	
2014\LD-Charger	ESM -- Electronic Shifter	√	√	√	√	√	
2014\LD-Charger	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2014\LD-Charger	AMP -- Amplifier	√	√	√	√		
2014\LD-Charger	HFM -- Hands Free Module	√	√	√	√		
2014\LD-Charger	HSM -- Heated Seat Module	√	√	√	√	√	
2014\LD-Charger	ADCM -- Active Damping Control Module	√	√	√	√		
2014\LD-Charger	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2014\LD-Charger	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2014\LD-Charger	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2014\LX-300,Charger,Magnum,Grand Voyager	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\LX-300,Charger,Magnum,Grand Voyager	TCM -- Transmission Control Module	√	√	√	√		
2014\LX-300,Charger,Magnum,Grand Voyager	DTCM -- Drive Train Control Module	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\LX-300,Charger,Magnum,Grand Voyager	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	TPM -- Tire Pressure Monitor	√	√	√	√		
2014\LX-300,Charger,Magnum,Grand Voyager	BCM -- Body Controller	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	TGW -- Telematic Gateway Radio	√	√	√	√		
2014\LX-300,Charger,Magnum,Grand Voyager	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	EPS -- Electric Power Steering	√	√	√	√		
2014\LX-300,Charger,Magnum,Grand Voyager	PTS -- Parktronics	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	ICS -- Integrated Center Stack	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	AFLS -- Adaptive Front Lighting System	√	√	√	√	√	

2014\LX-300,Charger,Magnum,Grand Voyager	ACC -- Adaptive Cruise Control	√	√	√	√		
2014\LX-300,Charger,Magnum,Grand Voyager	SCCM -- Steering Column Control Module	√	√	√	√		
2014\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√		
2014\LX-300,Charger,Magnum,Grand Voyager	HFM -- Hands Free Module	√	√	√	√		
2014\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2014\LX-300,Charger,Magnum,Grand Voyager	ADCM -- Active Damping Control Module	√	√	√	√		
2014\LX-300,Charger,Magnum,Grand Voyager	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2014\LX-300,Charger,Magnum,Grand Voyager	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2014\MK-Compass,Patriot	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\MK-Compass,Patriot	TCM -- Transmission Control Module	√	√	√	√	√	
2014\MK-Compass,Patriot	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2014\MK-Compass,Patriot	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\MK-Compass,Patriot	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2014\MK-Compass,Patriot	CGW -- Central Gateway	√	√	√	√	√	0003
2014\MK-Compass,Patriot	WCM/TPMS -- Wireless Control	√	√	√	√		
2014\MK-Compass,Patriot	SAS -- Steering Angle Sensor	√	√	√	√		
2014\MK-Compass,Patriot	RADIO -- Radio	√	√	√	√	√	
2014\MK-Compass,Patriot	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\MK-Compass,Patriot	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2014\MK-Compass,Patriot	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2014\MK-Compass,Patriot	AMP -- Amplifier	√	√	√	√		
2014\MK-Compass,Patriot	HFM -- Hands Free Module	√	√	√	√	√	
2014\NY-Ypsilon	ECM -- Engine Control Module	√	√	√	√	√	
2014\NY-Ypsilon	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014\NY-Ypsilon	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2014\NY-Ypsilon	IPC -- Instrument Panel Cluster	√	√	√	√	√	0043
2014\NY-Ypsilon	BCM -- Body Controller	√	√	√	√	√	
2014\NY-Ypsilon	EPS -- Electric Power Steering	√	√	√	√		
2014\NY-Ypsilon	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	

2014\NY-Ypsilon	AHM -- Additional Heater Module	√	√	√	√	√	
2014\PF-Dart	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\PF-Dart	TCM -- Transmission Control Module	√	√	√	√	√	
2014\PF-Dart	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014\PF-Dart	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\PF-Dart	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\PF-Dart	BCM -- Body Controller	√	√	√	√	√	
2014\PF-Dart	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014\PF-Dart	EPS -- Electric Power Steering	√	√	√	√		
2014\PF-Dart	ICS -- Integrated Center Stack	√	√	√	√	√	
2014\PF-Dart	RADIO -- Radio	√	√	√	√	√	
2014\PF-Dart	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\PF-Dart	SCCM -- Steering Column Control Module	√	√	√	√		
2014\PF-Dart	PAM -- Park Assist Module	√	√	√	√		
2014\PF-Dart	ESM -- Electronic Shifter	√	√	√	√		
2014\PF-Dart	OCM -- Occupant Classification	√	√	√	√		
2014\PF-Dart	AMP -- Amplifier	√	√	√	√		
2014\PF-Dart	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2014\PF-Dart	CTM -- Convergence Telematic Module	√	√	√	√		
2014\PF-Dart	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2014\PF-Dart	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	
2014\PF-Dart	EDM -- External Disc Module	√	√	√		√	
2014\RM-Routan	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\RM-Routan	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2014\RM-Routan	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2014\RM-Routan	TPM -- Tire Pressure Monitor	√	√	√	√		
2014\RM-Routan	CGW -- Central Gateway	√	√	√	√	√	0003
2014\RM-Routan	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2014\RM-Routan	SAS -- Steering Angle Sensor	√	√	√	√		
2014\RM-Routan	PTS -- Parktronic	√	√	√	√	√	
2014\RM-Routan	RADIO -- Radio	√	√	√	√	√	
2014\RM-Routan	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\RM-Routan	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2014\RM-Routan	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2014\RM-Routan	DMFR -- Door Module Front Right	√	√	√	√	√	
2014\RM-Routan	DMFL -- Door Module Front Left	√	√	√	√	√	
2014\RM-Routan	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2014\RM-Routan	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2014\RM-Routan	PLGM -- Power Liftgate Module	√	√	√	√	√	
2014\RM-Routan	FSM -- Fold Stow Module	√	√	√	√	√	
2014\RM-Routan	SUNR -- Sunroof	√	√	√	√	√	
2014\RM-Routan	DVD -- DVD Changer	√	√	√	√		
2014\RM-Routan	AMP -- Amplifier	√	√	√	√		
2014\RM-Routan	HFM -- Hands Free Module	√	√	√	√	√	

2014\RM-Routan	VES2 -- Second Row Screen	√	√	√	√	√	
2014\RM-Routan	VES3 -- Last Row Screen	√	√	√	√	√	
2014\RM-Routan	HSM -- Heated Seat Module	√	√	√	√	√	
2014\RM-Routan	PEM -- Passive Entry Module	√	√	√	√		
2014\RM-Routan	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2014\RM-Routan	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2014\RT-Caravan,Town & Country	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\RT-Caravan,Town & Country	TCM -- Transmission Control Module	√	√	√	√	√	
2014\RT-Caravan,Town & Country	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2014\RT-Caravan,Town & Country	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\RT-Caravan,Town & Country	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2014\RT-Caravan,Town & Country	TPM -- Tire Pressure Monitor	√	√	√	√		
2014\RT-Caravan,Town & Country	CGW -- Central Gateway	√	√	√	√	√	0003
2014\RT-Caravan,Town & Country	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2014\RT-Caravan,Town & Country	SAS -- Steering Angle Sensor	√	√	√	√		
2014\RT-Caravan,Town & Country	PTS -- Parktronic	√	√	√	√	√	
2014\RT-Caravan,Town & Country	RADIO -- Radio	√	√	√	√	√	
2014\RT-Caravan,Town & Country	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\RT-Caravan,Town & Country	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2014\RT-Caravan,Town & Country	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2014\RT-Caravan,Town & Country	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2014\RT-Caravan,Town & Country	DMFR -- Door Module Front Right	√	√	√	√	√	
2014\RT-Caravan,Town & Country	DMFL -- Door Module Front Left	√	√	√	√	√	
2014\RT-Caravan,Town & Country	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2014\RT-Caravan,Town & Country	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2014\RT-Caravan,Town & Country	PLGM -- Power Liftgate Module	√	√	√	√	√	
2014\RT-Caravan,Town & Country	FSM -- Fold Stow Module	√	√	√	√	√	
2014\RT-Caravan,Town & Country	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2014\RT-Caravan,Town & Country	AHBM -- Automatic High Beam	√	√	√	√	√	
2014\RT-Caravan,Town & Country	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2014\RT-Caravan,Town & Country	DVD -- DVD Changer	√	√	√	√		
2014\RT-Caravan,Town & Country	AMP -- Amplifier	√	√	√	√		
2014\RT-Caravan,Town & Country	HFM -- Hands Free Module	√	√	√	√	√	
2014\RT-Caravan,Town & Country	VES2 -- Second Row Screen	√	√	√	√	√	
2014\RT-Caravan,Town & Country	VES3 -- Last Row Screen	√	√	√	√	√	
2014\RT-Caravan,Town & Country	HSM -- Heated Seat Module	√	√	√	√	√	
2014\RT-Caravan,Town & Country	PEM -- Passive Entry Module	√	√	√	√		
2014\RT-Caravan,Town & Country	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2014\RT-Caravan,Town & Country	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2014\RT-Caravan,Town & Country	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2014\VF-ProMaster	ECM -- Engine Control Module	√	√	√	√	√	0041, 0011, 0041
2014\VF-ProMaster	TCM -- Transmission Control Module	√	√	√	√	√	
2014\VF-ProMaster	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014\VF-ProMaster	ORC -- AirBag/Occupant Restraint	√	√	√	√		

2014\VF-ProMaster	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\VF-ProMaster	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2014\VF-ProMaster	BCM -- Body Controller	√	√	√	√	√	
2014\VF-ProMaster	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\VF-ProMaster	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2014\VF-ProMaster	PAM -- Park Assist Module	√	√	√	√		
2014\WD-Durango	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\WD-Durango	TCM -- Transmission Control Module	√	√	√	√		
2014\WD-Durango	DTCM -- Drive Train Control Module	√	√	√	√	√	
2014\WD-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014\WD-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\WD-Durango	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\WD-Durango	TPM -- Tire Pressure Monitor	√	√	√	√		
2014\WD-Durango	BCM -- Body Controller	√	√	√	√	√	
2014\WD-Durango	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014\WD-Durango	EPS -- Electric Power Steering	√	√	√	√		
2014\WD-Durango	PTS -- Parktronic	√	√	√	√	√	
2014\WD-Durango	ICS -- Integrated Center Stack	√	√	√	√		
2014\WD-Durango	RADIO -- Radio	√	√	√	√	√	
2014\WD-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\WD-Durango	HVACR -- Heat, Ventilation and A/C Rear	√	√	√	√	√	
2014\WD-Durango	ACC -- Adaptive Cruise Control	√	√	√	√		
2014\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2014\WD-Durango	DDM -- Driver Door Module	√	√	√	√	√	
2014\WD-Durango	PDM -- Passenger Door Module	√	√	√	√	√	
2014\WD-Durango	ESM -- Electronic Shifter	√	√	√	√		
2014\WD-Durango	PLGM -- Power Liftgate Module	√	√	√	√	√	
2014\WD-Durango	AHLM -- Headlamp Leveling	√	√	√	√		
2014\WD-Durango	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2014\WD-Durango	AMP -- Amplifier	√	√	√	√		
2014\WD-Durango	VES2 -- Second Row Screen	√	√	√	√	√	
2014\WD-Durango	VES3 -- Last Row Screen	√	√	√	√	√	
2014\WD-Durango	HSM -- Heated Seat Module	√	√	√	√	√	
2014\WD-Durango	ELSD -- Electronic Limited Slip Differential	√	√	√	√		
2014\WD-Durango	FFCM -- Forward Facing Camera Module	√	√	√	√		
2014\WD-Durango	LBSS -- Left Blind Spot Sensor	√	√	√			
2014\WD-Durango	RBSS -- Right Blind Spot Sensor	√	√	√			
2014\WD-Durango	EDM -- External Disc Module	√	√	√	√	√	
2014\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	0041
2014\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2014\WK-Grand Cherokee	DTCM -- Drive Train Control Module	√	√	√	√	√	
2014\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2014\WK-Grand Cherokee	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\WK-Grand Cherokee	TPM -- Tire Pressure Monitor	√	√	√	√		

2014\WK-Grand Cherokee	BCM -- Body Controller	√	√	√	√	√	
2014\WK-Grand Cherokee	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014\WK-Grand Cherokee	EPS -- Electric Power Steering	√	√	√	√		
2014\WK-Grand Cherokee	PTS -- Parktronics	√	√	√	√	√	
2014\WK-Grand Cherokee	ICS -- Integrated Center Stack	√	√	√	√		
2014\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√	√	
2014\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\WK-Grand Cherokee	AFLS -- Adaptive Front Lighting System	√	√	√	√		
2014\WK-Grand Cherokee	ACC -- Adaptive Cruise Control	√	√	√	√		
2014\WK-Grand Cherokee	SCCM -- Steering Column Control Module	√	√	√	√		
2014\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2014\WK-Grand Cherokee	DDM -- Driver Door Module	√	√	√	√	√	
2014\WK-Grand Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2014\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√		
2014\WK-Grand Cherokee	PLGM -- Power Liftgate Module	√	√	√	√	√	
2014\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2014\WK-Grand Cherokee	VES2 -- Second Row Screen	√	√	√	√	√	
2014\WK-Grand Cherokee	VES3 -- Last Row Screen	√	√	√	√	√	
2014\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2014\WK-Grand Cherokee	ADCM -- Active Damping Control Module	√	√	√	√		
2014\WK-Grand Cherokee	ASCM -- Air Suspension Control Module	√	√	√	√		
2014\WK-Grand Cherokee	ELSD -- Electronic Limited Slip Differential	√	√	√	√		
2014\WK-Grand Cherokee	FFCM -- Forward Facing Camera Module	√	√	√	√		
2014\WK-Grand Cherokee	LBSS -- Left Blind Spot Sensor	√	√	√			
2014\WK-Grand Cherokee	RBSS -- Right Blind Spot Sensor	√	√	√			
2014\WK-Grand Cherokee	EDM -- External Disc Module	√	√	√	√	√	
2014\ZD-Viper (Post-2013)	ECM -- Engine Control Module	√	√	√	√	√	
2014\ZD-Viper (Post-2013)	ABS -- Anti Lock Brakes	√	√	√	√	√	
2014\ZD-Viper (Post-2013)	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2014\ZD-Viper (Post-2013)	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2014\ZD-Viper (Post-2013)	TPM -- Tire Pressure Monitor	√	√	√	√		
2014\ZD-Viper (Post-2013)	BCM -- Body Controller	√	√	√	√	√	
2014\ZD-Viper (Post-2013)	RFH -- Radio Frequency Hub	√	√	√	√	√	
2014\ZD-Viper (Post-2013)	ICS -- Integrated Center Stack	√	√	√	√	√	
2014\ZD-Viper (Post-2013)	RADIO -- Radio	√	√	√	√	√	
2014\ZD-Viper (Post-2013)	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2014\ZD-Viper (Post-2013)	SCCM -- Steering Column Control Module	√	√	√	√		
2014\ZD-Viper (Post-2013)	DDM -- Driver Door Module	√	√	√	√	√	
2014\ZD-Viper (Post-2013)	PDM -- Passenger Door Module	√	√	√	√	√	
2014\ZD-Viper (Post-2013)	OCM -- Occupant Classification	√	√	√	√		
2014\ZD-Viper (Post-2013)	AMP -- Amplifier	√	√	√	√		
2014\ZD-Viper (Post-2013)	ADCM -- Active Damping Control Module	√	√	√	√		
2015\4C	ECM -- Engine Control Module	√	√	√	√	√	
2015\4C	TCM -- Transmission Control Module	√	√	√	√		
2015\4C	ABS -- Anti Lock Brakes	√	√	√	√	√	



2015\4C	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\4C	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\4C	TPM -- Tire Pressure Monitor	√	√	√	√		
2015\4C	BCM -- Body Controller	√	√	√	√	√	
2015\4C	PAM -- Park Assist Module	√	√	√	√		
2015\BF-Fiat 500L	ECM -- Engine Control Module	√	√	√	√	√	
2015\BF-Fiat 500L	TCM -- Transmission Control Module	√	√	√	√	√	
2015\BF-Fiat 500L	ABS -- Anti Lock Brakes	√	√	√	√		
2015\BF-Fiat 500L	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\BF-Fiat 500L	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\BF-Fiat 500L	BCM -- Body Controller	√	√	√	√	√	
2015\BF-Fiat 500L	EPS -- Electric Power Steering	√	√	√	√		
2015\BF-Fiat 500L	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\BF-Fiat 500L	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2015\BF-Fiat 500L	PAM -- Park Assist Module	√	√	√	√		
2015\BF-Fiat 500L	ESM -- Electronic Shifter	√	√	√	√	√	
2015\BU-Renegade	ECM -- Engine Control Module	√	√	√	√	√	
2015\BU-Renegade	TCM -- Transmission Control Module	√	√	√	√		
2015\BU-Renegade	DTCM -- Drive Train Control Module	√	√	√	√		
2015\BU-Renegade	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\BU-Renegade	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\BU-Renegade	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\BU-Renegade	BCM -- Body Controller	√	√	√	√	√	
2015\BU-Renegade	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\BU-Renegade	ESL -- Electronic Steering Lock		√	√	√		
2015\BU-Renegade	EPS -- Electric Power Steering	√	√	√	√		
2015\BU-Renegade	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\BU-Renegade	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2015\BU-Renegade	ACC -- Adaptive Cruise Control	√	√	√	√	√	
2015\BU-Renegade	PAM -- Park Assist Module	√	√	√	√		
2015\BU-Renegade	ESM -- Electronic Shifter	√	√	√	√	√	
2015\BU-Renegade	AMP -- Amplifier	√	√	√	√	√	
2015\BU-Renegade	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2015\BU-Renegade	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2015\BU-Renegade	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	
2015\BU-Renegade	HALF -- Haptical Lane Feedback	√	√	√	√		
2015\BU-Renegade	RRM -- Radio Receiver Module	√	√	√	√	√	
2015\BU-Renegade	TTM -- Trailer tow module	√	√	√	√	√	
2015\D2-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2015\D2-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2015\D2-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\D2-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\D2-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2015\D2-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\D2-Ram Truck	BCM -- Body Controller	√	√	√	√	√	

2015\D2-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\D2-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2015\D2-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\D2-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2015\D2-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2015\D2-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\D2-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2015\D2-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2015\D2-Ram Truck	AMP -- Amplifier	√	√	√	√		
2015\D2-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2015\D2-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2015\D2-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2015\D2-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2015\D2-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2015\D2-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2015\D2-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2015\DD-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2015\DD-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2015\DD-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\DD-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\DD-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2015\DD-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\DD-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2015\DD-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\DD-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2015\DD-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\DD-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2015\DD-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\DD-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2015\DD-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\DD-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2015\DD-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2015\DD-Ram Truck	AMP -- Amplifier	√	√	√	√		
2015\DD-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2015\DD-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2015\DD-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2015\DD-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2015\DD-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2015\DD-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2015\DJ-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2015\DJ-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2015\DJ-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\DJ-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\DJ-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\DJ-Ram Truck	BCM -- Body Controller	√	√	√	√	√	

2015\DJ-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\DJ-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2015\DJ-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\DJ-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2015\DJ-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\DJ-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2015\DJ-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\DJ-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2015\DJ-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2015\DJ-Ram Truck	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2015\DJ-Ram Truck	AMP -- Amplifier	√	√	√	√		
2015\DJ-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2015\DJ-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2015\DJ-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2015\DJ-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2015\DJ-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2015\DJ-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2015\DJ-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2015\DP-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2015\DP-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2015\DP-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\DP-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\DP-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2015\DP-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\DP-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2015\DP-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\DP-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2015\DP-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\DP-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2015\DP-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\DP-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2015\DP-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\DP-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2015\DP-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2015\DP-Ram Truck	AMP -- Amplifier	√	√	√	√		
2015\DP-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2015\DP-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2015\DP-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2015\DP-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2015\DP-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2015\DS-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2015\DS-Ram Truck	TCM -- Transmission Control Module	√	√	√	√		
2015\DS-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\DS-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\DS-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	

2015\DS-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\DS-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2015\DS-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\DS-Ram Truck	EPS -- Electric Power Steering	√	√	√	√		
2015\DS-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2015\DS-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\DS-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2015\DS-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\DS-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2015\DS-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\DS-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2015\DS-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2015\DS-Ram Truck	ESM -- Electronic Shifter	√	√	√	√		
2015\DS-Ram Truck	AMP -- Amplifier	√	√	√	√		
2015\DS-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2015\DS-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2015\DS-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2015\DS-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2015\DS-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2015\DX-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2015\DX-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2015\DX-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\DX-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\DX-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2015\DX-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\DX-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2015\DX-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\DX-Ram Truck	EPS -- Electric Power Steering	√	√	√	√		
2015\DX-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2015\DX-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\DX-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2015\DX-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2015\DX-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\DX-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2015\DX-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2015\DX-Ram Truck	ESM -- Electronic Shifter	√	√	√	√		
2015\DX-Ram Truck	AMP -- Amplifier	√	√	√	√		
2015\DX-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2015\DX-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2015\DX-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2015\DX-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2015\DX-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2015\DX-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2015\DX-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2015\FF-500	ECM -- Engine Control Module	√	√	√	√	√	

2015\FF-500	TCM -- Transmission Control Module	√	√	√	√	√	
2015\FF-500	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\FF-500	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\FF-500	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\FF-500	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2015\FF-500	BCM -- Body Controller	√	√	√	√	√	
2015\FF-500	EPS -- Electric Power Steering	√	√	√	√		
2015\FF-500	PTS -- Parktronics	√	√	√	√		
2015\FF-500	RADIO -- Radio	√	√	√	√	√	
2015\FF-500	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\FF-500	EVCU -- Electronic Vehicle Control Unit	√	√	√	√	√	0022
2015\FF-500	ESM -- Electronic Shifter	√	√	√			
2015\FF-500	BPCM -- Battery Pack Control Module	√	√	√	√	√	0018, 0025, 0024, 0040, 0023, 0042, 0033, 0020, 0045, 0019
2015\FF-500	EAC -- Electric A/C Compressor	√	√	√	√		
2015\FF-500	OBCM -- On Board Charging Module	√	√	√	√		
2015\FF-500	CTM -- Convergence Telematic Module	√	√	√	√	√	
2015\FF-500	VTM -- Vehicle Tracking Module	√	√	√	√		
2015\FF-500	RBC -- Regenerative Brake Controller	√	√	√	√		
2015\FF-500	PIM -- Power Inverter Module	√	√	√	√		
2015\J8-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2015\J8-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2015\J8-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2015\J8-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2015\J8-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2015\J8-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2015\J8-Wrangler	RADIO -- Radio	√	√	√	√	√	
2015\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\J8-Wrangler	ESM -- Electronic Shifter	√	√	√	√	√	
2015\JC-Journey	ECM -- Engine Control Module	√	√	√	√	√	0041
2015\JC-Journey	TCM -- Transmission Control Module	√	√	√	√	√	
2015\JC-Journey	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\JC-Journey	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\JC-Journey	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\JC-Journey	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\JC-Journey	TPM -- Tire Pressure Monitor	√	√	√	√		
2015\JC-Journey	BCM -- Body Controller	√	√	√	√	√	
2015\JC-Journey	TGW -- Telematic Gateway Radio	√	√	√	√		
2015\JC-Journey	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\JC-Journey	PTS -- Parktronics	√	√	√	√	√	
2015\JC-Journey	ICS -- Integrated Center Stack	√	√	√	√	√	

2015\JC-Journey	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\JC-Journey	SCCM -- Steering Column Control Module	√	√	√	√		
2015\JC-Journey	DDM -- Driver Door Module	√	√	√	√	√	
2015\JC-Journey	PDM -- Passenger Door Module	√	√	√	√	√	
2015\JC-Journey	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2015\JC-Journey	AMP -- Amplifier	√	√	√	√		
2015\JC-Journey	HFM -- Hands Free Module	√	√	√	√		
2015\JC-Journey	VES3 -- Last Row Screen	√	√	√	√	√	
2015\JC-Journey	HSM -- Heated Seat Module	√	√	√	√	√	
2015\JC-Journey	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2015\JC-Journey	VTM -- Vehicle Tracking Module	√	√	√	√		
2015\JF-Freemont	ECM -- Engine Control Module	√	√	√	√	√	0041
2015\JF-Freemont	TCM -- Transmission Control Module	√	√	√	√	√	
2015\JF-Freemont	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\JF-Freemont	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\JF-Freemont	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\JF-Freemont	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\JF-Freemont	TPM -- Tire Pressure Monitor	√	√	√	√		
2015\JF-Freemont	BCM -- Body Controller	√	√	√	√	√	
2015\JF-Freemont	TGW -- Telematic Gateway Radio	√	√	√	√		
2015\JF-Freemont	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\JF-Freemont	PTS -- Parktronics	√	√	√	√	√	
2015\JF-Freemont	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\JF-Freemont	SCCM -- Steering Column Control Module	√	√	√	√		
2015\JF-Freemont	DDM -- Driver Door Module	√	√	√	√	√	
2015\JF-Freemont	PDM -- Passenger Door Module	√	√	√	√	√	
2015\JF-Freemont	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2015\JF-Freemont	AMP -- Amplifier	√	√	√	√		
2015\JF-Freemont	HFM -- Hands Free Module	√	√	√	√		
2015\JF-Freemont	VES3 -- Last Row Screen	√	√	√	√	√	
2015\JF-Freemont	HSM -- Heated Seat Module	√	√	√	√	√	
2015\JF-Freemont	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2015\JF-Freemont	VTM -- Vehicle Tracking Module	√	√	√	√		
2015\JK-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	
2015\JK-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2015\JK-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2015\JK-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2015\JK-Wrangler	TPM -- Tire Pressure Monitor	√	√	√	√		
2015\JK-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2015\JK-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2015\JK-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2015\JK-Wrangler	RADIO -- Radio	√	√	√	√	√	

2015\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\JK-Wrangler	ESM -- Electronic Shifter	√	√	√	√	√	
2015\JK-Wrangler	ASBS -- Automatic Sway Bar System	√	√	√	√		
2015\JK-Wrangler	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2015\JK-Wrangler	AMP -- Amplifier	√	√	√	√		
2015\JK-Wrangler	HFM -- Hands Free Module	√	√	√	√	√	
2015\KK-Liberty	ECM -- Engine Control Module	√	√	√	√	√	0041
2015\KK-Liberty	TCM -- Transmission Control Module	√	√	√	√		
2015\KK-Liberty	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2015\KK-Liberty	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2015\KK-Liberty	CGW -- Central Gateway	√	√	√	√	√	0003
2015\KK-Liberty	WCM/TPMS -- Wireless Control	√	√	√	√		
2015\KK-Liberty	SAS -- Steering Angle Sensor	√	√	√	√		
2015\KK-Liberty	PTS -- Parktronic	√	√	√	√	√	
2015\KK-Liberty	RADIO -- Radio	√	√	√	√	√	
2015\KK-Liberty	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\KK-Liberty	DMFL -- Door Module Front Left	√	√	√	√	√	
2015\KK-Liberty	ESM -- Electronic Shifter	√	√	√	√	√	
2015\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2015\KK-Liberty	OCM -- Occupant Classification	√	√	√	√		
2015\KK-Liberty	SUNR -- Sunroof	√	√	√	√		
2015\KK-Liberty	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2015\KK-Liberty	AMP -- Amplifier	√	√	√	√		
2015\KK-Liberty	HFM -- Hands Free Module	√	√	√	√	√	
2015\KL-Cherokee	ECM -- Engine Control Module	√	√	√	√	√	0041
2015\KL-Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2015\KL-Cherokee	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\KL-Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\KL-Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2015\KL-Cherokee	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\KL-Cherokee	EPB -- Electrical Parking Brake	√	√	√	√		
2015\KL-Cherokee	BCM -- Body Controller	√	√	√	√	√	
2015\KL-Cherokee	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\KL-Cherokee	ESL -- Electronic Steering Lock	√	√	√	√		
2015\KL-Cherokee	EPS -- Electric Power Steering	√	√	√	√		
2015\KL-Cherokee	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\KL-Cherokee	RADIO -- Radio	√	√	√	√	√	
2015\KL-Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\KL-Cherokee	ACC -- Adaptive Cruise Control	√	√	√	√		
2015\KL-Cherokee	PTU -- Power Transfer Unit	√	√	√			
2015\KL-Cherokee	SCCM -- Steering Column Control Module	√	√	√	√	√	
2015\KL-Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2015\KL-Cherokee	DDM -- Driver Door Module	√	√	√	√	√	

2015\KL-Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2015\KL-Cherokee	PAM -- Park Assist Module	√	√	√	√	√	
2015\KL-Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2015\KL-Cherokee	PLGM -- Power Liftgate Module	√	√	√	√	√	
2015\KL-Cherokee	OCM -- Occupant Classification	√	√	√	√		
2015\KL-Cherokee	AHLM -- Headlamp Leveling	√	√	√	√		
2015\KL-Cherokee	AMP -- Amplifier	√	√	√	√		
2015\KL-Cherokee	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2015\KL-Cherokee	FFCM -- Forward Facing Camera Module	√	√	√	√		
2015\KL-Cherokee	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2015\KL-Cherokee	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2015\KL-Cherokee	RDM -- Rear Drive Module	√	√	√			
2015\KL-Cherokee	DTV -- Digital Television	√	√	√	√	√	
2015\LA-Challenger	ECM -- Engine Control Module	√	√	√	√	√	
2015\LA-Challenger	TCM -- Transmission Control Module	√	√	√	√		
2015\LA-Challenger	ABS -- Anti Lock Brakes	√	√	√	√	√	0001
2015\LA-Challenger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\LA-Challenger	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\LA-Challenger	TPM -- Tire Pressure Monitor	√	√	√	√		
2015\LA-Challenger	BCM -- Body Controller	√	√	√	√	√	
2015\LA-Challenger	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\LA-Challenger	EPS -- Electric Power Steering	√	√	√	√		
2015\LA-Challenger	PTS -- Parktronics	√	√	√	√		
2015\LA-Challenger	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\LA-Challenger	RADIO -- Radio	√	√	√	√	√	
2015\LA-Challenger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\LA-Challenger	ACC -- Adaptive Cruise Control	√	√	√	√		
2015\LA-Challenger	SCCM -- Steering Column Control Module	√	√	√	√		
2015\LA-Challenger	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\LA-Challenger	DDM -- Driver Door Module	√	√	√	√	√	
2015\LA-Challenger	PDM -- Passenger Door Module	√	√	√	√	√	
2015\LA-Challenger	ESM -- Electronic Shifter	√	√	√	√	√	
2015\LA-Challenger	AMP -- Amplifier	√	√	√	√		
2015\LA-Challenger	HSM -- Heated Seat Module	√	√	√	√	√	
2015\LA-Challenger	ADCM -- Active Damping Control Module	√	√	√	√		
2015\LA-Challenger	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2015\LA-Challenger	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2015\LD-Charger	ECM -- Engine Control Module	√	√	√	√	√	
2015\LD-Charger	TCM -- Transmission Control Module	√	√	√	√		
2015\LD-Charger	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\LD-Charger	ABS -- Anti Lock Brakes	√	√	√	√	√	0001
2015\LD-Charger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\LD-Charger	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\LD-Charger	TPM -- Tire Pressure Monitor	√	√	√	√		
2015\LD-Charger	BCM -- Body Controller	√	√	√	√	√	



2015\LD-Charger	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\LD-Charger	EPS -- Electric Power Steering	√	√	√	√		
2015\LD-Charger	PTS -- Parktronics	√	√	√	√		
2015\LD-Charger	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\LD-Charger	RADIO -- Radio	√	√	√	√	√	
2015\LD-Charger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\LD-Charger	SCCM -- Steering Column Control Module	√	√	√	√		
2015\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\LD-Charger	DDM -- Driver Door Module	√	√	√	√	√	
2015\LD-Charger	PDM -- Passenger Door Module	√	√	√	√	√	
2015\LD-Charger	ESM -- Electronic Shifter	√	√	√	√	√	
2015\LD-Charger	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2015\LD-Charger	AMP -- Amplifier	√	√	√	√		
2015\LD-Charger	HSM -- Heated Seat Module	√	√	√	√	√	
2015\LD-Charger	ADCM -- Active Damping Control Module	√	√	√	√		
2015\LD-Charger	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2015\LD-Charger	FFCM -- Forward Facing Camera Module	√	√	√	√		
2015\LD-Charger	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2015\LD-Charger	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2015\LX-300,Charger,Magnum,Grand Voyager	ECM -- Engine Control Module	√	√	√	√	√	0041
2015\LX-300,Charger,Magnum,Grand Voyager	TCM -- Transmission Control Module	√	√	√	√		
2015\LX-300,Charger,Magnum,Grand Voyager	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	ABS -- Anti Lock Brakes	√	√	√	√	√	0001
2015\LX-300,Charger,Magnum,Grand Voyager	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\LX-300,Charger,Magnum,Grand Voyager	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	TPM -- Tire Pressure Monitor	√	√	√	√		
2015\LX-300,Charger,Magnum,Grand Voyager	BCM -- Body Controller	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	EPS -- Electric Power Steering	√	√	√	√		
2015\LX-300,Charger,Magnum,Grand Voyager	PTS -- Parktronics	√	√	√	√		
2015\LX-300,Charger,Magnum,Grand Voyager	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	RADIO -- Radio	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	

2015\LX-300,Charger,Magnum,Grand Voyager	AFLS -- Adaptive Front Lighting System	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	ACC -- Adaptive Cruise Control	√	√	√	√		
2015\LX-300,Charger,Magnum,Grand Voyager	SCCM -- Steering Column Control Module	√	√	√	√		
2015\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√		
2015\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2015\LX-300,Charger,Magnum,Grand Voyager	ADCM -- Active Damping Control Module	√	√	√	√		
2015\LX-300,Charger,Magnum,Grand Voyager	FFCM -- Forward Facing Camera Module	√	√	√	√		
2015\LX-300,Charger,Magnum,Grand Voyager	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2015\MK-Compass,Patriot	ECM -- Engine Control Module	√	√	√	√	√	
2015\MK-Compass,Patriot	TCM -- Transmission Control Module	√	√	√	√	√	
2015\MK-Compass,Patriot	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2015\MK-Compass,Patriot	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\MK-Compass,Patriot	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2015\MK-Compass,Patriot	CGW -- Central Gateway	√	√	√	√	√	0003
2015\MK-Compass,Patriot	WCM/TPMS -- Wireless Control	√	√	√	√		
2015\MK-Compass,Patriot	SAS -- Steering Angle Sensor	√	√	√	√		
2015\MK-Compass,Patriot	RADIO -- Radio	√	√	√	√	√	
2015\MK-Compass,Patriot	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\MK-Compass,Patriot	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2015\MK-Compass,Patriot	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2015\MK-Compass,Patriot	AMP -- Amplifier	√	√	√	√		
2015\MK-Compass,Patriot	HFM -- Hands Free Module	√	√	√	√	√	
2015\NY-Ypsilon	ECM -- Engine Control Module	√	√	√	√	√	
2015\NY-Ypsilon	TCM -- Transmission Control Module	√	√	√	√	√	
2015\NY-Ypsilon	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\NY-Ypsilon	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2015\NY-Ypsilon	IPC -- Instrument Panel Cluster	√	√	√	√	√	0043
2015\NY-Ypsilon	BCM -- Body Controller	√	√	√	√	√	
2015\NY-Ypsilon	EPS -- Electric Power Steering	√	√	√	√		

2015\NY-Ypsilon	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\NY-Ypsilon	AHM -- Additional Heater Module	√	√	√	√	√	
2015\PF-Dart	ECM -- Engine Control Module	√	√	√	√	√	
2015\PF-Dart	TCM -- Transmission Control Module	√	√	√	√	√	
2015\PF-Dart	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\PF-Dart	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\PF-Dart	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\PF-Dart	BCM -- Body Controller	√	√	√	√	√	
2015\PF-Dart	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\PF-Dart	EPS -- Electric Power Steering	√	√	√	√		
2015\PF-Dart	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\PF-Dart	RADIO -- Radio	√	√	√	√	√	
2015\PF-Dart	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\PF-Dart	SCCM -- Steering Column Control Module	√	√	√	√		
2015\PF-Dart	PAM -- Park Assist Module	√	√	√	√		
2015\PF-Dart	ESM -- Electronic Shifter	√	√	√	√		
2015\PF-Dart	OCM -- Occupant Classification	√	√	√	√		
2015\PF-Dart	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2015\PF-Dart	CTM -- Convergence Telematic Module	√	√	√	√		
2015\PF-Dart	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2015\PF-Dart	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	
2015\PF-Dart	EDM -- External Disc Module	√	√	√		√	
2015\RT-Caravan,Town & Country	ECM -- Engine Control Module	√	√	√	√	√	
2015\RT-Caravan,Town & Country	TCM -- Transmission Control Module	√	√	√	√	√	
2015\RT-Caravan,Town & Country	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2015\RT-Caravan,Town & Country	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\RT-Caravan,Town & Country	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2015\RT-Caravan,Town & Country	TPM -- Tire Pressure Monitor	√	√	√	√		
2015\RT-Caravan,Town & Country	CGW -- Central Gateway	√	√	√	√	√	0003
2015\RT-Caravan,Town & Country	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2015\RT-Caravan,Town & Country	SAS -- Steering Angle Sensor	√	√	√	√		
2015\RT-Caravan,Town & Country	PTS -- Parktronic	√	√	√	√	√	
2015\RT-Caravan,Town & Country	RADIO -- Radio	√	√	√	√	√	
2015\RT-Caravan,Town & Country	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\RT-Caravan,Town & Country	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\RT-Caravan,Town & Country	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2015\RT-Caravan,Town & Country	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2015\RT-Caravan,Town & Country	DMFR -- Door Module Front Right	√	√	√	√	√	
2015\RT-Caravan,Town & Country	DMFL -- Door Module Front Left	√	√	√	√	√	
2015\RT-Caravan,Town & Country	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2015\RT-Caravan,Town & Country	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2015\RT-Caravan,Town & Country	PLGM -- Power Liftgate Module	√	√	√	√	√	
2015\RT-Caravan,Town & Country	FSM -- Fold Stow Module	√	√	√	√	√	
2015\RT-Caravan,Town & Country	SUNR -- Sunroof	√	√	√	√	√	
2015\RT-Caravan,Town & Country	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	

2015\RT-Caravan,Town & Country	AHBM -- Automatic High Beam	√	√	√	√	√	
2015\RT-Caravan,Town & Country	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2015\RT-Caravan,Town & Country	DVD -- DVD Changer	√	√	√	√		
2015\RT-Caravan,Town & Country	AMP -- Amplifier	√	√	√	√		
2015\RT-Caravan,Town & Country	HFM -- Hands Free Module	√	√	√	√	√	
2015\RT-Caravan,Town & Country	VES2 -- Second Row Screen	√	√	√	√	√	
2015\RT-Caravan,Town & Country	VES3 -- Last Row Screen	√	√	√	√	√	
2015\RT-Caravan,Town & Country	HSM -- Heated Seat Module	√	√	√	√	√	
2015\RT-Caravan,Town & Country	PEM -- Passive Entry Module	√	√	√	√		
2015\RT-Caravan,Town & Country	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2015\RT-Caravan,Town & Country	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2015\UF-200	ECM -- Engine Control Module	√	√	√	√	√	
2015\UF-200	TCM -- Transmission Control Module	√	√	√	√		
2015\UF-200	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\UF-200	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\UF-200	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2015\UF-200	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\UF-200	EPB -- Electrical Parking Brake	√	√	√	√		
2015\UF-200	BCM -- Body Controller	√	√	√	√	√	
2015\UF-200	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\UF-200	EPS -- Electric Power Steering	√	√	√	√		
2015\UF-200	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\UF-200	RADIO -- Radio	√	√	√	√	√	
2015\UF-200	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\UF-200	ACC -- Adaptive Cruise Control	√	√	√	√		
2015\UF-200	PTU -- Power Transfer Unit	√	√	√			
2015\UF-200	SCCM -- Steering Column Control Module	√	√	√	√		
2015\UF-200	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2015\UF-200	DDM -- Driver Door Module	√	√	√	√	√	
2015\UF-200	PDM -- Passenger Door Module	√	√	√	√	√	
2015\UF-200	PAM -- Park Assist Module	√	√	√	√	√	
2015\UF-200	ESM -- Electronic Shifter	√	√	√	√		
2015\UF-200	OCM -- Occupant Classification	√	√	√	√		
2015\UF-200	AMP -- Amplifier	√	√	√	√		
2015\UF-200	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2015\UF-200	FFCM -- Forward Facing Camera Module	√	√	√	√		
2015\UF-200	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2015\UF-200	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2015\UF-200	RRM -- Radio Receiver Module	√	√	√	√		
2015\VF-ProMaster	ECM -- Engine Control Module	√	√	√	√	√	0011, 0041
2015\VF-ProMaster	TCM -- Transmission Control Module	√	√	√	√	√	
2015\VF-ProMaster	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\VF-ProMaster	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\VF-ProMaster	IPC -- Instrument Panel Cluster	√	√	√	√	√	

2015\VF-ProMaster	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2015\VF-ProMaster	BCM -- Body Controller	√	√	√	√	√	
2015\VF-ProMaster	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\VF-ProMaster	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2015\VF-ProMaster	PAM -- Park Assist Module	√	√	√	√		
2015\VM-ProMaster City	ECM -- Engine Control Module	√	√	√	√	√	
2015\VM-ProMaster City	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\VM-ProMaster City	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\VM-ProMaster City	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\VM-ProMaster City	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2015\VM-ProMaster City	BCM -- Body Controller	√	√	√	√	√	
2015\VM-ProMaster City	RADIO -- Radio	√	√	√	√	√	
2015\VM-ProMaster City	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\VM-ProMaster City	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2015\VM-ProMaster City	PAM -- Park Assist Module	√	√	√	√		
2015\VM-ProMaster City	ESM -- Electronic Shifter	√	√	√	√	√	
2015\VM-ProMaster City	TTM -- Trailer tow module	√	√	√	√		
2015\WD-Durango	ECM -- Engine Control Module	√	√	√	√	√	
2015\WD-Durango	TCM -- Transmission Control Module	√	√	√	√		
2015\WD-Durango	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\WD-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\WD-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\WD-Durango	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\WD-Durango	TPM -- Tire Pressure Monitor	√	√	√	√		
2015\WD-Durango	BCM -- Body Controller	√	√	√	√	√	
2015\WD-Durango	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\WD-Durango	EPS -- Electric Power Steering	√	√	√	√		
2015\WD-Durango	PTS -- Parktronics	√	√	√	√	√	
2015\WD-Durango	ICS -- Integrated Center Stack	√	√	√	√		
2015\WD-Durango	RADIO -- Radio	√	√	√	√	√	
2015\WD-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\WD-Durango	HVACR -- Heat, Ventilation and A/C Rear	√	√	√	√	√	
2015\WD-Durango	ACC -- Adaptive Cruise Control	√	√	√	√		
2015\WD-Durango	SCCM -- Steering Column Control Module	√	√	√	√		
2015\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\WD-Durango	DDM -- Driver Door Module	√	√	√	√	√	
2015\WD-Durango	PDM -- Passenger Door Module	√	√	√	√	√	
2015\WD-Durango	ESM -- Electronic Shifter	√	√	√	√		
2015\WD-Durango	PLGM -- Power Liftgate Module	√	√	√	√	√	
2015\WD-Durango	AHLM -- Headlamp Leveling	√	√	√	√		
2015\WD-Durango	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2015\WD-Durango	AMP -- Amplifier	√	√	√	√		
2015\WD-Durango	VES2 -- Second Row Screen	√	√	√	√	√	
2015\WD-Durango	VES3 -- Last Row Screen	√	√	√	√	√	
2015\WD-Durango	HSM -- Heated Seat Module	√	√	√	√	√	

2015\WD-Durango	FFCM -- Forward Facing Camera Module	√	√	√	√		
2015\WD-Durango	LBSS -- Left Blind Spot Sensor	√	√	√			
2015\WD-Durango	RBSS -- Right Blind Spot Sensor	√	√	√			
2015\WD-Durango	EDM -- External Disc Module	√	√	√	√	√	
2015\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	
2015\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2015\WK-Grand Cherokee	DTCM -- Drive Train Control Module	√	√	√	√	√	
2015\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2015\WK-Grand Cherokee	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\WK-Grand Cherokee	TPM -- Tire Pressure Monitor	√	√	√	√		
2015\WK-Grand Cherokee	BCM -- Body Controller	√	√	√	√	√	
2015\WK-Grand Cherokee	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\WK-Grand Cherokee	EPS -- Electric Power Steering	√	√	√	√		
2015\WK-Grand Cherokee	PTS -- Parktronics	√	√	√	√	√	
2015\WK-Grand Cherokee	ICS -- Integrated Center Stack	√	√	√	√		
2015\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√	√	
2015\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\WK-Grand Cherokee	AFLS -- Adaptive Front Lighting System	√	√	√	√		
2015\WK-Grand Cherokee	ACC -- Adaptive Cruise Control	√	√	√	√		
2015\WK-Grand Cherokee	SCCM -- Steering Column Control Module	√	√	√	√		
2015\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2015\WK-Grand Cherokee	DDM -- Driver Door Module	√	√	√	√	√	
2015\WK-Grand Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2015\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√		
2015\WK-Grand Cherokee	PLGM -- Power Liftgate Module	√	√	√	√	√	
2015\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2015\WK-Grand Cherokee	AMP -- Amplifier	√	√	√	√		
2015\WK-Grand Cherokee	VES2 -- Second Row Screen	√	√	√	√	√	
2015\WK-Grand Cherokee	VES3 -- Last Row Screen	√	√	√	√	√	
2015\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2015\WK-Grand Cherokee	ADCM -- Active Damping Control Module	√	√	√	√		
2015\WK-Grand Cherokee	ASCM -- Air Suspension Control Module	√	√	√	√		
2015\WK-Grand Cherokee	ELSD -- Electronic Limited Slip Differential	√	√	√	√		
2015\WK-Grand Cherokee	FFCM -- Forward Facing Camera Module	√	√	√	√		
2015\WK-Grand Cherokee	LBSS -- Left Blind Spot Sensor	√	√	√			
2015\WK-Grand Cherokee	RBSS -- Right Blind Spot Sensor	√	√	√			
2015\WK-Grand Cherokee	EDM -- External Disc Module	√	√	√	√	√	
2015\WK-Grand Cherokee	ANC -- Active Noise Cancelation	√	√	√	√		
2015\ZD-Viper (Post-2013)	ECM -- Engine Control Module	√	√	√	√	√	
2015\ZD-Viper (Post-2013)	ABS -- Anti Lock Brakes	√	√	√	√	√	
2015\ZD-Viper (Post-2013)	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2015\ZD-Viper (Post-2013)	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2015\ZD-Viper (Post-2013)	TPM -- Tire Pressure Monitor	√	√	√	√		
2015\ZD-Viper (Post-2013)	BCM -- Body Controller	√	√	√	√	√	

2015\ZD-Viper (Post-2013)	RFH -- Radio Frequency Hub	√	√	√	√	√	
2015\ZD-Viper (Post-2013)	ICS -- Integrated Center Stack	√	√	√	√	√	
2015\ZD-Viper (Post-2013)	RADIO -- Radio	√	√	√	√	√	
2015\ZD-Viper (Post-2013)	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2015\ZD-Viper (Post-2013)	SCCM -- Steering Column Control Module	√	√	√	√		
2015\ZD-Viper (Post-2013)	DDM -- Driver Door Module	√	√	√	√	√	
2015\ZD-Viper (Post-2013)	PDM -- Passenger Door Module	√	√	√	√	√	
2015\ZD-Viper (Post-2013)	OCM -- Occupant Classification	√	√	√	√		
2015\ZD-Viper (Post-2013)	AMP -- Amplifier	√	√	√	√		
2015\ZD-Viper (Post-2013)	ADCM -- Active Damping Control Module	√	√	√	√		
2016\4C	ECM -- Engine Control Module	√	√	√	√	√	
2016\4C	TCM -- Transmission Control Module	√	√	√	√		
2016\4C	BCM -- Body Controller	√	√	√	√	√	
2016\4C	PAM -- Park Assist Module	√	√	√	√		
2016\4C	TPM -- Tire Pressure Monitor	√	√	√	√		
2016\4C	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\4C	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\4C	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\B1-Renegade	ESM -- Electronic Shifter	√	√	√	√	√	
2016\B1-Renegade	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\B1-Renegade	ESL -- Electronic Steering Lock		√	√	√		
2016\B1-Renegade	PAM -- Park Assist Module	√	√	√	√		
2016\B1-Renegade	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2016\B1-Renegade	RRM -- Radio Receiver Module	√	√	√	√	√	
2016\B1-Renegade	ECM -- Engine Control Module	√	√	√	√	√	0039, 0041
2016\B1-Renegade	TCM -- Transmission Control Module	√	√	√	√		
2016\B1-Renegade	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\B1-Renegade	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\B1-Renegade	ACC -- Adaptive Cruise Control	√	√	√	√	√	
2016\B1-Renegade	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\B1-Renegade	EPS -- Electric Power Steering	√	√	√	√		
2016\B1-Renegade	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2016\B1-Renegade	DTCM -- Drive Train Control Module	√	√	√	√		
2016\B1-Renegade	BCM -- Body Controller	√	√	√	√	√	
2016\B1-Renegade	AMP -- Amplifier	√	√	√	√	√	
2016\B1-Renegade	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2016\B1-Renegade	TTM -- Trailer tow module	√	√	√	√	√	
2016\B1-Renegade	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	
2016\B1-Renegade	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\BF-Fiat 500L	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\BF-Fiat 500L	TCM -- Transmission Control Module	√	√	√	√	√	
2016\BF-Fiat 500L	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2016\BF-Fiat 500L	ECM -- Engine Control Module	√	√	√	√	√	
2016\BF-Fiat 500L	PAM -- Park Assist Module	√	√	√	√		
2016\BF-Fiat 500L	EPS -- Electric Power Steering	√	√	√	√		

2016\BF-Fiat 500L	ABS -- Anti Lock Brakes	√	√	√	√		
2016\BF-Fiat 500L	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2016\BF-Fiat 500L	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\BF-Fiat 500L	BCM -- Body Controller	√	√	√	√	√	
2016\BF-Fiat 500L	ESM -- Electronic Shifter	√	√	√	√	√	
2016\BF-Fiat 500L	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\BQ-Renegade	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2016\BQ-Renegade	ESL -- Electronic Steering Lock		√	√	√		
2016\BQ-Renegade	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2016\BQ-Renegade	AMP -- Amplifier	√	√	√	√	√	
2016\BQ-Renegade	RRM -- Radio Receiver Module	√	√	√	√	√	
2016\BQ-Renegade	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	
2016\BQ-Renegade	ACC -- Adaptive Cruise Control	√	√	√	√	√	
2016\BQ-Renegade	TCM -- Transmission Control Module	√	√	√	√		
2016\BQ-Renegade	EPS -- Electric Power Steering	√	√	√	√		
2016\BQ-Renegade	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\BQ-Renegade	DTCM -- Drive Train Control Module	√	√	√	√		
2016\BQ-Renegade	BCM -- Body Controller	√	√	√	√	√	
2016\BQ-Renegade	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2016\BQ-Renegade	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\BQ-Renegade	PAM -- Park Assist Module	√	√	√	√		
2016\BQ-Renegade	ESM -- Electronic Shifter	√	√	√	√		
2016\BQ-Renegade	ECM -- Engine Control Module	√	√	√	√	√	0041, 0039, 0039, 0041
2016\BQ-Renegade	TTM -- Trailer tow module	√	√	√	√	√	
2016\BQ-Renegade	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\BQ-Renegade	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\BQ-Renegade	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\BU-Renegade	ECM -- Engine Control Module	√	√	√	√	√	0041, 0039, 0039, 0041
2016\BU-Renegade	TCM -- Transmission Control Module	√	√	√	√		
2016\BU-Renegade	HALF -- Haptical Lane Feedback	√	√	√	√		
2016\BU-Renegade	ESM -- Electronic Shifter	√	√	√	√	√	
2016\BU-Renegade	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\BU-Renegade	RRM -- Radio Receiver Module	√	√	√	√	√	
2016\BU-Renegade	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	
2016\BU-Renegade	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\BU-Renegade	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\BU-Renegade	ESL -- Electronic Steering Lock		√	√	√		
2016\BU-Renegade	PAM -- Park Assist Module	√	√	√	√		
2016\BU-Renegade	AMP -- Amplifier	√	√	√	√	√	
2016\BU-Renegade	DTCM -- Drive Train Control Module	√	√	√	√		
2016\BU-Renegade	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2016\BU-Renegade	EPS -- Electric Power Steering	√	√	√	√		
2016\BU-Renegade	ACC -- Adaptive Cruise Control	√	√	√	√	√	
2016\BU-Renegade	BCM -- Body Controller	√	√	√	√	√	
2016\BU-Renegade	IPC -- Instrument Panel Cluster	√	√	√	√	√	



2016\BU-Renegade	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2016\BU-Renegade	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2016\BU-Renegade	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\BU-Renegade	TTM -- Trailer tow module	√	√	√	√	√	
2016\D2-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2016\D2-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2016\D2-Ram Truck	AMP -- Amplifier	√	√	√	√		
2016\D2-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2016\D2-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2016\D2-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2016\D2-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2016\D2-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\D2-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2016\D2-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\D2-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\D2-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2016\D2-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\D2-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2016\D2-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2016\D2-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2016\D2-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2016\D2-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\D2-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2016\D2-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2016\D2-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2016\D2-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2016\D2-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2016\DD-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2016\DD-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2016\DD-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\DD-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2016\DD-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2016\DD-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\DD-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\DD-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2016\DD-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2016\DD-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2016\DD-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2016\DD-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2016\DD-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\DD-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2016\DD-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\DD-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2016\DD-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2016\DD-Ram Truck	AMP -- Amplifier	√	√	√	√		

2016\DD-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2016\DD-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2016\DD-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2016\DD-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2016\DD-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	VGT -- Variable Geometry Turbo	√	√	√			
2016\DF-Ram 3500 Cab Chassis 10K	PTS -- Parktronics	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	DDM -- Driver Door Module	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	HSM -- Heated Seat Module	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	DTCM -- Drive Train Control Module	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	SCCM -- Steering Column Control Module	√	√	√	√		
2016\DF-Ram 3500 Cab Chassis 10K	AMP -- Amplifier	√	√	√	√		
2016\DF-Ram 3500 Cab Chassis 10K	DCU -- Dosing Control Unit	√	√	√			
2016\DF-Ram 3500 Cab Chassis 10K	TCM -- Transmission Control Module	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	RADIO -- Radio	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2016\DF-Ram 3500 Cab Chassis 10K	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	PDM -- Passenger Door Module	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	EDM -- External Disc Module	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2016\DF-Ram 3500 Cab Chassis 10K	ECM -- Engine Control Module	√	√	√	√	√	0041
2016\DJ-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\DJ-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\DJ-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\DJ-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2016\DJ-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2016\DJ-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2016\DJ-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2016\DJ-Ram Truck	AMP -- Amplifier	√	√	√	√		
2016\DJ-Ram Truck	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2016\DJ-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\DJ-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\DJ-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2016\DJ-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2016\DJ-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2016\DJ-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2016\DJ-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2016\DJ-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2016\DJ-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041

2016\DJ-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2016\DJ-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2016\DJ-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2016\DJ-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2016\DJ-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2016\DJ-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2016\DP-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2016\DP-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2016\DP-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2016\DP-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2016\DP-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2016\DP-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2016\DP-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\DP-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2016\DP-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2016\DP-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\DP-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2016\DP-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\DP-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\DP-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2016\DP-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\DP-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2016\DP-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2016\DP-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2016\DP-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2016\DP-Ram Truck	AMP -- Amplifier	√	√	√	√		
2016\DP-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2016\DP-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2016\DS-Ram Truck	AMP -- Amplifier	√	√	√	√		
2016\DS-Ram Truck	EPS -- Electric Power Steering	√	√	√	√		
2016\DS-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\DS-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\DS-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2016\DS-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2016\DS-Ram Truck	ESM -- Electronic Shifter	√	√	√	√		
2016\DS-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2016\DS-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2016\DS-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2016\DS-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2016\DS-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2016\DS-Ram Truck	TCM -- Transmission Control Module	√	√	√	√		
2016\DS-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\DS-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\DS-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2016\DS-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	

2016\DS-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\DS-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2016\DS-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2016\DS-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2016\DS-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2016\DS-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2016\DX-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2016\DX-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2016\DX-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2016\DX-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2016\DX-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2016\DX-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2016\DX-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\DX-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\DX-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\DX-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2016\DX-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2016\DX-Ram Truck	PTS -- Parktronic	√	√	√	√	√	
2016\DX-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2016\DX-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2016\DX-Ram Truck	EPS -- Electric Power Steering	√	√	√	√		
2016\DX-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2016\DX-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2016\DX-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2016\DX-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2016\DX-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2016\DX-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\DX-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2016\DX-Ram Truck	ESM -- Electronic Shifter	√	√	√	√		
2016\DX-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2016\DX-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\DX-Ram Truck	AMP -- Amplifier	√	√	√	√		
2016\FB-500X	ECM -- Engine Control Module	√	√	√	√	√	0041, 0039, 0039
2016\FB-500X	HALF -- Haptical Lane Feedback	√	√	√	√		
2016\FB-500X	BCM -- Body Controller	√	√	√	√	√	
2016\FB-500X	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2016\FB-500X	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2016\FB-500X	TCM -- Transmission Control Module	√	√	√	√		
2016\FB-500X	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\FB-500X	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2016\FB-500X	DTCM -- Drive Train Control Module	√	√	√	√		
2016\FB-500X	ACC -- Adaptive Cruise Control	√	√	√	√	√	
2016\FB-500X	EPS -- Electric Power Steering	√	√	√	√		
2016\FB-500X	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\FB-500X	ESM -- Electronic Shifter	√	√	√	√	√	

2016\FB-500X	ESL -- Electronic Steering Lock		√	√	√		
2016\FB-500X	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\FB-500X	RRM -- Radio Receiver Module	√	√	√	√	√	
2016\FB-500X	PAM -- Park Assist Module	√	√	√	√		
2016\FB-500X	AMP -- Amplifier	√	√	√	√	√	
2016\FB-500X	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	
2016\FB-500X	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\FF-500	EVCU -- Electronic Vehicle Control Unit	√	√	√	√	√	0022
2016\FF-500	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2016\FF-500	TCM -- Transmission Control Module	√	√	√	√	√	
2016\FF-500	RBC -- Regenerative Brake Controller	√	√	√	√		
2016\FF-500	ECM -- Engine Control Module	√	√	√	√	√	
2016\FF-500	OBCM -- On Board Charging Module	√	√	√	√		
2016\FF-500	PTS -- Parktronics	√	√	√	√		
2016\FF-500	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\FF-500	PIM -- Power Inverter Module	√	√	√	√		
2016\FF-500	EAC -- Electric A/C Compressor	√	√	√	√		
2016\FF-500	ESM -- Electronic Shifter	√	√	√			
2016\FF-500	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\FF-500	EPS -- Electric Power Steering	√	√	√	√		
2016\FF-500	VTM -- Vehicle Tracking Module	√	√	√	√		
2016\FF-500	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\FF-500	BPCM -- Battery Pack Control Module	√	√	√	√	√	0018, 0025, 0024, 0040, 0023, 0042, 0033, 0020, 0045, 0019
2016\FF-500	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2016\FF-500	BCM -- Body Controller	√	√	√	√	√	
2016\FF-500	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\J8-Wrangler	RADIO -- Radio	√	√	√	√	√	
2016\J8-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2016\J8-Wrangler	ESM -- Electronic Shifter	√	√	√	√	√	
2016\J8-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2016\J8-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2016\J8-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2016\J8-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2016\J8-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	0015, 0014, 0032, 0044
2016\JC-Journey	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\JC-Journey	HSM -- Heated Seat Module	√	√	√	√	√	
2016\JC-Journey	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\JC-Journey	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\JC-Journey	VTM -- Vehicle Tracking Module	√	√	√	√		

2016JC-Journey	PDM -- Passenger Door Module	√	√	√	√	√	
2016JC-Journey	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2016JC-Journey	SCCM -- Steering Column Control Module	√	√	√	√		
2016JC-Journey	DTCM -- Drive Train Control Module	√	√	√	√	√	
2016JC-Journey	HFM -- Hands Free Module	√	√	√	√		
2016JC-Journey	TGW -- Telematic Gateway Radio	√	√	√	√		
2016JC-Journey	VES3 -- Last Row Screen	√	√	√	√	√	
2016JC-Journey	TCM -- Transmission Control Module	√	√	√	√	√	
2016JC-Journey	ICS -- Integrated Center Stack	√	√	√	√	√	
2016JC-Journey	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016JC-Journey	BCM -- Body Controller	√	√	√	√	√	
2016JC-Journey	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2016JC-Journey	ECM -- Engine Control Module	√	√	√	√	√	0041
2016JC-Journey	TPM -- Tire Pressure Monitor	√	√	√	√		
2016JC-Journey	DDM -- Driver Door Module	√	√	√	√	√	
2016JC-Journey	PTS -- Parktronics	√	√	√	√	√	
2016JC-Journey	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016JC-Journey	AMP -- Amplifier	√	√	√	√		
2016JF-Freemont	DTCM -- Drive Train Control Module	√	√	√	√	√	
2016JF-Freemont	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016JF-Freemont	HSM -- Heated Seat Module	√	√	√	√	√	
2016JF-Freemont	BCM -- Body Controller	√	√	√	√	√	
2016JF-Freemont	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2016JF-Freemont	HFM -- Hands Free Module	√	√	√	√		
2016JF-Freemont	SCCM -- Steering Column Control Module	√	√	√	√		
2016JF-Freemont	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2016JF-Freemont	TCM -- Transmission Control Module	√	√	√	√	√	
2016JF-Freemont	ECM -- Engine Control Module	√	√	√	√	√	0041
2016JF-Freemont	DDM -- Driver Door Module	√	√	√	√	√	
2016JF-Freemont	VTM -- Vehicle Tracking Module	√	√	√	√		
2016JF-Freemont	AMP -- Amplifier	√	√	√	√		
2016JF-Freemont	ICS -- Integrated Center Stack	√	√	√	√	√	
2016JF-Freemont	PDM -- Passenger Door Module	√	√	√	√	√	
2016JF-Freemont	TPM -- Tire Pressure Monitor	√	√	√	√		
2016JF-Freemont	TGW -- Telematic Gateway Radio	√	√	√	√		
2016JF-Freemont	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016JF-Freemont	VES3 -- Last Row Screen	√	√	√	√	√	
2016JF-Freemont	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016JF-Freemont	PTS -- Parktronics	√	√	√	√	√	
2016JF-Freemont	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016JK-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	0015, 0014, 0032, 0044
2016JK-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2016JK-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	

2016\JK-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2016\JK-Wrangler	TPM -- Tire Pressure Monitor	√	√	√	√		
2016\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2016\JK-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\JK-Wrangler	AMP -- Amplifier	√	√	√	√		
2016\JK-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2016\JK-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2016\JK-Wrangler	ASBS -- Automatic Sway Bar System	√	√	√	√		
2016\JK-Wrangler	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2016\JK-Wrangler	HFM -- Hands Free Module	√	√	√	√	√	
2016\JK-Wrangler	RADIO -- Radio	√	√	√	√	√	
2016\JK-Wrangler	ESM -- Electronic Shifter	√	√	√	√	√	
2016\JK-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2016\KL-Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2016\KL-Cherokee	DTV -- Digital Television	√	√	√	√	√	
2016\KL-Cherokee	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\KL-Cherokee	FFCM -- Forward Facing Camera Module	√	√	√	√		
2016\KL-Cherokee	PAM -- Park Assist Module	√	√	√	√	√	
2016\KL-Cherokee	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2016\KL-Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\KL-Cherokee	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\KL-Cherokee	EPS -- Electric Power Steering	√	√	√	√		
2016\KL-Cherokee	EDM -- External Disc Module	√	√	√		√	
2016\KL-Cherokee	DTCM -- Drive Train Control Module	√	√	√	√	√	
2016\KL-Cherokee	OCM -- Occupant Classification	√	√	√	√		
2016\KL-Cherokee	PTU -- Power Transfer Unit	√	√	√			
2016\KL-Cherokee	ACC -- Adaptive Cruise Control	√	√	√	√		
2016\KL-Cherokee	PLGM -- Power Liftgate Module	√	√	√	√	√	
2016\KL-Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2016\KL-Cherokee	BCM -- Body Controller	√	√	√	√	√	
2016\KL-Cherokee	AMP -- Amplifier	√	√	√	√		
2016\KL-Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2016\KL-Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2016\KL-Cherokee	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2016\KL-Cherokee	DDM -- Driver Door Module	√	√	√	√	√	
2016\KL-Cherokee	EPB -- Electrical Parking Brake	√	√	√	√		
2016\KL-Cherokee	ESL -- Electronic Steering Lock	√	√	√	√		
2016\KL-Cherokee	SCCM -- Steering Column Control Module	√	√	√	√	√	
2016\KL-Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2016\KL-Cherokee	ECM -- Engine Control Module	√	√	√	√	√	0041
2016\KL-Cherokee	RADIO -- Radio	√	√	√	√	√	
2016\KL-Cherokee	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\KL-Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\KL-Cherokee	RDM -- Rear Drive Module	√	√	√			
2016\KL-Cherokee	RBSS -- Right Blind Spot Sensor	√	√	√	√		

2016\LA-Challenger	ACC -- Adaptive Cruise Control	√	√	√	√		
2016\LA-Challenger	TPM -- Tire Pressure Monitor	√	√	√	√		
2016\LA-Challenger	EPS -- Electric Power Steering	√	√	√	√		
2016\LA-Challenger	HSM -- Heated Seat Module	√	√	√	√	√	
2016\LA-Challenger	SCCM -- Steering Column Control Module	√	√	√	√		
2016\LA-Challenger	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2016\LA-Challenger	BCM -- Body Controller	√	√	√	√	√	
2016\LA-Challenger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\LA-Challenger	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2016\LA-Challenger	TCM -- Transmission Control Module	√	√	√	√		
2016\LA-Challenger	ABS -- Anti Lock Brakes	√	√	√	√	√	0001
2016\LA-Challenger	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2016\LA-Challenger	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\LA-Challenger	ESM -- Electronic Shifter	√	√	√	√	√	
2016\LA-Challenger	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\LA-Challenger	AMP -- Amplifier	√	√	√	√	√	
2016\LA-Challenger	RADIO -- Radio	√	√	√	√	√	
2016\LA-Challenger	ADCM -- Active Damping Control Module	√	√	√	√		
2016\LA-Challenger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\LA-Challenger	DDM -- Driver Door Module	√	√	√	√	√	
2016\LA-Challenger	PDM -- Passenger Door Module	√	√	√	√	√	
2016\LA-Challenger	ECM -- Engine Control Module	√	√	√	√	√	0041
2016\LA-Challenger	PTS -- Parktronics	√	√	√	√	√	
2016\LD-Charger	TPM -- Tire Pressure Monitor	√	√	√	√		
2016\LD-Charger	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\LD-Charger	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2016\LD-Charger	PTS -- Parktronics	√	√	√	√	√	
2016\LD-Charger	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\LD-Charger	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2016\LD-Charger	HSM -- Heated Seat Module	√	√	√	√	√	
2016\LD-Charger	SCCM -- Steering Column Control Module	√	√	√	√		
2016\LD-Charger	ACC -- Adaptive Cruise Control	√	√	√	√		
2016\LD-Charger	EPS -- Electric Power Steering	√	√	√	√		
2016\LD-Charger	ADCM -- Active Damping Control Module	√	√	√	√		
2016\LD-Charger	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2016\LD-Charger	AMP -- Amplifier	√	√	√	√		
2016\LD-Charger	DSM -- Display Screen Module	√	√	√	√		
2016\LD-Charger	ESM -- Electronic Shifter	√	√	√	√	√	
2016\LD-Charger	RADIO -- Radio	√	√	√	√	√	
2016\LD-Charger	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\LD-Charger	DTCM -- Drive Train Control Module	√	√	√	√	√	
2016\LD-Charger	TCM -- Transmission Control Module	√	√	√	√		
2016\LD-Charger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\LD-Charger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\LD-Charger	ECM -- Engine Control Module	√	√	√	√	√	0041



2016\LD-Charger	BCM -- Body Controller	√	√	√	√	√	
2016\LD-Charger	ABS -- Anti Lock Brakes	√	√	√	√	√	0001
2016\LD-Charger	DDM -- Driver Door Module	√	√	√	√	√	
2016\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2016\LD-Charger	PDM -- Passenger Door Module	√	√	√	√	√	
2016\LD-Charger	FFCM -- Forward Facing Camera Module	√	√	√	√		
2016\LD-Charger	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2016\LX-300,Charger,Magnum,Grand Voyager	RADIO -- Radio	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	EPS -- Electric Power Steering	√	√	√	√		
2016\LX-300,Charger,Magnum,Grand Voyager	BCM -- Body Controller	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	ECM -- Engine Control Module	√	√	√	√	√	0041
2016\LX-300,Charger,Magnum,Grand Voyager	ADCM -- Active Damping Control Module	√	√	√	√		
2016\LX-300,Charger,Magnum,Grand Voyager	AFLS -- Adaptive Front Lighting System	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	DTCM -- Drive Train Control Module	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	TPM -- Tire Pressure Monitor	√	√	√	√		
2016\LX-300,Charger,Magnum,Grand Voyager	ABS -- Anti Lock Brakes	√	√	√	√	√	0001
2016\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	SCCM -- Steering Column Control Module	√	√	√	√		
2016\LX-300,Charger,Magnum,Grand Voyager	ACC -- Adaptive Cruise Control	√	√	√	√		
2016\LX-300,Charger,Magnum,Grand Voyager	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	PTS -- Parktronics	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	TCM -- Transmission Control Module	√	√	√	√		

2016\LX-300,Charger,Magnum,Grand Voyager	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2016\LX-300,Charger,Magnum,Grand Voyager	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2016\LX-300,Charger,Magnum,Grand Voyager	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\LX-300,Charger,Magnum,Grand Voyager	FFCM -- Forward Facing Camera Module	√	√	√	√		
2016\MK-Compass,Patriot	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\MK-Compass,Patriot	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2016\MK-Compass,Patriot	RADIO -- Radio	√	√	√	√	√	
2016\MK-Compass,Patriot	TCM -- Transmission Control Module	√	√	√	√	√	
2016\MK-Compass,Patriot	SAS -- Steering Angle Sensor	√	√	√	√		
2016\MK-Compass,Patriot	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2016\MK-Compass,Patriot	ECM -- Engine Control Module	√	√	√	√	√	
2016\MK-Compass,Patriot	HFM -- Hands Free Module	√	√	√	√	√	
2016\MK-Compass,Patriot	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2016\MK-Compass,Patriot	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\MK-Compass,Patriot	CGW -- Central Gateway	√	√	√	√	√	0003
2016\MK-Compass,Patriot	WCM/TPMS -- Wireless Control	√	√	√	√		
2016\MK-Compass,Patriot	AMP -- Amplifier	√	√	√	√		
2016\MK-Compass,Patriot	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2016\NY-Ypsilon	IPC -- Instrument Panel Cluster	√	√	√	√	√	0043
2016\NY-Ypsilon	ECM -- Engine Control Module	√	√	√	√	√	
2016\NY-Ypsilon	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2016\NY-Ypsilon	AHM -- Additional Heater Module	√	√	√	√	√	
2016\NY-Ypsilon	TCM -- Transmission Control Module	√	√	√	√	√	
2016\NY-Ypsilon	EPS -- Electric Power Steering	√	√	√	√		
2016\NY-Ypsilon	BCM -- Body Controller	√	√	√	√	√	
2016\NY-Ypsilon	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\PF-Dart	CTM -- Convergence Telematic Module	√	√	√	√		
2016\PF-Dart	RADIO -- Radio	√	√	√	√	√	
2016\PF-Dart	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\PF-Dart	ECM -- Engine Control Module	√	√	√	√	√	
2016\PF-Dart	PAM -- Park Assist Module	√	√	√	√		
2016\PF-Dart	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2016\PF-Dart	SCCM -- Steering Column Control Module	√	√	√	√		
2016\PF-Dart	OCM -- Occupant Classification	√	√	√	√		
2016\PF-Dart	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\PF-Dart	EPS -- Electric Power Steering	√	√	√	√		

2016\PF-Dart	BCM -- Body Controller	√	√	√	√	√	
2016\PF-Dart	EDM -- External Disc Module	√	√	√		√	
2016\PF-Dart	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	
2016\PF-Dart	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\PF-Dart	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\PF-Dart	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\PF-Dart	AMP -- Amplifier	√	√	√	√		
2016\PF-Dart	TCM -- Transmission Control Module	√	√	√	√	√	
2016\PF-Dart	ESM -- Electronic Shifter	√	√	√	√		
2016\PF-Dart	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\PF-Dart	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2016\RT-Caravan,Town & Country	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2016\RT-Caravan,Town & Country	TPM -- Tire Pressure Monitor	√	√	√	√		
2016\RT-Caravan,Town & Country	SAS -- Steering Angle Sensor	√	√	√	√		
2016\RT-Caravan,Town & Country	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\RT-Caravan,Town & Country	ECM -- Engine Control Module	√	√	√	√	√	
2016\RT-Caravan,Town & Country	DVD -- DVD Changer	√	√	√	√		
2016\RT-Caravan,Town & Country	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2016\RT-Caravan,Town & Country	PEM -- Passive Entry Module	√	√	√	√		
2016\RT-Caravan,Town & Country	DMFL -- Door Module Front Left	√	√	√	√	√	
2016\RT-Caravan,Town & Country	VES2 -- Second Row Screen	√	√	√	√	√	
2016\RT-Caravan,Town & Country	RADIO -- Radio	√	√	√	√	√	
2016\RT-Caravan,Town & Country	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	
2016\RT-Caravan,Town & Country	PSDML -- Power Sliding Doors (Left)	√	√	√	√		
2016\RT-Caravan,Town & Country	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2016\RT-Caravan,Town & Country	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2016\RT-Caravan,Town & Country	HFM -- Hands Free Module	√	√	√	√	√	
2016\RT-Caravan,Town & Country	VES3 -- Last Row Screen	√	√	√	√	√	
2016\RT-Caravan,Town & Country	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\RT-Caravan,Town & Country	AMP -- Amplifier	√	√	√	√		
2016\RT-Caravan,Town & Country	DMFR -- Door Module Front Right	√	√	√	√	√	
2016\RT-Caravan,Town & Country	TCM -- Transmission Control Module	√	√	√	√	√	
2016\RT-Caravan,Town & Country	CGW -- Central Gateway	√	√	√	√	√	0003
2016\RT-Caravan,Town & Country	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2016\RT-Caravan,Town & Country	FSM -- Fold Stow Module	√	√	√	√	√	
2016\RT-Caravan,Town & Country	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2016\RT-Caravan,Town & Country	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2016\RT-Caravan,Town & Country	SUNR -- Sunroof	√	√	√	√	√	
2016\RT-Caravan,Town & Country	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2016\UF-200	OCM -- Occupant Classification	√	√	√	√		
2016\UF-200	PTU -- Power Transfer Unit	√	√	√			
2016\UF-200	EPB -- Electrical Parking Brake	√	√	√	√		
2016\UF-200	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2016\UF-200	PDM -- Passenger Door Module	√	√	√	√	√	

2016\UF-200	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\UF-200	FFCM -- Forward Facing Camera Module	√	√	√	√		
2016\UF-200	SCCM -- Steering Column Control Module	√	√	√	√		
2016\UF-200	TCM -- Transmission Control Module	√	√	√	√		
2016\UF-200	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2016\UF-200	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2016\UF-200	EPS -- Electric Power Steering	√	√	√	√		
2016\UF-200	ACC -- Adaptive Cruise Control	√	√	√	√		
2016\UF-200	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\UF-200	RRM -- Radio Receiver Module	√	√	√	√		
2016\UF-200	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2016\UF-200	ECM -- Engine Control Module	√	√	√	√	√	
2016\UF-200	DDM -- Driver Door Module	√	√	√	√	√	
2016\UF-200	AMP -- Amplifier	√	√	√	√		
2016\UF-200	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\UF-200	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\UF-200	RADIO -- Radio	√	√	√	√	√	
2016\UF-200	PAM -- Park Assist Module	√	√	√	√	√	
2016\UF-200	ESM -- Electronic Shifter	√	√	√	√		
2016\UF-200	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2016\UF-200	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\UF-200	BCM -- Body Controller	√	√	√	√	√	
2016\UF-200	DTCM -- Drive Train Control Module	√	√	√	√	√	
2016\VF-ProMaster	PAM -- Park Assist Module	√	√	√	√		
2016\VF-ProMaster	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\VF-ProMaster	RADIO -- Radio	√	√	√	√	√	
2016\VF-ProMaster	ECM -- Engine Control Module	√	√	√	√	√	0011, 0041
2016\VF-ProMaster	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2016\VF-ProMaster	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2016\VF-ProMaster	BCM -- Body Controller	√	√	√	√	√	
2016\VF-ProMaster	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\VF-ProMaster	TCM -- Transmission Control Module	√	√	√	√	√	
2016\VF-ProMaster	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\VM-ProMaster City	ECM -- Engine Control Module	√	√	√	√	√	
2016\VM-ProMaster City	TCM -- Transmission Control Module	√	√	√	√		
2016\VM-ProMaster City	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\VM-ProMaster City	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\VM-ProMaster City	BCM -- Body Controller	√	√	√	√	√	
2016\VM-ProMaster City	RADIO -- Radio	√	√	√	√	√	
2016\VM-ProMaster City	TTM -- Trailer tow module	√	√	√	√		
2016\VM-ProMaster City	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\VM-ProMaster City	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2016\VM-ProMaster City	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\VM-ProMaster City	ESM -- Electronic Shifter	√	√	√	√	√	
2016\VM-ProMaster City	TPM -- Tire Pressure Monitor	√	√	√	√	√	

2016\VM-ProMaster City	PAM -- Park Assist Module	√	√	√	√		
2016\WD-Durango	HSM -- Heated Seat Module	√	√	√	√	√	
2016\WD-Durango	PDM -- Passenger Door Module	√	√	√	√	√	
2016\WD-Durango	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\WD-Durango	BCM -- Body Controller	√	√	√	√	√	
2016\WD-Durango	LBSS -- Left Blind Spot Sensor	√	√	√			
2016\WD-Durango	VES3 -- Last Row Screen	√	√	√	√	√	
2016\WD-Durango	SCCM -- Steering Column Control Module	√	√	√	√		
2016\WD-Durango	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\WD-Durango	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2016\WD-Durango	PLGM -- Power Liftgate Module	√	√	√	√	√	
2016\WD-Durango	ACC -- Adaptive Cruise Control	√	√	√	√		
2016\WD-Durango	AHLM -- Headlamp Leveling	√	√	√	√		
2016\WD-Durango	TCM -- Transmission Control Module	√	√	√	√		
2016\WD-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\WD-Durango	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\WD-Durango	ELSD -- Electronic Limited Slip Differential	√	√	√	√		
2016\WD-Durango	HVACR -- Heat, Ventilation and A/C Rear	√	√	√	√	√	
2016\WD-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\WD-Durango	VES2 -- Second Row Screen	√	√	√	√	√	
2016\WD-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\WD-Durango	EDM -- External Disc Module	√	√	√	√	√	
2016\WD-Durango	DDM -- Driver Door Module	√	√	√	√	√	
2016\WD-Durango	PTS -- Parktronic	√	√	√	√	√	
2016\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2016\WD-Durango	EPS -- Electric Power Steering	√	√	√	√		
2016\WD-Durango	ECM -- Engine Control Module	√	√	√	√	√	0041
2016\WD-Durango	FFCM -- Forward Facing Camera Module	√	√	√	√		
2016\WD-Durango	AMP -- Amplifier	√	√	√	√		
2016\WD-Durango	RBSS -- Right Blind Spot Sensor	√	√	√			
2016\WD-Durango	RADIO -- Radio	√	√	√	√	√	
2016\WD-Durango	ESM -- Electronic Shifter	√	√	√	√		
2016\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2016\WK-Grand Cherokee	DDM -- Driver Door Module	√	√	√	√	√	
2016\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2016\WK-Grand Cherokee	ADCM -- Active Damping Control Module	√	√	√	√		
2016\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2016\WK-Grand Cherokee	TPM -- Tire Pressure Monitor	√	√	√	√		
2016\WK-Grand Cherokee	AFLS -- Adaptive Front Lighting System	√	√	√	√		
2016\WK-Grand Cherokee	PTS -- Parktronic	√	√	√	√	√	
2016\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√	√	
2016\WK-Grand Cherokee	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\WK-Grand Cherokee	ELSD -- Electronic Limited Slip Differential	√	√	√	√		
2016\WK-Grand Cherokee	ACC -- Adaptive Cruise Control	√	√	√	√		

2016\WK-Grand Cherokee	EPS -- Electric Power Steering	√	√	√	√		
2016\WK-Grand Cherokee	RBSS -- Right Blind Spot Sensor	√	√	√			
2016\WK-Grand Cherokee	EDM -- External Disc Module	√	√	√	√	√	
2016\WK-Grand Cherokee	VES3 -- Last Row Screen	√	√	√	√	√	
2016\WK-Grand Cherokee	DTV -- Digital Television	√	√	√	√	√	
2016\WK-Grand Cherokee	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	0041
2016\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2016\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2016\WK-Grand Cherokee	FFCM -- Forward Facing Camera Module	√	√	√	√		
2016\WK-Grand Cherokee	PLGM -- Power Liftgate Module	√	√	√	√	√	
2016\WK-Grand Cherokee	ANC -- Active Noise Cancelation	√	√	√	√		
2016\WK-Grand Cherokee	DTCM -- Drive Train Control Module	√	√	√	√	√	
2016\WK-Grand Cherokee	BCM -- Body Controller	√	√	√	√	√	
2016\WK-Grand Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2016\WK-Grand Cherokee	AMP -- Amplifier	√	√	√	√	√	
2016\WK-Grand Cherokee	ASCM -- Air Suspension Control Module	√	√	√	√		
2016\WK-Grand Cherokee	LBSS -- Left Blind Spot Sensor	√	√	√			
2016\WK-Grand Cherokee	VES2 -- Second Row Screen	√	√	√	√	√	
2016\WK-Grand Cherokee	SCCM -- Steering Column Control Module	√	√	√	√		
2016\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2016\ZD-Viper (Post-2013)	TPM -- Tire Pressure Monitor	√	√	√	√		
2016\ZD-Viper (Post-2013)	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2016\ZD-Viper (Post-2013)	ECM -- Engine Control Module	√	√	√	√	√	
2016\ZD-Viper (Post-2013)	AMP -- Amplifier	√	√	√	√		
2016\ZD-Viper (Post-2013)	ICS -- Integrated Center Stack	√	√	√	√	√	
2016\ZD-Viper (Post-2013)	DDM -- Driver Door Module	√	√	√	√	√	
2016\ZD-Viper (Post-2013)	RFH -- Radio Frequency Hub	√	√	√	√	√	
2016\ZD-Viper (Post-2013)	PDM -- Passenger Door Module	√	√	√	√	√	
2016\ZD-Viper (Post-2013)	ABS -- Anti Lock Brakes	√	√	√	√	√	
2016\ZD-Viper (Post-2013)	OCM -- Occupant Classification	√	√	√	√		
2016\ZD-Viper (Post-2013)	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2016\ZD-Viper (Post-2013)	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2016\ZD-Viper (Post-2013)	SCCM -- Steering Column Control Module	√	√	√	√		
2016\ZD-Viper (Post-2013)	BCM -- Body Controller	√	√	√	√	√	
2016\ZD-Viper (Post-2013)	RADIO -- Radio	√	√	√	√	√	
2016\ZD-Viper (Post-2013)	ADCM -- Active Damping Control Module	√	√	√	√		
2017\4C	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\4C	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\4C	PAM -- Park Assist Module	√	√	√	√		
2017\4C	ECM -- Engine Control Module	√	√	√	√	√	
2017\4C	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\4C	TCM -- Transmission Control Module	√	√	√	√		
2017\4C	BCM -- Body Controller	√	√	√	√	√	

2017\4C	TPM -- Tire Pressure Monitor	√	√	√	√		
2017\B1-Renegade	ACC -- Adaptive Cruise Control	√	√	√	√	√	
2017\B1-Renegade	PAM -- Park Assist Module	√	√	√	√		
2017\B1-Renegade	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2017\B1-Renegade	TCM -- Transmission Control Module	√	√	√	√		
2017\B1-Renegade	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2017\B1-Renegade	TTM -- Trailer tow module	√	√	√	√	√	
2017\B1-Renegade	EPS -- Electric Power Steering	√	√	√	√		
2017\B1-Renegade	AMP -- Amplifier	√	√	√	√	√	
2017\B1-Renegade	ECM -- Engine Control Module	√	√	√	√	√	0041, 0039, 0039
2017\B1-Renegade	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2017\B1-Renegade	BCM -- Body Controller	√	√	√	√	√	
2017\B1-Renegade	RRM -- Radio Receiver Module	√	√	√	√	√	
2017\B1-Renegade	ESM -- Electronic Shifter	√	√	√	√	√	
2017\B1-Renegade	DTCM -- Drive Train Control Module	√	√	√	√		
2017\B1-Renegade	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\B1-Renegade	HALF -- Haptical Lane Feedback	√	√	√	√		
2017\B1-Renegade	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\B1-Renegade	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\B1-Renegade	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\B1-Renegade	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	
2017\B1-Renegade	ESL -- Electronic Steering Lock		√	√	√		
2017\BF-Fiat 500L	PAM -- Park Assist Module	√	√	√	√		
2017\BF-Fiat 500L	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\BF-Fiat 500L	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2017\BF-Fiat 500L	ABS -- Anti Lock Brakes	√	√	√	√		
2017\BF-Fiat 500L	ECM -- Engine Control Module	√	√	√	√	√	
2017\BF-Fiat 500L	EPS -- Electric Power Steering	√	√	√	√		
2017\BF-Fiat 500L	TCM -- Transmission Control Module	√	√	√	√	√	
2017\BF-Fiat 500L	ESM -- Electronic Shifter	√	√	√	√	√	
2017\BF-Fiat 500L	BCM -- Body Controller	√	√	√	√	√	
2017\BF-Fiat 500L	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2017\BF-Fiat 500L	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\BF-Fiat 500L	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\BU-Renegade	RRM -- Radio Receiver Module	√	√	√	√	√	
2017\BU-Renegade	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\BU-Renegade	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\BU-Renegade	EPS -- Electric Power Steering	√	√	√	√		
2017\BU-Renegade	TCM -- Transmission Control Module	√	√	√	√		
2017\BU-Renegade	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2017\BU-Renegade	DTCM -- Drive Train Control Module	√	√	√	√		
2017\BU-Renegade	ESL -- Electronic Steering Lock		√	√	√		
2017\BU-Renegade	AMP -- Amplifier	√	√	√	√	√	
2017\BU-Renegade	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\BU-Renegade	ECM -- Engine Control Module	√	√	√	√	√	0041, 0039, 0041

2017\BU-Renegade	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\BU-Renegade	HALF -- Haptical Lane Feedback	√	√	√	√		
2017\BU-Renegade	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2017\BU-Renegade	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\BU-Renegade	ESM -- Electronic Shifter	√	√	√	√	√	
2017\BU-Renegade	BCM -- Body Controller	√	√	√	√	√	
2017\BU-Renegade	TTM -- Trailer tow module	√	√	√	√	√	
2017\BU-Renegade	ACC -- Adaptive Cruise Control	√	√	√	√	√	
2017\BU-Renegade	PAM -- Park Assist Module	√	√	√	√		
2017\BU-Renegade	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	
2017\D2-Ram Truck	AMP -- Amplifier	√	√	√	√		
2017\D2-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2017\D2-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2017\D2-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\D2-Ram Truck	PTS -- Parktronic	√	√	√	√	√	
2017\D2-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2017\D2-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2017\D2-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\D2-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2017\D2-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\D2-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2017\D2-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\D2-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2017\D2-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\D2-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2017\D2-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2017\D2-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\D2-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2017\D2-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\D2-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2017\D2-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2017\D2-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\D2-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2017\D2-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2017\DD-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2017\DD-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2017\DD-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\DD-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2017\DD-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2017\DD-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2017\DD-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\DD-Ram Truck	AMP -- Amplifier	√	√	√	√		
2017\DD-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2017\DD-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2017\DD-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	



2017\DD-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\DD-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2017\DD-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2017\DD-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2017\DD-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\DD-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\DD-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\DD-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\DD-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2017\DD-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2017\DD-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	EDM -- External Disc Module	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	TCM -- Transmission Control Module	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	DCU -- Dosing Control Unit	√	√	√			
2017\DF-Ram 3500 Cab Chassis 10K	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	BCM -- Body Controller	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	ECM -- Engine Control Module	√	√	√	√	√	0041
2017\DF-Ram 3500 Cab Chassis 10K	SCCM -- Steering Column Control Module	√	√	√	√		
2017\DF-Ram 3500 Cab Chassis 10K	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	VGT -- Variable Geometry Turbo	√	√	√			
2017\DF-Ram 3500 Cab Chassis 10K	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2017\DF-Ram 3500 Cab Chassis 10K	HSM -- Heated Seat Module	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	PTS -- Parktronics	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	RADIO -- Radio	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	DDM -- Driver Door Module	√	√	√	√	√	
2017\DF-Ram 3500 Cab Chassis 10K	AMP -- Amplifier	√	√	√	√		
2017\DJ-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\DJ-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2017\DJ-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2017\DJ-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2017\DJ-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2017\DJ-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2017\DJ-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2017\DJ-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\DJ-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\DJ-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\DJ-Ram Truck	AMP -- Amplifier	√	√	√	√		
2017\DJ-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		

2017\DJ-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2017\DJ-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\DJ-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2017\DJ-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2017\DJ-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\DJ-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\DJ-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2017\DJ-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2017\DJ-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\DJ-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2017\DJ-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2017\DJ-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2017\DJ-Ram Truck	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√		
2017\DP-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\DP-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\DP-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\DP-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2017\DP-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2017\DP-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2017\DP-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\DP-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2017\DP-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2017\DP-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\DP-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2017\DP-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\DP-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2017\DP-Ram Truck	VGT -- Variable Geometry Turbo	√	√	√			
2017\DP-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\DP-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2017\DP-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2017\DP-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2017\DP-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2017\DP-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\DP-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2017\DP-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2017\DS-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2017\DS-Ram Truck	AMP -- Amplifier	√	√	√	√		
2017\DS-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	0041
2017\DS-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\DS-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2017\DS-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2017\DS-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2017\DS-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2017\DS-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2017\DS-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	

2017\DS-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2017\DS-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\DS-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\DS-Ram Truck	EPS -- Electric Power Steering	√	√	√	√		
2017\DS-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\DS-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2017\DS-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\DS-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\DS-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\DS-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2017\DS-Ram Truck	TCM -- Transmission Control Module	√	√	√	√		
2017\DS-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2017\DS-Ram Truck	ESM -- Electronic Shifter	√	√	√	√		
2017\DS-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\DX-Ram Truck	BCM -- Body Controller	√	√	√	√	√	
2017\DX-Ram Truck	EDM -- External Disc Module	√	√	√	√	√	
2017\DX-Ram Truck	PTS -- Parktronics	√	√	√	√	√	
2017\DX-Ram Truck	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\DX-Ram Truck	PDM -- Passenger Door Module	√	√	√	√	√	
2017\DX-Ram Truck	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\DX-Ram Truck	DDM -- Driver Door Module	√	√	√	√	√	
2017\DX-Ram Truck	EPS -- Electric Power Steering	√	√	√	√		
2017\DX-Ram Truck	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\DX-Ram Truck	RADIO -- Radio	√	√	√	√	√	
2017\DX-Ram Truck	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\DX-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\DX-Ram Truck	HSM -- Heated Seat Module	√	√	√	√	√	
2017\DX-Ram Truck	AMP -- Amplifier	√	√	√	√		
2017\DX-Ram Truck	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\DX-Ram Truck	ECM -- Engine Control Module	√	√	√	√	√	
2017\DX-Ram Truck	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\DX-Ram Truck	ASCM -- Air Suspension Control Module	√	√	√	√		
2017\DX-Ram Truck	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\DX-Ram Truck	SCCM -- Steering Column Control Module	√	√	√	√		
2017\DX-Ram Truck	ESM -- Electronic Shifter	√	√	√	√		
2017\DX-Ram Truck	TCM -- Transmission Control Module	√	√	√	√	√	
2017\DX-Ram Truck	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2017\DX-Ram Truck	DCU -- Dosing Control Unit	√	√	√			
2017\DX-Ram Truck	ITBM -- Integrated Trailer Brake Module	√	√	√	√		
2017\FB-500X	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\FB-500X	ESL -- Electronic Steering Lock		√	√	√		
2017\FB-500X	TCM -- Transmission Control Module	√	√	√	√		
2017\FB-500X	ACC -- Adaptive Cruise Control	√	√	√	√	√	
2017\FB-500X	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2017\FB-500X	RBSS -- Right Blind Spot Sensor	√	√	√	√	√	

2017\FB-500X	BCM -- Body Controller	√	√	√	√	√	
2017\FB-500X	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\FB-500X	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\FB-500X	DTCM -- Drive Train Control Module	√	√	√	√		
2017\FB-500X	ECM -- Engine Control Module	√	√	√	√	√	0041, 0039, 0039
2017\FB-500X	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\FB-500X	RRM -- Radio Receiver Module	√	√	√	√	√	
2017\FB-500X	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\FB-500X	AMP -- Amplifier	√	√	√	√	√	
2017\FB-500X	EPS -- Electric Power Steering	√	√	√	√		
2017\FB-500X	PAM -- Park Assist Module	√	√	√	√		
2017\FB-500X	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2017\FB-500X	ESM -- Electronic Shifter	√	√	√	√	√	
2017\FB-500X	LBSS -- Left Blind Spot Sensor	√	√	√	√	√	
2017\FB-500X	HALF -- Haptical Lane Feedback	√	√	√	√		
2017\FF-500	PIM -- Power Inverter Module	√	√	√	√		
2017\FF-500	OBCM -- On Board Charging Module	√	√	√	√		
2017\FF-500	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\FF-500	PTS -- Parktronics	√	√	√	√		
2017\FF-500	BPCM -- Battery Pack Control Module	√	√	√	√	√	0018, 0025, 0024, 0040, 0023, 0042, 0033, 0020, 0045, 0019
2017\FF-500	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2017\FF-500	EVCU -- Electronic Vehicle Control Unit	√	√	√	√	√	0022
2017\FF-500	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\FF-500	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2017\FF-500	VTM -- Vehicle Tracking Module	√	√	√	√		
2017\FF-500	TCM -- Transmission Control Module	√	√	√	√	√	
2017\FF-500	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\FF-500	EAC -- Electric A/C Compressor	√	√	√	√		
2017\FF-500	EPS -- Electric Power Steering	√	√	√	√		
2017\FF-500	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\FF-500	ESM -- Electronic Shifter	√	√	√			
2017\FF-500	RBC -- Regenerative Brake Controller	√	√	√	√		
2017\FF-500	BCM -- Body Controller	√	√	√	√	√	
2017\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2017\J8-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2017\J8-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2017\J8-Wrangler	CGW -- Central Gateway	√	√	√	√	√	0003
2017\J8-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2017\J8-Wrangler	RADIO -- Radio	√	√	√	√	√	
2017\J8-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\J8-Wrangler	ESM -- Electronic Shifter	√	√	√	√	√	

2017J8-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	0015, 0014, 0032, 0044
2017J8-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2017JC-Journey	SCCM -- Steering Column Control Module	√	√	√	√		
2017JC-Journey	PTS -- Parktronics	√	√	√	√	√	
2017JC-Journey	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017JC-Journey	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017JC-Journey	TPM -- Tire Pressure Monitor	√	√	√	√		
2017JC-Journey	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2017JC-Journey	HFM -- Hands Free Module	√	√	√	√		
2017JC-Journey	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017JC-Journey	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2017JC-Journey	TCM -- Transmission Control Module	√	√	√	√	√	
2017JC-Journey	PDM -- Passenger Door Module	√	√	√	√	√	
2017JC-Journey	HSM -- Heated Seat Module	√	√	√	√	√	
2017JC-Journey	DDM -- Driver Door Module	√	√	√	√	√	
2017JC-Journey	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017JC-Journey	TGW -- Telematic Gateway Radio	√	√	√	√		
2017JC-Journey	AMP -- Amplifier	√	√	√	√		
2017JC-Journey	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017JC-Journey	VES3 -- Last Row Screen	√	√	√	√	√	
2017JC-Journey	BCM -- Body Controller	√	√	√	√	√	
2017JC-Journey	VTM -- Vehicle Tracking Module	√	√	√	√		
2017JC-Journey	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017JC-Journey	ECM -- Engine Control Module	√	√	√	√	√	0041
2017JF-Freemont	BCM -- Body Controller	√	√	√	√	√	
2017JF-Freemont	HSM -- Heated Seat Module	√	√	√	√	√	
2017JF-Freemont	ICS -- Integrated Center Stack	√	√	√	√	√	
2017JF-Freemont	AMP -- Amplifier	√	√	√	√		
2017JF-Freemont	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017JF-Freemont	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017JF-Freemont	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017JF-Freemont	TGW -- Telematic Gateway Radio	√	√	√	√		
2017JF-Freemont	VTM -- Vehicle Tracking Module	√	√	√	√		
2017JF-Freemont	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2017JF-Freemont	TPM -- Tire Pressure Monitor	√	√	√	√		
2017JF-Freemont	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017JF-Freemont	ECM -- Engine Control Module	√	√	√	√	√	0041
2017JF-Freemont	SCCM -- Steering Column Control Module	√	√	√	√		
2017JF-Freemont	PTS -- Parktronics	√	√	√	√	√	
2017JF-Freemont	VES3 -- Last Row Screen	√	√	√	√	√	
2017JF-Freemont	DDM -- Driver Door Module	√	√	√	√	√	
2017JF-Freemont	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017JF-Freemont	PDM -- Passenger Door Module	√	√	√	√	√	
2017JF-Freemont	ABS -- Anti Lock Brakes	√	√	√	√	√	

2017\JF-Freemont	TCM -- Transmission Control Module	√	√	√	√	√	
2017\JF-Freemont	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2017\JF-Freemont	HFM -- Hands Free Module	√	√	√	√		
2017\JK-Wrangler	SAS -- Steering Angle Sensor	√	√	√	√		
2017\JK-Wrangler	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\JK-Wrangler	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2017\JK-Wrangler	ASBS -- Automatic Sway Bar System	√	√	√	√		
2017\JK-Wrangler	WCM/TPMS -- Wireless Control	√	√	√	√		
2017\JK-Wrangler	TPM -- Tire Pressure Monitor	√	√	√	√		
2017\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2017\JK-Wrangler	TCM -- Transmission Control Module	√	√	√	√		
2017\JK-Wrangler	ESM -- Electronic Shifter	√	√	√	√	√	
2017\JK-Wrangler	AMP -- Amplifier	√	√	√	√		
2017\JK-Wrangler	ABS -- Anti Lock Brakes	√	√	√	√	√	0002, 0005
2017\JK-Wrangler	RADIO -- Radio	√	√	√	√	√	
2017\JK-Wrangler	HFM -- Hands Free Module	√	√	√	√	√	
2017\JK-Wrangler	ECM -- Engine Control Module	√	√	√	√	√	0015, 0014, 0032, 0044
2017\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\KL-Cherokee	EPS -- Electric Power Steering	√	√	√	√		
2017\KL-Cherokee	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2017\KL-Cherokee	SCCM -- Steering Column Control Module	√	√	√	√	√	
2017\KL-Cherokee	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2017\KL-Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2017\KL-Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2017\KL-Cherokee	PLGM -- Power Liftgate Module	√	√	√	√	√	
2017\KL-Cherokee	AMP -- Amplifier	√	√	√	√		
2017\KL-Cherokee	FFCM -- Forward Facing Camera Module	√	√	√	√		
2017\KL-Cherokee	OCM -- Occupant Classification	√	√	√	√		
2017\KL-Cherokee	RDM -- Rear Drive Module	√	√	√			
2017\KL-Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\KL-Cherokee	DTV -- Digital Television	√	√	√	√	√	
2017\KL-Cherokee	BCM -- Body Controller	√	√	√	√	√	
2017\KL-Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\KL-Cherokee	PAM -- Park Assist Module	√	√	√	√	√	
2017\KL-Cherokee	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\KL-Cherokee	AHLM -- Headlamp Leveling	√	√	√	√		
2017\KL-Cherokee	EDM -- External Disc Module	√	√	√		√	
2017\KL-Cherokee	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\KL-Cherokee	EPB -- Electrical Parking Brake	√	√	√	√		
2017\KL-Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2017\KL-Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2017\KL-Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\KL-Cherokee	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2017\KL-Cherokee	PTU -- Power Transfer Unit	√	√	√			

2017\KL-Cherokee	ESL -- Electronic Steering Lock	√	√	√	√		
2017\KL-Cherokee	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\KL-Cherokee	ECM -- Engine Control Module	√	√	√	√	√	0041
2017\KL-Cherokee	RADIO -- Radio	√	√	√	√	√	
2017\KL-Cherokee	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\KL-Cherokee	ACC -- Adaptive Cruise Control	√	√	√	√		
2017\LA-Challenger	ABS -- Anti Lock Brakes	√	√	√	√	√	0001
2017\LA-Challenger	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2017\LA-Challenger	ESM -- Electronic Shifter	√	√	√	√	√	
2017\LA-Challenger	TPM -- Tire Pressure Monitor	√	√	√	√		
2017\LA-Challenger	SCCM -- Steering Column Control Module	√	√	√	√		
2017\LA-Challenger	EPS -- Electric Power Steering	√	√	√	√		
2017\LA-Challenger	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2017\LA-Challenger	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\LA-Challenger	TCM -- Transmission Control Module	√	√	√	√		
2017\LA-Challenger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\LA-Challenger	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\LA-Challenger	ADCM -- Active Damping Control Module	√	√	√	√		
2017\LA-Challenger	ACC -- Adaptive Cruise Control	√	√	√	√		
2017\LA-Challenger	AMP -- Amplifier	√	√	√	√		
2017\LA-Challenger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\LA-Challenger	PDM -- Passenger Door Module	√	√	√	√	√	
2017\LA-Challenger	RADIO -- Radio	√	√	√	√	√	
2017\LA-Challenger	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\LA-Challenger	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\LA-Challenger	ECM -- Engine Control Module	√	√	√	√	√	0041
2017\LA-Challenger	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\LA-Challenger	BCM -- Body Controller	√	√	√	√	√	
2017\LA-Challenger	HSM -- Heated Seat Module	√	√	√	√	√	
2017\LA-Challenger	DDM -- Driver Door Module	√	√	√	√	√	
2017\LA-Challenger	PTS -- Parktronics	√	√	√	√	√	
2017\LD-Charger	TCM -- Transmission Control Module	√	√	√	√		
2017\LD-Charger	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\LD-Charger	ECM -- Engine Control Module	√	√	√	√	√	0041
2017\LD-Charger	ADCM -- Active Damping Control Module	√	√	√	√		
2017\LD-Charger	ABS -- Anti Lock Brakes	√	√	√	√	√	0001
2017\LD-Charger	BCM -- Body Controller	√	√	√	√	√	
2017\LD-Charger	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\LD-Charger	AMP -- Amplifier	√	√	√	√		
2017\LD-Charger	PTS -- Parktronics	√	√	√	√	√	
2017\LD-Charger	ESM -- Electronic Shifter	√	√	√	√	√	
2017\LD-Charger	DSM -- Display Screen Module	√	√	√	√		
2017\LD-Charger	EPS -- Electric Power Steering	√	√	√	√		
2017\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\LD-Charger	RFH -- Radio Frequency Hub	√	√	√	√	√	

2017\LD-Charger	DDM -- Driver Door Module	√	√	√	√	√	
2017\LD-Charger	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2017\LD-Charger	PDM -- Passenger Door Module	√	√	√	√	√	
2017\LD-Charger	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2017\LD-Charger	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\LD-Charger	ACC -- Adaptive Cruise Control	√	√	√	√		
2017\LD-Charger	SCCM -- Steering Column Control Module	√	√	√	√		
2017\LD-Charger	RADIO -- Radio	√	√	√	√	√	
2017\LD-Charger	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\LD-Charger	VSIM -- Vehicle System Interface Module	√	√	√	√	√	
2017\LD-Charger	FFCM -- Forward Facing Camera Module	√	√	√	√		
2017\LD-Charger	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\LD-Charger	TPM -- Tire Pressure Monitor	√	√	√	√		
2017\LD-Charger	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	TCM -- Transmission Control Module	√	√	√	√		
2017\LX-300,Charger,Magnum,Grand Voyager	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	HSM -- Heated Seat Module	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	PTS -- Parktronics	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	SCCM -- Steering Column Control Module	√	√	√	√		
2017\LX-300,Charger,Magnum,Grand Voyager	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2017\LX-300,Charger,Magnum,Grand Voyager	RADIO -- Radio	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2017\LX-300,Charger,Magnum,Grand Voyager	DDM -- Driver Door Module	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	EPS -- Electric Power Steering	√	√	√	√		
2017\LX-300,Charger,Magnum,Grand Voyager	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	TPM -- Tire Pressure Monitor	√	√	√	√		
2017\LX-300,Charger,Magnum,Grand Voyager	ADCM -- Active Damping Control Module	√	√	√	√		



2017\LX-300,Charger,Magnum,Grand Voyager	FFCM -- Forward Facing Camera Module	√	√	√	√		
2017\LX-300,Charger,Magnum,Grand Voyager	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	ACC -- Adaptive Cruise Control	√	√	√	√		
2017\LX-300,Charger,Magnum,Grand Voyager	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\LX-300,Charger,Magnum,Grand Voyager	ESM -- Electronic Shifter	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	AMP -- Amplifier	√	√	√	√		
2017\LX-300,Charger,Magnum,Grand Voyager	BCM -- Body Controller	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	ECM -- Engine Control Module	√	√	√	√	√	0041
2017\LX-300,Charger,Magnum,Grand Voyager	AFLS -- Adaptive Front Lighting System	√	√	√	√	√	
2017\LX-300,Charger,Magnum,Grand Voyager	PDM -- Passenger Door Module	√	√	√	√	√	
2017\M1-551	OCM -- Occupant Classification	√	√	√	√		
2017\M1-551	DTV -- Digital Television	√	√	√	√	√	
2017\M1-551	ESM -- Electronic Shifter	√	√	√	√		
2017\M1-551	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\M1-551	TCM -- Transmission Control Module	√	√	√	√	√	
2017\M1-551	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2017\M1-551	ESL -- Electronic Steering Lock		√	√	√		
2017\M1-551	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2017\M1-551	ECM -- Engine Control Module	√	√	√	√	√	0041, 0014, 0039, 0041
2017\M1-551	TTM -- Trailer tow module	√	√	√	√	√	
2017\M1-551	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2017\M1-551	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\M1-551	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\M1-551	DTCM -- Drive Train Control Module	√	√	√	√		
2017\M1-551	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\M1-551	BCM -- Body Controller	√	√	√	√	√	
2017\M1-551	PAM -- Park Assist Module	√	√	√	√		
2017\M1-551	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\M1-551	PLGM -- Power Liftgate Module	√	√	√	√	√	
2017\M1-551	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\M1-551	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2017\M1-551	FFCM -- Forward Facing Camera Module	√	√	√	√		
2017\M1-551	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\M1-551	EPS -- Electric Power Steering	√	√	√	√		
2017\M1-551	AMP -- Amplifier	√	√	√	√	√	
2017\M1-551	RRM -- Radio Receiver Module	√	√	√	√	√	
2017\M1-551	ACC -- Adaptive Cruise Control	√	√	√	√	√	

2017\M4-553	TTM -- Trailer tow module	√	√	√	√	√	
2017\M4-553	BCM -- Body Controller	√	√	√	√	√	
2017\M4-553	PAM -- Park Assist Module	√	√	√	√		
2017\M4-553	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2017\M4-553	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\M4-553	ESM -- Electronic Shifter	√	√	√	√		
2017\M4-553	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2017\M4-553	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\M4-553	DTCM -- Drive Train Control Module	√	√	√	√		
2017\M4-553	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2017\M4-553	TCM -- Transmission Control Module	√	√	√	√	√	
2017\M4-553	EPS -- Electric Power Steering	√	√	√	√		
2017\M4-553	ECM -- Engine Control Module	√	√	√	√	√	0041, 0014, 0039, 0041
2017\M4-553	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\M4-553	ACC -- Adaptive Cruise Control	√	√	√	√	√	
2017\M4-553	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2017\M4-553	ESL -- Electronic Steering Lock		√	√	√		
2017\M4-553	DTV -- Digital Television	√	√	√	√	√	
2017\M4-553	FFCM -- Forward Facing Camera Module	√	√	√	√		
2017\M4-553	PLGM -- Power Liftgate Module	√	√	√	√	√	
2017\M4-553	AMP -- Amplifier	√	√	√	√	√	
2017\M4-553	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\M4-553	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\M4-553	RRM -- Radio Receiver Module	√	√	√	√	√	
2017\M4-553	OCM -- Occupant Classification	√	√	√	√		
2017\M4-553	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\M6-556	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2017\M6-556	EPS -- Electric Power Steering	√	√	√	√		
2017\M6-556	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2017\M6-556	FFCM -- Forward Facing Camera Module	√	√	√	√		
2017\M6-556	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2017\M6-556	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2017\M6-556	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\M6-556	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\M6-556	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\M6-556	DTCM -- Drive Train Control Module	√	√	√	√		
2017\M6-556	TCM -- Transmission Control Module	√	√	√	√		
2017\M6-556	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\M6-556	PLGM -- Power Liftgate Module	√	√	√	√	√	
2017\M6-556	ECM -- Engine Control Module	√	√	√	√	√	0041, 0014, 0039, 0041
2017\M6-556	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\M6-556	OCM -- Occupant Classification	√	√	√	√		
2017\M6-556	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\M6-556	DTV -- Digital Television	√	√	√	√	√	
2017\M6-556	ESM -- Electronic Shifter	√	√	√	√		

2017\M6-556	TTM -- Trailer tow module	√	√	√	√	√	
2017\M6-556	RRM -- Radio Receiver Module	√	√	√	√	√	
2017\M6-556	PAM -- Park Assist Module	√	√	√	√		
2017\M6-556	ESL -- Electronic Steering Lock		√	√	√		
2017\M6-556	ACC -- Adaptive Cruise Control	√	√	√	√	√	
2017\M6-556	AMP -- Amplifier	√	√	√	√	√	
2017\M6-556	BCM -- Body Controller	√	√	√	√	√	
2017\MK-Compass,Patriot	SAS -- Steering Angle Sensor	√	√	√	√		
2017\MK-Compass,Patriot	CGW -- Central Gateway	√	√	√	√	√	0003
2017\MK-Compass,Patriot	AMP -- Amplifier	√	√	√	√		
2017\MK-Compass,Patriot	ABS -- Anti Lock Brakes	√	√	√	√	√	0029, 0005, 0002, 0027, 0005, 0029
2017\MK-Compass,Patriot	TCM -- Transmission Control Module	√	√	√	√	√	
2017\MK-Compass,Patriot	FDCM -- Final Drive Control/All Wheel Drive	√	√	√	√	√	
2017\MK-Compass,Patriot	WCM/TPMS -- Wireless Control	√	√	√	√		
2017\MK-Compass,Patriot	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2017\MK-Compass,Patriot	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\MK-Compass,Patriot	ECM -- Engine Control Module	√	√	√	√	√	0012, 0036, 0053
2017\MK-Compass,Patriot	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2017\MK-Compass,Patriot	RADIO -- Radio	√	√	√	√	√	
2017\MK-Compass,Patriot	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\MK-Compass,Patriot	HFM -- Hands Free Module	√	√	√	√	√	
2017\MP-552	TCM -- Transmission Control Module	√	√	√	√	√	
2017\MP-552	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\MP-552	DTCM -- Drive Train Control Module	√	√	√	√		
2017\MP-552	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2017\MP-552	DTV -- Digital Television	√	√	√	√	√	
2017\MP-552	PLGM -- Power Liftgate Module	√	√	√	√	√	
2017\MP-552	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2017\MP-552	AMP -- Amplifier	√	√	√	√	√	
2017\MP-552	ECM -- Engine Control Module	√	√	√	√	√	0041, 0014, 0039, 0041
2017\MP-552	OCM -- Occupant Classification	√	√	√	√		
2017\MP-552	TTM -- Trailer tow module	√	√	√	√	√	
2017\MP-552	FFCM -- Forward Facing Camera Module	√	√	√	√		
2017\MP-552	ESM -- Electronic Shifter	√	√	√	√		
2017\MP-552	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2017\MP-552	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\MP-552	RRM -- Radio Receiver Module	√	√	√	√	√	
2017\MP-552	EPS -- Electric Power Steering	√	√	√	√		
2017\MP-552	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\MP-552	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\MP-552	BCM -- Body Controller	√	√	√	√	√	
2017\MP-552	ACC -- Adaptive Cruise Control	√	√	√	√	√	
2017\MP-552	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	

2017\MP-552	ESL -- Electronic Steering Lock		√	√	√		
2017\MP-552	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\MP-552	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\MP-552	PAM -- Park Assist Module	√	√	√	√		
2017\PD-Neon	ACC -- Adaptive Cruise Control	√	√	√	√	√	
2017\PD-Neon	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\PD-Neon	ECM -- Engine Control Module	√	√	√	√	√	
2017\PD-Neon	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\PD-Neon	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\PD-Neon	AHM -- Additional Heater Module	√	√	√	√		
2017\PD-Neon	RRM -- Radio Receiver Module	√	√	√	√	√	
2017\PD-Neon	ESM -- Electronic Shifter	√	√	√	√	√	
2017\PD-Neon	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2017\PD-Neon	TCM -- Transmission Control Module	√	√	√	√		
2017\PD-Neon	PAM -- Park Assist Module	√	√	√	√		
2017\PD-Neon	EPS -- Electric Power Steering	√	√	√	√		
2017\PD-Neon	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\PD-Neon	BCM -- Body Controller	√	√	√	√	√	
2017\RT-Caravan,Town & Country	SUNR -- Sunroof	√	√	√	√	√	
2017\RT-Caravan,Town & Country	PEM -- Passive Entry Module	√	√	√	√		
2017\RT-Caravan,Town & Country	VES2 -- Second Row Screen	√	√	√	√	√	
2017\RT-Caravan,Town & Country	AMP -- Amplifier	√	√	√	√		
2017\RT-Caravan,Town & Country	HFM -- Hands Free Module	√	√	√	√	√	
2017\RT-Caravan,Town & Country	PLGM -- Power Liftgate Module	√	√	√	√	√	
2017\RT-Caravan,Town & Country	DMFL -- Door Module Front Left	√	√	√	√	√	
2017\RT-Caravan,Town & Country	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\RT-Caravan,Town & Country	TPM -- Tire Pressure Monitor	√	√	√	√		
2017\RT-Caravan,Town & Country	ABS -- Anti Lock Brakes	√	√	√	√	√	0001, 0002
2017\RT-Caravan,Town & Country	EPPM -- Electronic Pedestrian Protection Module	√	√	√	√		
2017\RT-Caravan,Town & Country	RADIO -- Radio	√	√	√	√	√	
2017\RT-Caravan,Town & Country	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2017\RT-Caravan,Town & Country	FSM -- Fold Stow Module	√	√	√	√	√	
2017\RT-Caravan,Town & Country	DVD -- DVD Changer	√	√	√	√		
2017\RT-Caravan,Town & Country	WCM/TPMS -- Wireless Control	√	√	√	√	√	
2017\RT-Caravan,Town & Country	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2017\RT-Caravan,Town & Country	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\RT-Caravan,Town & Country	DMFR -- Door Module Front Right	√	√	√	√	√	
2017\RT-Caravan,Town & Country	MIC/CCN -- Mechanical Instrument Cluster	√	√	√	√	√	
2017\RT-Caravan,Town & Country	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2017\RT-Caravan,Town & Country	TCM -- Transmission Control Module	√	√	√	√	√	
2017\RT-Caravan,Town & Country	PSDMR -- Power Sliding Doors (Right)	√	√	√	√		
2017\RT-Caravan,Town & Country	ECM -- Engine Control Module	√	√	√	√	√	
2017\RT-Caravan,Town & Country	SAS -- Steering Angle Sensor	√	√	√	√		
2017\RT-Caravan,Town & Country	HIDT -- High Intensity Discharge Translator	√	√	√	√	√	

2017\RT-Caravan,Town & Country	CGW -- Central Gateway	√	√	√	√	√	0003
2017\RT-Caravan,Town & Country	VES3 -- Last Row Screen	√	√	√	√	√	
2017\RU	VRM -- Video Routing Module	√	√	√	√		
2017\RU	TCM -- Transmission Control Module	√	√	√	√		
2017\RU	FFCM -- Forward Facing Camera Module	√	√	√	√		
2017\RU	BPCM -- Battery Pack Control Module	√	√	√	√	√	0018, 0019, 0020, 0023, 0024, 0025, 0033, 0045
2017\RU	DSM -- Display Screen Module	√	√	√	√		
2017\RU	AHCP -- Auxiliary Hybrid Control Processor	√	√	√			
2017\RU	ECM -- Engine Control Module	√	√	√	√	√	0041
2017\RU	DMRR -- Rear Door Module (Right)	√	√	√	√	√	
2017\RU	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2017\RU	APM -- Adjustable Pedal Module	√	√	√	√		
2017\RU	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\RU	AMP -- Amplifier	√	√	√	√	√	
2017\RU	EAC -- Electric A/C Compressor	√	√	√	√		
2017\RU	PSDML -- Power Sliding Doors (Left)	√	√	√	√	√	
2017\RU	HSM -- Heated Seat Module	√	√	√	√	√	
2017\RU	ABSO -- Anti Lock Brakes OBD	√	√	√	√	√	
2017\RU	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\RU	HVACR -- Heat, Ventilation and A/C Rear	√	√	√	√	√	
2017\RU	ACC -- Adaptive Cruise Control	√	√	√	√		
2017\RU	ANC -- Active Noise Cancelation	√	√	√	√	√	
2017\RU	CVPM -- Central vision processing module	√	√	√	√		
2017\RU	EBBM -- Electronic Brake Booster Module	√	√	√	√		
2017\RU	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\RU	MSMP -- Memory Seat Module - Passenger	√	√	√	√		
2017\RU	PTS -- Parktronics	√	√	√	√	√	
2017\RU	RADIO -- Radio	√	√	√	√	√	
2017\RU	OCM -- Occupant Classification	√	√	√	√		
2017\RU	EAM -- Emergency Assistance Module	√	√	√	√	√	
2017\RU	RBSS -- Right Blind Spot Sensor	√	√	√			
2017\RU	OBCM -- On Board Charging Module	√	√	√	√		
2017\RU	SCCM -- Steering Column Control Module	√	√	√	√		
2017\RU	LBSS -- Left Blind Spot Sensor	√	√	√			
2017\RU	PLGM -- Power Liftgate Module	√	√	√	√	√	
2017\RU	BCM -- Body Controller	√	√	√	√	√	
2017\RU	EDM -- External Disc Module	√	√	√	√	√	
2017\RU	PSDMR -- Power Sliding Doors (Right)	√	√	√	√	√	
2017\RU	EPS -- Electric Power Steering	√	√	√	√		
2017\RU	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\RU	FSM -- Fold Stow Module	√	√	√	√	√	
2017\RU	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\RU	ESL -- Electronic Steering Lock	√	√	√	√		

2017\RU	DDM -- Driver Door Module	√	√	√	√	√	
2017\RU	HCP -- Hybrid Control Processor	√	√	√	√	√	
2017\RU	DMRL -- Rear Door Module (Left)	√	√	√	√	√	
2017\RU	PDM -- Passenger Door Module	√	√	√	√	√	
2017\RU	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\RU	AHLM -- Headlamp Leveling	√	√	√	√	√	
2017\RU	EOMR -- Electronic Overhead Module Rear	√	√	√	√	√	
2017\UF-200	EPS -- Electric Power Steering	√	√	√	√		
2017\UF-200	RADIO -- Radio	√	√	√	√	√	
2017\UF-200	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\UF-200	RBSS -- Right Blind Spot Sensor	√	√	√	√		
2017\UF-200	LBSS -- Left Blind Spot Sensor	√	√	√	√		
2017\UF-200	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\UF-200	RRM -- Radio Receiver Module	√	√	√	√		
2017\UF-200	ACC -- Adaptive Cruise Control	√	√	√	√		
2017\UF-200	FFCM -- Forward Facing Camera Module	√	√	√	√		
2017\UF-200	PTU -- Power Transfer Unit	√	√	√			
2017\UF-200	SCCM -- Steering Column Control Module	√	√	√	√		
2017\UF-200	PAM -- Park Assist Module	√	√	√	√	√	
2017\UF-200	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√		
2017\UF-200	ECM -- Engine Control Module	√	√	√	√	√	
2017\UF-200	PDM -- Passenger Door Module	√	√	√	√	√	
2017\UF-200	CSWM -- Comfort Seat Wheel Module	√	√	√	√	√	
2017\UF-200	EPB -- Electrical Parking Brake	√	√	√	√		
2017\UF-200	AMP -- Amplifier	√	√	√	√		
2017\UF-200	TCM -- Transmission Control Module	√	√	√	√		
2017\UF-200	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\UF-200	BCM -- Body Controller	√	√	√	√	√	
2017\UF-200	ESM -- Electronic Shifter	√	√	√	√		
2017\UF-200	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\UF-200	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\UF-200	OCM -- Occupant Classification	√	√	√	√		
2017\UF-200	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\UF-200	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\VF-ProMaster	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\VF-ProMaster	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\VF-ProMaster	BCM -- Body Controller	√	√	√	√	√	
2017\VF-ProMaster	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2017\VF-ProMaster	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\VF-ProMaster	EPB -- Electrical Parking Brake	√	√	√	√	√	
2017\VF-ProMaster	TCM -- Transmission Control Module	√	√	√	√	√	
2017\VF-ProMaster	ECM -- Engine Control Module	√	√	√	√	√	0011, 0041
2017\VF-ProMaster	RADIO -- Radio	√	√	√	√	√	
2017\VF-ProMaster	PAM -- Park Assist Module	√	√	√	√		
2017\VF-ProMaster	TPM -- Tire Pressure Monitor	√	√	√	√	√	

2017\VF-ProMaster	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\VM-ProMaster City	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\VM-ProMaster City	TTM -- Trailer tow module	√	√	√	√		
2017\VM-ProMaster City	ESM -- Electronic Shifter	√	√	√	√	√	
2017\VM-ProMaster City	TCM -- Transmission Control Module	√	√	√	√		
2017\VM-ProMaster City	PAM -- Park Assist Module	√	√	√	√		
2017\VM-ProMaster City	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\VM-ProMaster City	RADIO -- Radio	√	√	√	√	√	
2017\VM-ProMaster City	ECM -- Engine Control Module	√	√	√	√	√	
2017\VM-ProMaster City	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\VM-ProMaster City	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\VM-ProMaster City	BCM -- Body Controller	√	√	√	√	√	
2017\VM-ProMaster City	ETM -- Entertainment Telematic Module	√	√	√	√	√	
2017\VM-ProMaster City	TPM -- Tire Pressure Monitor	√	√	√	√	√	
2017\WD-Durango	ECM -- Engine Control Module	√	√	√	√	√	0041
2017\WD-Durango	EPS -- Electric Power Steering	√	√	√	√		
2017\WD-Durango	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\WD-Durango	PLGM -- Power Liftgate Module	√	√	√	√	√	
2017\WD-Durango	BCM -- Body Controller	√	√	√	√	√	
2017\WD-Durango	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\WD-Durango	RBSS -- Right Blind Spot Sensor	√	√	√			
2017\WD-Durango	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\WD-Durango	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\WD-Durango	EDM -- External Disc Module	√	√	√	√	√	
2017\WD-Durango	VES2 -- Second Row Screen	√	√	√	√	√	
2017\WD-Durango	HVACR -- Heat, Ventilation and A/C Rear	√	√	√	√	√	
2017\WD-Durango	SCCM -- Steering Column Control Module	√	√	√	√		
2017\WD-Durango	LBSS -- Left Blind Spot Sensor	√	√	√			
2017\WD-Durango	TCM -- Transmission Control Module	√	√	√	√		
2017\WD-Durango	AMP -- Amplifier	√	√	√	√		
2017\WD-Durango	AHLM -- Headlamp Leveling	√	√	√	√		
2017\WD-Durango	ACC -- Adaptive Cruise Control	√	√	√	√		
2017\WD-Durango	DDM -- Driver Door Module	√	√	√	√	√	
2017\WD-Durango	FFCM -- Forward Facing Camera Module	√	√	√	√		
2017\WD-Durango	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\WD-Durango	ELSD -- Electronic Limited Slip Differential	√	√	√	√		
2017\WD-Durango	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2017\WD-Durango	PDM -- Passenger Door Module	√	√	√	√	√	
2017\WD-Durango	ESM -- Electronic Shifter	√	√	√	√	√	
2017\WD-Durango	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\WD-Durango	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\WD-Durango	HSM -- Heated Seat Module	√	√	√	√	√	
2017\WD-Durango	VES3 -- Last Row Screen	√	√	√	√	√	
2017\WD-Durango	RADIO -- Radio	√	√	√	√	√	

2017\WK-Grand Cherokee	ESM -- Electronic Shifter	√	√	√	√	√	
2017\WK-Grand Cherokee	TCM -- Transmission Control Module	√	√	√	√		
2017\WK-Grand Cherokee	ECM -- Engine Control Module	√	√	√	√	√	
2017\WK-Grand Cherokee	PDM -- Passenger Door Module	√	√	√	√	√	
2017\WK-Grand Cherokee	EDM -- External Disc Module	√	√	√	√	√	
2017\WK-Grand Cherokee	RADIO -- Radio	√	√	√	√	√	
2017\WK-Grand Cherokee	DDM -- Driver Door Module	√	√	√	√	√	
2017\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	√	√	√	√	√	
2017\WK-Grand Cherokee	EAM -- Emergency Assistance Module	√	√	√	√	√	
2017\WK-Grand Cherokee	TPM -- Tire Pressure Monitor	√	√	√	√		
2017\WK-Grand Cherokee	ELSD -- Electronic Limited Slip Differential	√	√	√	√		
2017\WK-Grand Cherokee	ACC -- Adaptive Cruise Control	√	√	√	√		
2017\WK-Grand Cherokee	PTS -- Parktronic	√	√	√	√	√	
2017\WK-Grand Cherokee	FFCM -- Forward Facing Camera Module	√	√	√	√		
2017\WK-Grand Cherokee	EPS -- Electric Power Steering	√	√	√	√		
2017\WK-Grand Cherokee	ASCM -- Air Suspension Control Module	√	√	√	√		
2017\WK-Grand Cherokee	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\WK-Grand Cherokee	VES3 -- Last Row Screen	√	√	√	√	√	
2017\WK-Grand Cherokee	DTV -- Digital Television	√	√	√	√	√	
2017\WK-Grand Cherokee	VES2 -- Second Row Screen	√	√	√	√	√	
2017\WK-Grand Cherokee	AMP -- Amplifier	√	√	√	√	√	
2017\WK-Grand Cherokee	PLGM -- Power Liftgate Module	√	√	√	√	√	
2017\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	√	√	√	√	√	
2017\WK-Grand Cherokee	RBSS -- Right Blind Spot Sensor	√	√	√			
2017\WK-Grand Cherokee	HSM -- Heated Seat Module	√	√	√	√	√	
2017\WK-Grand Cherokee	SCCM -- Steering Column Control Module	√	√	√	√		
2017\WK-Grand Cherokee	AFLS -- Adaptive Front Lighting System	√	√	√	√		
2017\WK-Grand Cherokee	DTCM -- Drive Train Control Module	√	√	√	√	√	
2017\WK-Grand Cherokee	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\WK-Grand Cherokee	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\WK-Grand Cherokee	LBSS -- Left Blind Spot Sensor	√	√	√			
2017\WK-Grand Cherokee	ADCM -- Active Damping Control Module	√	√	√	√		
2017\WK-Grand Cherokee	BCM -- Body Controller	√	√	√	√	√	
2017\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	√	√	√	√		
2017\WK-Grand Cherokee	RFH -- Radio Frequency Hub	√	√	√	√	√	
2017\ZD-Viper (Post-2013)	ABS -- Anti Lock Brakes	√	√	√	√	√	
2017\ZD-Viper (Post-2013)	TPM -- Tire Pressure Monitor	√	√	√	√		
2017\ZD-Viper (Post-2013)	PDM -- Passenger Door Module	√	√	√	√	√	
2017\ZD-Viper (Post-2013)	OCM -- Occupant Classification	√	√	√	√		
2017\ZD-Viper (Post-2013)	DDM -- Driver Door Module	√	√	√	√	√	
2017\ZD-Viper (Post-2013)	IPC -- Instrument Panel Cluster	√	√	√	√	√	
2017\ZD-Viper (Post-2013)	ICS -- Integrated Center Stack	√	√	√	√	√	
2017\ZD-Viper (Post-2013)	ORC -- AirBag/Occupant Restraint	√	√	√	√	√	
2017\ZD-Viper (Post-2013)	RFH -- Radio Frequency Hub	√	√	√	√	√	



2017\ZD-Viper (Post-2013)	RADIO -- Radio	√	√	√	√	√	
2017\ZD-Viper (Post-2013)	ADCM -- Active Damping Control Module	√	√	√	√		
2017\ZD-Viper (Post-2013)	BCM -- Body Controller	√	√	√	√	√	
2017\ZD-Viper (Post-2013)	ECM -- Engine Control Module	√	√	√	√	√	
2017\ZD-Viper (Post-2013)	HVAC -- Heat, Ventilation and A/C	√	√	√	√	√	
2017\ZD-Viper (Post-2013)	SCCM -- Steering Column Control Module	√	√	√	√		